

(NASA-CR-166504) SUMS CALIBRATION TEST
REPORT Final Report (Bendix Aerospace
Systems Div.) 357 p HC A16/MP A01 CSCL 14P

595
NB3-20081


Unclas
G3/35 08993

SUMS CALIBRATION TEST REPORT

March 1982


BSR 4491

ORIGINAL PAGE IS
OF POOR QUALITY



Prepared by: G. Robertson
G. Robertson

Approved by: K. Hsi
K. Hsi



Contract NAS 1-16073

TABLE OF CONTENTS
SUMS Calibration Report

ORIGINAL PAGE 19
OF POOR QUALITY

FORWARD

Section 1: GENERAL DESCRIPTION AND DATA

- Output Data Description
- Engineering Data Conversion Factors
- Ion Pump Current vs. Inlet Pressure
- Mass Range Calibration
- Ion Source and Preamp Temperature Calibration
- Science Data Look-up Table
- Calibration of Instrument Gauges

Section 2: STATIC CALIBRATION

- Sensitivity of SUMS at Inlet for N_2 and O_2
- Ratio of $14 \times 100/28$ for Nitrogen
- Ratio of $16 \times 100/32$ for Oxygen
- Typical Data Plots from N_2 and O_2

Section 3: DYNAMIC CALIBRATION

- Table of Corrected Time, Pressure, Current, Fraction and Ratio of Inlet Transducer to Baratron
- Corrected Ion Current vs. Time
- Plots of Fraction of Static Drops

Section 4: COMPOSITION

- Table of Corrected Time, Pressure and Current of 28 and 32 Peaks
- Corrected Ion Current vs. Time

Appendix A: AS RUN TEST PROCEDURE

- Static
- Calibration of Molecular Leak (N_2 & O_2)
- Dynamic
- Composition

Appendix B: OTHER PROCEDURES

FORWARD

After completion of the Shuttle Upper Atmosphere Mass Spectrometer (SUMS) certification and acceptance tests, instrument calibration was performed on SUMS flight unit number 1, P/N 3290600. Results of the calibration and the as-run test procedures are presented herein.

Section 1 compiles general description and data. These include output data description, engineering data conversion factors, tables and curves and calibration on instrument gauges.

Section 2 presents static calibration results. Instrument sensitive versus external pressure for N_2 and O_2 were determined. Data from each scan of calibration are provided in the data tapes. Typical data plots from N_2 and O_2 are provided. Sensitivity of SUMS at inlet for N_2 and O_2 , and ratios of 14/28 for nitrogen and 16/32 for oxygen are presented.

Section 3 presents dynamic calibration data. Nitrogen gas is admitted to the SUMS inlet in a controlled pressure rise from a pressure of approximately 10^{-4} Torr to approximately 25 Torr. During the pressure rise the nitrogen 28 and 14 peaks are recorded. The response of the instrument from this test are compared to the static calibration to determine the time response of the instrument. Corrected ion current vs. time, plots of fraction of static drops and tables of time, pressure, current, fractions and ratios of inlet transducer to Baratron are provided.

Section 4 presents composition changes calibration results. Nitrogen is admitted to the SUMS inlet in a controlled pressure rise. At given pressure points, the gas composition is switched to a nitrogen/oxygen mixture. From this test, time response to the composition change is determined. Corrected ion current vs. time and tables of time, pressure and current are provided.

The As-Run Procedures for static, dynamic and composition change calibrations are included in Appendix A of this report. Also included is the as-run test procedure for calibration of molecular leaks for O_2 and N_2 .

Data printouts and data tapes from each scan of calibration have been forwarded to Mr. Roy Duckett of NASA/LARC and are not included herein.

SUNS HP9830 DATA TAPE DIRECTORY
(AS OF 3-19-82)

ORIGINAL PAGE 19
OF POOR QUALITY

000 SERIES

TAPE #	BULK #	DATE	TEST #	PROCEDURE	COMMENTS
001	1	8-28-81	TP3298663	BACKGROUND DATA (BEFORE ARGON)	
001	2	8-28-81	TP3298663	DATA AFTER ONE HOUR ARGON	
001	3	9-11-81	TP3298648	RUN #1	
001	4	9-11-81	TP3298648	RUN #2	
002	1	9-22-81	TP3298648	TRIAL RUN #1 (VALVE OPEN)	
002	2	9-23-81	TP3298648	TRIAL RUN #2 (VALVE CLOSED)	
002	3	9-23-81	TP3298648	1.5 HOUR FILAMENT WARM-UP	
002	4	10-1-81		SPECTRA AFTER CHANGING O-RING	
003	1	10-1-81		SAME AS ABOVE EXCEPT WITH VALVE CLOSED	
003	2	10-7-81		SPECTRA FOLLOWING 62 HOUR BAKEOUT WITH VALVE CLOSED	
003	3	10-13-81	TP3298648	PRE-ACCEPTANCE TEST FUNCTIONAL	
003	4	10-15-81	TP3298641	SUNS ACCEPTANCE TEST	*****
004	1	10-15-81	TP3298641	ACCEPT. TEST BARATRON PRESS=4.4X10 ⁻³ TORR	
004	2	10-16-81	TP3298641	SUNS ACCEPTANCE TEST (2ND RUN)	***
004	3	10-22-81	TP3298644	EMI TEST @ 7.5 MHZ PER APPENDIX E	
004	4	10-22-81	TP3298644	EMI TEST, TEST CABLE DISCONNECTED	
005	1	11-10-81	TP3298648	POST BAKEOUT FUNCTIONAL	
005	2	11-12-81	TP3298667	LEAK TEST, 1ST PART	
005	3	11-13-81	TP3298667	LEAK TEST, 1ST PART	
005	4	11-13-81	TP3298667	LEAK TEST, 2ND PART	
006	1	11-20-81	TP3298648	SUNS FUNCTIONAL	
006	2	11-23-81		UAMS FUNCTIONAL (POST VIBRATION)	
006	3	11-23-81	TP3298648	SUNS FUNCTIONAL	
006	4	11-30-81	TP3298667	LEAK TEST (BACKGROUND)	
007	1	11-30-81	TP3298667	LEAK TEST	
007	2	12-23-81	TP3298648	PRE-THERMAL/VACUUM FUNCTIONAL	
007	3	1-5-82	TP3298648	THERMAL/VACUUM FUNCTIONAL, COLD (-49F)	
007	4	1-6-82	TP3298648	THERMAL/VACUUM FUNCTIONAL, HOT (+90F)	
008	1	2-23-82	TP3298648	DYNAMIC CALIBRATION BACKGROUND (BEFORE)	
008	2	2-24-82	TP3298648	DYNAMIC CALIBRATION BACKGROUND (AFTER)	
008	3	2-25-82	SPECIAL	BACKGROUND (BEFORE), ALL VALVES OPEN	
008	4	2-26-82	SPECIAL	BACKGROUND (AFTER), ALL VALVES OPEN	
009	1	3-2-82	TP3298648	COMPOSITION CHANGE CAL BCKGRND (BEFORE)	
009	2	3-4-82	TP3298648	COMPOSITION CHANGE CAL BCKGRND (AFTER)	
009	3				
009	4				

TAPE #	BULK #	DATE	TEST #	PROCEDURE	COMMENTS
101	1	1-20-82	TP3290648	N2 (RESIDUALS)	RANGE VALVE OPEN
101	2	1-20-82	TP3290648	N2 (1 X 10 ⁻⁶ TORR)	RANGE VALVE OPEN
101	3	1-20-82	TP3290648	N2 (3 X 10 ⁻⁶ TORR)	RANGE VALVE OPEN
101	4	1-20-82	TP3290648	N2 (1 X 10 ⁻⁵ TORR)	RANGE VALVE OPEN
101	5	1-20-82	TP3290648	N2 (3 X 10 ⁻⁵ TORR)	RANGE VALVE OPEN
101	6	1-20-82	TP3290648	N2 (1 X 10 ⁻⁴ TORR)	RANGE VALVE OPEN
102	1	1-20-82	TP3290648	N2 (3 X 10 ⁻⁴ TORR)	RANGE VALVE OPEN
102	2	1-20-82	TP3290648	N2 (1 X 10 ⁻³ TORR)	RANGE VALVE OPEN
102	3	1-20-82	TP3290648	N2 (3 X 10 ⁻³ TORR)	RANGE VALVE OPEN
102	4	1-20-82	TP3290648	N2 (4.6 X 10 ⁻³ TORR)	RANGE VALVE OPEN
102	5	1-21-82	TP3290648	N2 (BACKGROUND)	PROTECTION VALVE CLOSED
102	6	1-21-82	TP3290648	N2 (BKGD)	RANGE, PROT OPEN; INLET CLOSED
103	1	1-21-82	TP3290648	N2 (1 X 10 ⁻² TORR)	RANGE VALVE CLOSED
103	2	1-21-82	TP3290648	N2 (0.8380 TORR)	RANGE VALVE CLOSED
103	3	1-21-82	TP3290648	N2 (0.100 TORR)	RANGE VALVE CLOSED
103	4	1-21-82	TP3290648	N2 (0.300 TORR)	RANGE VALVE CLOSED
103	5	1-21-82	TP3290648	N2 (1.00 TORR)	RANGE VALVE CLOSED
103	6	1-21-82	TP3290648	N2 (3.00 TORR)	RANGE VALVE CLOSED
104	1	1-21-82	TP3290648	N2 (10.00 TORR)	RANGE VALVE CLOSED
104	2	1-21-82	TP3290648	N2 (21.00 TORR)	RANGE VALVE CLOSED
104	3	1-21-82	TP3290648	N2 (32.72 TORR)	RANGE VALVE CLOSED
104	4	1-21-82	TP3290648	N2 (BACKGROUND)	ALL VALVES CLOSED
104	5				
104	6				
105	1	1-26-82	TP3290648	O2 (RESIDUALS)	RANGE VALVE OPEN
105	2	1-26-82	TP3290648	O2 (1.1 X 10 ⁻⁶ TORR)	RANGE VALVE OPEN
105	3	1-26-82	TP3290648	O2 (3.4 X 10 ⁻⁶ TORR)	RANGE VALVE OPEN
105	4	1-26-82	TP3290648	O2 (8.6 X 10 ⁻⁵ TORR)	RANGE VALVE OPEN
105	5	1-26-82	TP3290648	O2 (4.2 X 10 ⁻⁵ TORR)	RANGE VALVE OPEN
105	6	1-26-82	TP3290648	O2 ()	TORR) RANGE VALVE OPEN
106	1	1-26-82	TP3290648	O2 (9.5 X 10 ⁻⁵ TORR)	RANGE VALVE OPEN
106	2	1-26-82	TP3290648	O2 (2.3 X 10 ⁻⁵ TORR)	RANGE VALVE OPEN
106	3	1-26-82	TP3290648	O2 (2.97 X 10 ⁻⁴ TORR)	RANGE VALVE OPEN
106	4	1-26-82	TP3290648	O2 (1.00 X 10 ⁻³ TORR)	RANGE VALVE OPEN
106	5	1-26-82	TP3290648	O2 (3.00 X 10 ⁻³ TORR)	RANGE VALVE OPEN
106	6	1-27-82	TP3290648	O2 (BACKGROUND)	RANGE VALVE CLOSED
107	1	1-27-82	TP3290648	O2 (1.0 X 10 ⁻²)	RANGE VALVE CLOSED
107	2	1-27-82	TP3290648	O2 (3.0 X 10 ⁻² TORR)	RANGE VALVE CLOSED
107	3	1-27-82	TP3290648	O2 (1.0 X 10 ⁻¹ TORR)	RANGE VALVE CLOSED
107	4	1-27-82	TP3290648	O2 (3.0 X 10 ⁻¹ TORR)	RANGE VALVE CLOSED
107	5	1-27-82	TP3290648	O2 (1.0 TORR)	RANGE VALVE CLOSED
107	6	1-27-82	TP3290648	O2 (3.0 TORR)	RANGE VALVE CLOSED

ORIGINAL PAGE IS
OF POOR QUALITY

108 * 1 * 1-27-82 * TP3290648 * O2 (10.0 TORR) RANGE VALVE CLOSED
108 * 2 * * * *
108 * 3 * * * *
108 * 4 * * * *
108 * 5 * * * *
108 * 6 * * * *

109 * 1 * 2-1-82 * TP3290648 * O2/EXTRA (5.0 X 10-8 TORR) RANGE OPEN
109 * 2 * 2-1-82 * TP3290648 * O2/EXTRA (9.9 X 10-7 TORR) RANGE OPEN
109 * 3 * 2-1-82 * TP3290648 * O2/EXTRA (3.0 X 10-6 TORR) RANGE OPEN
109 * 4 * 2-1-82 * TP3290648 * O2/EXTRA (1.0 X 10-5 TORR) RANGE OPEN
109 * 5 * 2-1-82 * TP3290648 * O2/EXTRA (3.1 X 10-5 TORR) RANGE OPEN
109 * 6 * 2-1-82 * TP3290648 * O2/EXTRA (1.4 X 10-4 TORR) RANGE OPEN

110 * 1 * 2-2-82 * TP3290648 * N2/O2 (9.7 X 10-8) RANGE VALVE OPEN
110 * 2 * 2-2-82 * TP3290648 * N2/O2 (1.1 X 10-6 TORR) RANGE VALVE OPEN
110 * 3 * 2-2-82 * TP3290648 * N2/O2 (3.2 X 10-6 TORR) RANGE VALVE OPEN
110 * 4 * 2-2-82 * TP3290648 * N2/O2 (1.1 X 10-5 TORR) RANGE VALVE OPEN
110 * 5 * 2-2-82 * TP3290648 * N2/O2 (3.2 X 10-5 TORR) RANGE VALVE OPEN
110 * 6 * 2-2-82 * TP3290648 * N2/O2 (1.4 X 10-4 TORR) RANGE VALVE OPEN

111 * 1 * 2-2-82 * TP3290648 * N2/O2 (3.0 X 10-5 TORR) RANGE VALVE OPEN
111 * 2 * 2-2-82 * TP3290648 * N2/O2 (1.0 X 10-4 TORR) RANGE VALVE OPEN
111 * 3 * 2-2-82 * TP3290648 * N2/O2 (3.0 X 10-4 TORR) RANGE VALVE OPEN
111 * 4 * 2-3-82 * TP3290648 * N2/O2 (1.0 X 10-3 TORR) RANGE VALVE OPEN
111 * 5 * 2-3-82 * TP3290648 * N2/O2 (3.2 X 10-3 TORR) RANGE VALVE OPEN
111 * 6 * * * *

112 * 1 * * *
112 * 2 * * *
112 * 3 * * *
112 * 4 * * *
112 * 5 * * *
112 * 6 * * *

113 * 1 * 2-4-82 * TP3290648 * N2/O2 (5.1 X 10-4 TORR) RANGE VALVE OPEN
113 * 2 * 2-4-82 * TP3290648 * N2/O2 (1.0 X 10-3 TORR) RANGE VALVE OPEN
113 * 3 * 2-4-82 * TP3290648 * N2/O2 (4.0 X 10-3 TORR) RANGE VALVE OPEN
113 * 4 * 2-4-82 * TP3290648 * N2/O2 (BACKGROUND) RANGE VALVE OPEN
113 * 5 * 2-4-82 * TP3290648 * N2/O2 (BACKGROUND) RANGE VALVE CLOSED
113 * 6 * * *

114 * 1 * 2-4-82 * TP3290648 * N2/O2 (4.2 X 10-3 TORR) RANGE CLOSED
114 * 2 * 2-4-82 * TP3290648 * N2/O2 (1.0 X 10-2 TORR) RANGE CLOSED
114 * 3 * 2-4-82 * TP3290648 * N2/O2 (3.0 X 10-2 TORR) RANGE CLOSED
114 * 4 * 2-4-82 * TP3290648 * N2/O2 (1.0 X 10-1 TORR) RANGE CLOSED
114 * 5 * 2-4-82 * TP3290648 * N2/O2 (3.0 X 10-1 TORR) RANGE CLOSED
114 * 6 * 2-4-82 * TP3290648 * N2/O2 (1.0 TORR) RANGE CLOSED

115 * 1 * 2-4-82 * TP3290648 * N2/O2 (3.0 TORR) RANGE VALVE CLOSED
115 * 2 * 2-4-82 * TP3290648 * N2/O2 (10.00 TORR) RANGE VALVE CLOSED
115 * 3 * 2-4-82 * TP3290648 * N2/O2 (30.1 TORR) RANGE VALVE CLOSED
115 * 4 * 2-4-82 * TP3290648 * N2/O2 (BACKGROUND) INLET CLOSED, RANGE OPEN
115 * 5 * 2-4-82 * TP3290648 * N2/O2 (BACKGROUND) INLET OPEN, RANGE OPEN
115 * 6 * * *

200 SERIES
(DYNAMIC CALIBRATION)

4 OF 5

TAPE #	BULK #	DATE	TEST #	PROCEDURE	COMMENTS
201	1	2-23-82	TP3290648	RUN #1	NOMINAL PRESSURE PROFILE
201	2	2-23-82	TP3290648	RUN #2	NOMINAL PRESSURE PROFILE
201	3	2-23-82	TP3290648	RUN #3	NOMINAL PRESSURE PROFILE
201	4	2-24-82	TP3290648	RUN #1	+25% P/P PRESSURE PROFILE
202	1	2-24-82	TP3290648	RUN #2	+25% P/P PRESSURE PROFILE
202	2	2-26-82	SPECIAL		NOMINAL PROFILE TO 150 SECONDS THEN HOLD
202	3	2-26-82	SPECIAL		NOMINAL PROFILE TO 630 SECONDS THEN HOLD
202	4	2-26-82	SPECIAL		0.1 X EXP(-0.0132 X T) PROFILE
203	1	3-5-82	EXTRA		NOMINAL PRESSURE PROFILE
203	2	3-5-82	EXTRA		NOMINAL PROFILE TO 155 SECONDS THEN HOLD
203	3	3-5-82	EXTRA		NOMINAL PROFILE TO 635 SECONDS THEN HOLD
203	4				

ORIGINAL PAGE IS
OF POOR QUALITY

200 SERIES
(COMPOSITION CHANGE CALIBRATION)

TAPE #	BULK #	DATE	TEST #	PROCEDURE	COMMENTS
301	1	3-2-82	TP3290648	RUN TYPE #1, O2	=> N2
301	2	3-4-82	TP3290648	RUN TYPE #2, O2	=> N2
301	3	3-4-82	TP3290648	RUN TYPE #3, O2	=> N2
301	4	3-4-82	TP3290648	RUN TYPE #4, O2	=> N2
301	5	3-4-82	TP3290648	RUN TYPE #1, N2	=> N2/O2
301	6	3-4-82	TP3290648	RUN TYPE #2, N2	=> N2/O2
301	1	3-4-82	TP3290648	RUN TYPE #3, N2	=> N2/O2
301	2	3-4-82	TP3290648	RUN TYPE #4, N2	=> N2/O2
301	3				
301	4				
301	5				
301	6				

ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

OEX/SUMS DATA FORMAT DETAILS

Prepared by:

Greg Robertson
Bendix Aerospace Operations

23 November 1981

Background

The OEX/SUMS instrument is built around a Viking/UAMS instrument. The UAMS data output format is not directly compatible with the Shuttle PCM system. In order to interface UAMS with the PCM, it was necessary to change its serial output format to a parallel format. This is all done within the SUMS instrument.

UAMS Data Format

The SUMS data format is easier to understand if the UAMS format is first understood. The data comes from UAMS serially in 5 second minor frames. (See Figure 1). The first 16 bits form the ID or SYNC word. The next 12 eight bit words are UAMS Housekeeping words. (Not to be confused with SUMS Housekeeping words which will be discussed later). The remainder of the 5 second frame is made up of 432 nine bit science words.

The 432 nine bit science words are of two types; high mass and low mass. There are 360 high mass and 72 low mass science words per 5 second minor frame. Thus there are five times as many high mass words as low mass words. The low mass words follow every fifth high mass word in the UAMS data format. The first high mass word which has a low mass word following it is dependent upon the interlacing frame number which is discussed below.

As mentioned above, the UAMS data comes out in the form of 5 second minor frames. Four of these minor frames constitute a major frame. It is important to note that each 5 second minor frame stands alone as a complete mass spectra. The only difference, format wise, between adjacent 5 second minor frames is the interlacing of the high and low mass science words.

The four different minor frame formats are referred to as frames #1, #2, #3 or #4. Two bits in the first 8 bit UAMS Housekeeping word are used to identify the frame number. (See Table 1 for bit definitions).

The high mass/low mass interlacing is as follows. The first of the 432 science words is always a high mass word. For frame #1, the first low mass word follows the first high mass word, and low mass words follow every fifth high mass

**ORIGINAL PAGE IS
OF POOR QUALITY**

word thereafter. For frame #2 the first low mass word follows the second high mass word, and low mass words follow every fifth high mass word thereafter. For frames #3 and #4 the first low mass word follows the third and fourth, respectively, high mass words, and low mass words follow every fifth high mass word thereafter. This interlacing is illustrated below where "H" signifies a 9 bit high mass science word and "L" signifies a 9 bit low mass science word.

```

frame #1  H L H H H H H L H H H H H L H H ...
frame #2  H H L H H H H H L H H H H H L H ...
frame #3  H H H L H H H H H L H H H H H L ...
frame #4  H H H H L H H H H H L H H H H H ...

```

Table 1 identifies and describes the format of the 12 eight bit UAMS Housekeeping words. References to the SUMS or PCM data formats will be discussed below.

SUMS Data Format

The SUMS interfaces with the PCM consist of two 8 bit parallel digital ports and 12 analog ports. SUMS is currently using PCM Format 3A. In this format SUMS has continuous use of word slots 47 and 48 for the digital data. The analog data uses word slot 49, the first 12 words deep in each data cycle.

Table 2 lists the SUMS analog channels and their levels. The remainder of the SUMS Data Format discussion will deal only with the SUMS parallel digital data.

The function of the SUMS digital electronics is to convert the UAMS serial data to 16 bit parallel words which the PCM can accept. Since the rate at which the PCM can sample SUMS data is a function of the PCM data cycle width, it was not practical to have a synchronous interface with UAMS. Therefore the interface with UAMS is asynchronous and the PCM oversamples SUMS in order to capture all the UAMS data.

SUMS outputs a 16 bit (2-8 bit) parallel word once every PCM mainframe. This word is synchronous with the PCM clock. Its rate is the same as the PCM mainframe rate. (8 mseconds nominally).

The SUMS 16 bit words are of two types (see Figure 2). The first type is the SUMS Data Word which contains the UAMS digital data. The SUMS Data Words can be recognized by a zero in the MSB. The second type of word is the SUMS Housekeeping word. The SUMS Housekeeping words have a one in the MSB.

The UAMS Data is formatted into 16 bit SUMS Data Words as follows: (refer to Figures 1 and 2). The 16 bit UAMS ID/SYNC word is split into two 8 bit parts. Each 8 bit part is put into the low end of a 16 bit SUMS data word.

ORIGINAL PAGE IS
OF POOR QUALITY

Each of the 12 8 bit UAMS Housekeeping words are put into the low end of a 16 bit SUMS Data word. The 432 9 bit science words are also each put into the low end of a 16 SUMS Data word. Therefore it requires a total of 446 16 bit SUMS Data words to output a 5 second frame of UAMS data.

Note again that all SUMS Data words are identified by a zero in the MSB. In addition, the two halves of the UAMS ID/SYNC word have bit 9 set to a one. (See Figure 2). This bit uniquely identifies the two halves of the ID/SYNC word for all SUMS digital data. Bits 10 through 14 of the SUMS Data Word are don't cares.

The ID/SYNC word (in SUMS format) is 0XXXXXX1X11101011 for the first half and 0XXXXXX1X10010000 for the second half.


At a PCM mainframe rate of 8 milliseconds it takes the PCM 3.57 seconds (which is less than 5 seconds) to collect 446 SUMS words. This illustrates the need for the SUMS Housekeeping words. When the PCM is ready to read a word, SUMS will send it a Data Word if one is available. If not it sends a SUMS Housekeeping word. The SUMS Housekeeping word contains 14 one bit status flags. (See Table 3).

Figure 3 shows a typical SUMS Data Frame.



SHUTTLE OEX-SUMS

FIGURE 1
UAMS DATA FORMAT



ORIGINAL PAGE IS
OF POOR QUALITY



Communications
Division

Aerospace Systems Operations

ORIGINAL PAGE 12
OF POOR QUALITY

Table 1

UAMS HOUSEKEEPING WORDS MEASUREMENTS LIST
prepared by: Greg Robertson, Bendix Aerospace
date: 2-9-81
revised: 3-23-82

	<u>Measurement Title</u>	<u>Range**</u>	<u>Digital Limits (Decimal)</u>
1*	Filament No., [1. eV, Frame No.	***	---
2	+15 VDC Supply	0-20 VDC	178 - 204
3	-15 VDC Supply	-30 - 0 VDC	120 - 142
4	Ion Pump Voltage	0-5000 VDC	143 - 191
5	Ion Source Temperature	-60-300°F	029 - 120
6	Electrometer Preamp Temp.	-60-190°F	076 - 195
7	+5 VDC Supply	0-10 VDC	115 - 141
8	A/D Voltage Reference	0-10 VDC	153 - 174
9	Total Emission Current	0-200 μ A	115 - 141
10	Electron Collector Current	0-200 μ A	092 - 134
11	Electron Acceleration Voltage	0-100 VDC	178 - 204
12	Ion Acceleration Voltage	0-200 VDC	026 - 046

* This number is the order in which the UAMS HOUSEKEEPING words follow the UAMS ID/Sync word in the PCM data format. That is, once the second half of the UAMS ID word (=0290H) is seen in the PCM data stream, then the next SUMS Data Word (i.e., the next word with MSB = 0) will be a 16 bit word of which the lower 8 bits will be a UAMS HOUSEKEEPING word. This word will contain information about the status of the Filament Number, Electron Ionizing Potential and the UAMS Interlacing Frame Number.

The next SUMS Data Word will contain the +15 VDC Supply voltage, and so on. The UAMS Science Data follows the twelfth UAMS HOUSEKEEPING word.

** The ranges of all the UAMS HOUSEKEEPING words, with the exception of 1, 5 and 6, are linear and represented by an 8 bit number.

*** The first SUMS Data Word containing a UAMS HOUSEKEEPING word is coded as follows (bit 15 = MSB)

<u>BITS</u>	<u>MEASUREMENT</u>	<u>VALUE</u>
7 and 6	---	---
5 and 4	Filament in use	10 = #1; 01 = #2
3 and 2	Ionizing Potential	10 = 75 eV; 01 = 25 eV
1 and 0	Interlacing frame #	00 = #1; 01 = #2; 10 = #3; 11 = #4
15 - 8	---	0XXX XXXX


FIGURE 2
SUMS DATA FORMAT

SHUTTLE OEX-SUMS




Revised: 11-23-81

ID or UAMS HOUSEKEEPING = X
Science = 0 or 1



ORIGINAL PAGE 18
OF POOR QUALITY

SUMS HOUSEKEEPING
WORD



ORIGINAL PAGE 13
OF POOR QUALITY

Table 3

SUMS HOUSEKEEPING WORDS BIT ASSIGNMENT
prepared by: G. Robertson, Bendix Aerospace
date: 2-9-81
revised: 3-23-82

BIT NUMBER	FUNCTION	VALUE	
		0=	1=
15	always set to one for SUMS HOUSEKEEPING words		
14	Ion Pump Current	Too High	(O.K.)
13	UAMS Ion Pump Power	(ON)	OFF
12	SUMS Instrument Power	ON	OFF
11	Inlet Pressure	(Too High)	O.K.
10	Internal Pressure	Too Low	(O.K.)
9	always set to zero for non-SUMS ID word		
8	SUMS Program Error	Error Detected	(O.K.)
7	Processor Halt	Halt	(O.K.)
6	SUMS Buffer Overflow	Overflow Detected	(O.K.)
5	Decode	ID word found	Searching for ID word
4	UAMS Reset	Operate Reset	(Release Reset)
3	System Reset	Operate Reset	(Release Reset)
2	Protection Valve Command	Open	(Close)
1	Range Valve Command	Open	(Close)
0	Inlet Valve Command	Open	(Close)

Parenthetical values are "on ground nominal".


SUMS Ion Pump Power On: SUMS HSK Word = D5FFH*

SUMS Ion Pump & Inst. Power On: SUMS HSK Word = C5DFH**

*This number is constant once everything is initialized (msecs).

**This number is constant once UAMS data is locked on (msecs).

Figure 3 Map of One SUMS Data Frame

ORIGINAL PAGE IS
OF POOR QUALITY

Note: The placement of the SUMS HSK words above is typical only. Actual placement is random and will vary from frame to frame.

Table 4 SUMS PCM DATA TEMPERATURE LOOKUP TABLE

ORIGINAL PAGE IS
OF POOR QUALITY

THERMISTOR 8-311-P-10-046 R1=37000 R2=14000 G=5.0560 OFFSET=3.7785

PCM A/D OUTPUT	TEMPERATURE (DEC F)	UNCERTAINTY (+/- DEC F)	PCM A/D OUTPUT	TEMPERATURE (DEC F)	UNCERTAINTY (+/- DEC F)
3	-39.2	3.5	66	-0.9	1.9
4	-38.3	3.5	67	-0.5	1.9
5	-37.4	3.4	68	-0.0	1.9
6	-36.5	3.4	69	0.4	1.9
7	-35.7	3.3	70	0.9	1.9
8	-34.8	3.2	71	1.3	1.9
9	-34.0	3.2	72	1.8	1.9
10	-33.2	3.1	73	2.2	1.9
11	-32.4	3.1	74	2.6	1.9
12	-31.6	3.0	75	3.1	1.8
13	-30.9	3.0	76	3.5	1.8
14	-30.1	3.0	77	4.0	1.8
15	-29.4	2.9	78	4.4	1.8
16	-28.6	2.9	79	4.8	1.8
17	-27.9	2.8	80	5.3	1.8
18	-27.2	2.8	81	5.7	1.8
19	-26.5	2.8	82	6.1	1.8
20	-25.8	2.7	83	6.6	1.8
21	-25.2	2.7	84	7.0	1.8
22	-24.5	2.7	85	7.4	1.8
23	-23.8	2.6	86	7.8	1.8
24	-23.2	2.6	87	8.3	1.8
25	-22.6	2.6	88	8.7	1.8
26	-21.9	2.5	89	9.1	1.8
27	-21.3	2.4	90	9.5	1.8
28	-20.7	2.4	91	9.9	1.8
29	-20.1	2.4	92	10.4	1.6
30	-19.5	2.4	93	10.8	1.6
31	-18.9	2.4	94	11.2	1.6
32	-18.3	2.3	95	11.6	1.6
33	-17.7	2.3	96	12.0	1.6
34	-17.1	2.3	97	12.4	1.6
35	-16.6	2.3	98	12.8	1.6
36	-16.0	2.3	99	13.3	1.6
37	-15.4	2.2	100	13.7	1.6
38	-14.9	2.2	101	14.1	1.7
39	-14.3	2.2	102	14.5	1.7
40	-13.8	2.2	103	14.9	1.7
41	-13.2	2.2	104	15.3	1.7
42	-12.7	2.2	105	15.7	1.7
43	-12.2	2.1	106	16.1	1.8
44	-11.7	2.1	107	16.5	1.8
45	-11.1	2.1	108	16.9	1.7
46	-10.6	2.1	109	17.4	1.7
47	-10.1	2.1	110	17.8	1.7
48	-9.6	2.1	111	18.2	1.7
49	-9.1	2.1	112	18.6	1.7
50	-8.6	2.1	113	19.0	1.7
51	-8.1	2.0	114	19.4	1.7
52	-7.6	2.0	115	19.8	1.7
53	-7.1	2.0	116	20.2	1.7
54	-6.6	2.0	117	20.6	1.7
55	-6.1	2.0	118	21.0	1.7
56	-5.6	2.0	119	21.4	1.7
57	-5.2	2.0	120	21.8	1.7
58	-4.7	2.0	121	22.2	1.7
59	-4.2	2.0	122	22.6	1.7
60	-3.7	1.9	123	23.0	1.7
61	-3.3	1.9	124	23.4	1.7
62	-2.8	1.9	125	23.8	1.7
63	-2.3	1.9	126	24.3	1.7
64	-1.9	1.9	127	24.7	1.7
65	-1.4	1.9			

ORIGINAL PAGE IS
OF POOR QUALITY

PCM A/D OUTPUT	TEMPERATURE (DEG F)	UNCERTAINTY (+/- DEG F)	PCM A/D OUTPUT	TEMPERATURE (DEG F)	UNCERTAINTY (+/- DEG F)
126	25.1	1.7	191	82.3	1.9
129	25.5	1.7	192	82.6	1.9
130	25.9	1.7	193	83.3	1.9
131	26.3	1.7	194	83.8	1.9
132	26.7	1.7	195	84.3	1.9
133	27.1	1.7	196	84.8	2.0
134	27.5	1.7	197	85.3	2.0
135	27.9	1.7	198	85.8	2.0
136	28.3	1.7	199	86.3	2.0
137	28.7	1.7	200	86.8	2.0
138	29.1	1.7	201	87.3	2.0
139	29.5	1.7	202	87.8	2.0
140	29.9	1.7	203	88.4	2.0
141	30.4	1.8	204	88.9	2.0
142	30.8	1.8	205	89.4	2.1
143	31.2	1.8	206	89.9	2.1
144	31.6	1.8	207	90.5	2.1
145	32.0	1.7	208	91.0	2.1
146	32.4	1.7	209	91.5	2.1
147	32.8	1.7	210	92.1	2.1
148	33.3	1.7	211	92.6	2.1
149	33.7	1.7	212	93.2	2.2
150	34.1	1.7	213	93.8	2.2
151	34.5	1.7	214	94.3	2.2
152	34.9	1.7	215	94.9	2.2
153	35.3	1.7	216	95.5	2.2
154	35.8	1.7	217	96.0	2.2
155	36.2	1.7	218	96.6	2.2
156	36.6	1.7	219	97.2	2.3
157	37.0	1.7	220	97.8	2.3
158	37.5	1.7	221	98.4	2.3
159	37.9	1.7	222	99.0	2.3
160	38.3	1.7	223	99.6	2.3
161	38.7	1.7	224	100.2	2.3
162	39.2	1.7	225	100.8	2.4
163	39.6	1.7	226	101.4	2.4
164	40.0	1.7	227	102.1	2.4
165	40.5	1.7	228	102.7	2.4
166	40.9	1.7	229	103.4	2.5
167	41.3	1.8	230	104.0	2.5
168	41.8	1.8	231	104.7	2.5
169	42.2	1.8	232	105.3	2.5
170	42.7	1.8	233	106.0	2.5
171	43.1	1.8	234	106.7	2.6
172	43.5	1.8	235	107.4	2.6
173	44.0	1.8	236	108.1	2.6
174	44.4	1.8	237	108.8	2.7
175	44.9	1.8	238	109.5	2.7
176	45.3	1.8	239	110.2	2.7
177	45.8	1.8	240	110.9	2.7
178	46.2	1.8	241	111.7	2.8
179	46.7	1.8	242	112.4	2.8
180	47.2	1.8	243	113.2	2.9
181	47.6	1.8	244	113.9	2.9
182	48.1	1.8	245	114.7	2.9
183	48.5	1.8	246	115.5	2.9
184	49.0	1.9	247	116.3	3.0
185	49.5	1.9	248	117.1	3.0
186	49.9	1.9	249	117.9	3.1
187	50.4	1.9	250	118.6	3.1
188	50.9	1.9	251	119.6	3.2
189	51.4	1.9	252	120.5	3.2
190	51.9	1.9	253	121.4	3.2

UAMS HOUSE KEEPING MONITORS

1. +15 Volt Supply $-V_{15}$

$$V_{15} = \frac{20 * DIG_{15}}{255}$$

Where DIG_{15} is the digital output for +15 volt supply.
2. -15 Volt Supply V_{-15}

$$V_{-15} = 0.118 * DIG_{-15} - 0.1574 * DIG_{15}$$

Where DIG_{-15} is digital output of -15 Volt supply
 DIG_{15} is digital output of 15 Volt supply
3. Ion Pump Voltage

$$V_{IP} = 19.8 * DIG_{IP} \text{ volts}$$
4. Ion Source Temperature
 See calibration curve
5. Pre Amp Temperature
 See calibration curve
6. +5 Volt Supply

$$V_5 = \frac{10 * DIG_5}{255} \text{ Volts}$$
7. A/D Reference Voltage

$$V_{A/D} = \frac{10 * DIG_{A/D}}{255} \text{ Volts}$$
8. Emission Current

$$I_e = \frac{100 * DIG_e}{126} \mu A$$
9. Collector Current

$$I_c = \frac{100 * DIG_c}{126}$$
10. Electron Voltage


$$V_{eV} = \frac{75 * DIG_{eV}}{190} \text{ Near 75 eV}$$

$$V_{eV} = \frac{25 * DIG_{eV}}{70} \text{ Near 25 eV}$$

ORIGINAL PAGE IS
OF POOR QUALITY

11. Ion Accelerator Voltage
Ion accelerator voltage is proportional to digital output
Nominal digital output is 39.

S/N 6 Mass Range Calibration




K-E SEMILOGARITHMIC 40 4973
3 CYCLES x 70 DIVISIONS
NEWTON & CRISP CO.

K-E 10.2 TO THE CENTIMETER 46 1513
 MADE IN U.S.A.
 KLUFFEL & EIDER CO.

DIGITAL OUT PUT 153

S/N 6



SCIENCE DATA LOOK UP TABLE

ORIGINAL PAGE 18
OF POOR QUALITYFILE 5
LIST OF ARRAY 6

ALL VALUES * 1E-15 AMP'S

	COL 1	COL 2	COL 3	COL 4
ROW 1	8.00000E+00	2.30000E+01	3.60000E+01	5.30000E+01
ROW 2	4.96000E+02	5.11000E+02	5.26000E+02	5.42000E+02
ROW 3	9.92000E+02	1.02000E+03	1.05000E+03	1.08000E+03
ROW 4	1.96000E+03	2.04000E+03	2.11000E+03	2.17000E+03
ROW 5	3.97000E+03	4.09000E+03	4.21000E+03	4.33000E+03
ROW 6	7.93000E+03	8.18000E+03	8.42000E+03	8.67000E+03
ROW 7	1.59000E+04	1.64000E+04	1.68000E+04	1.73000E+04
ROW 8	3.17000E+04	3.27000E+04	3.37000E+04	3.47000E+04
ROW 9	6.35000E+04	6.54000E+04	6.74000E+04	6.93000E+04
ROW 10	1.27000E+05	1.31000E+05	1.35000E+05	1.39000E+05
ROW 11	2.54000E+05	2.62000E+05	2.70000E+05	2.78000E+05
ROW 12	5.08000E+05	5.23000E+05	5.39000E+05	5.55000E+05
ROW 13	1.02000E+06	1.05000E+06	1.08000E+06	1.11000E+06
ROW 14	2.03000E+06	2.09000E+06	2.16000E+06	2.22000E+06

	COL 5	COL 6	COL 7	COL 8
ROW 1	6.90000E+01	8.40000E+01	9.90000E+01	1.14000E+02
ROW 2	5.57000E+02	5.72000E+02	5.87000E+02	6.03000E+02
ROW 3	1.11000E+03	1.14000E+03	1.17000E+03	1.21000E+03
ROW 4	2.23000E+03	2.29000E+03	2.35000E+03	2.41000E+03
ROW 5	4.46000E+03	4.58000E+03	4.70000E+03	4.82000E+03
ROW 6	8.91000E+03	9.16000E+03	9.40000E+03	9.64000E+03
ROW 7	1.78000E+04	1.83000E+04	1.88000E+04	1.93000E+04
ROW 8	3.56000E+04	3.66000E+04	3.76000E+04	3.86000E+04
ROW 9	7.13000E+04	7.32000E+04	7.52000E+04	7.71000E+04
ROW 10	1.43000E+05	1.46000E+05	1.50000E+05	1.54000E+05
ROW 11	2.85000E+05	2.93000E+05	3.01000E+05	3.09000E+05
ROW 12	5.70000E+05	5.86000E+05	6.02000E+05	6.17000E+05
ROW 13	1.14000E+06	1.17000E+06	1.20000E+06	1.23000E+06
ROW 14	2.28000E+06	2.34000E+06	2.41000E+06	2.47000E+06

	COL 9	COL 10	COL 11	COL 12
ROW 1	1.30000E+02	1.45000E+02	1.60000E+02	1.75000E+02
ROW 2	6.18000E+02	6.33000E+02	6.48000E+02	6.64000E+02
ROW 3	1.24000E+03	1.27000E+03	1.30000E+03	1.33000E+03
ROW 4	2.47000E+03	2.53000E+03	2.59000E+03	2.66000E+03
ROW 5	4.94000E+03	5.07000E+03	5.19000E+03	5.31000E+03
ROW 6	9.89000E+03	1.01000E+04	1.04000E+04	1.06000E+04
ROW 7	1.98000E+04	2.03000E+04	2.08000E+04	2.12000E+04
ROW 8	3.96000E+04	4.05000E+04	4.15000E+04	4.25000E+04
ROW 9	7.91000E+04	8.11000E+04	8.30000E+04	8.50000E+04
ROW 10	1.58000E+05	1.62000E+05	1.66000E+05	1.70000E+05
ROW 11	3.16000E+05	3.24000E+05	3.32000E+05	3.40000E+05
ROW 12	6.33000E+05	6.48000E+05	6.64000E+05	6.80000E+05
ROW 13	1.27000E+06	1.30000E+06	1.33000E+06	1.36000E+06
ROW 14	2.53000E+06	2.59000E+06	2.66000E+06	2.72000E+06

ORIGINAL PAGE IS
OF POOR QUALITY

FILE 5
LIST OF ARRAY 6

ALL VALUES * 1E-15 AMP

	COL 13	COL 14	COL 15	COL 16
ROW 1	1.91000E+02	2.06000E+02	2.21000E+02	2.37000E+02
ROW 2	6.79000E+02	6.94000E+02	7.10000E+02	7.25000E+02
ROW 3	1.36000E+03	1.39000E+03	1.42000E+03	1.45000E+03
ROW 4	2.72000E+03	2.78000E+03	2.84000E+03	2.90000E+03
ROW 5	5.43000E+03	5.55000E+03	5.68000E+03	5.80000E+03
ROW 6	1.09000E+04	1.11000E+04	1.14000E+04	1.16000E+04
ROW 7	2.17000E+04	2.22000E+04	2.27000E+04	2.32000E+04
ROW 8	4.35000E+04	4.44000E+04	4.54000E+04	4.64000E+04
ROW 9	8.69000E+04	8.89000E+04	9.08000E+04	9.28000E+04
ROW 10	1.74000E+05	1.78000E+05	1.82000E+05	1.86000E+05
ROW 11	3.46000E+05	3.55000E+05	3.63000E+05	3.71000E+05
ROW 12	6.95000E+05	7.11000E+05	7.27000E+05	7.42000E+05
ROW 13	1.39000E+06	1.42000E+06	1.45000E+06	1.48000E+06
ROW 14	2.78000E+06	2.84000E+06	2.91000E+06	2.97000E+06

	COL 17	COL 18	COL 19	COL 20
ROW 1	2.52000E+02	2.67000E+02	2.82000E+02	2.98000E+02
ROW 2	7.40000E+02	7.55000E+02	7.71000E+02	7.86000E+02
ROW 3	1.48000E+03	1.51000E+03	1.54000E+03	1.57000E+03
ROW 4	2.96000E+03	3.02000E+03	3.08000E+03	3.14000E+03
ROW 5	5.92000E+03	6.04000E+03	6.16000E+03	6.29000E+03
ROW 6	1.18000E+04	1.21000E+04	1.23000E+04	1.26000E+04
ROW 7	2.37000E+04	2.42000E+04	2.47000E+04	2.51000E+04
ROW 8	4.74000E+04	4.82000E+04	4.93000E+04	5.03000E+04
ROW 9	9.47000E+04	9.67000E+04	9.86000E+04	1.01000E+05
ROW 10	1.89000E+05	1.93000E+05	1.97000E+05	2.01000E+05
ROW 11	3.79000E+05	3.87000E+05	3.95000E+05	4.02000E+05
ROW 12	7.58000E+05	7.73000E+05	7.89000E+05	8.05000E+05
ROW 13	1.52000E+06	1.55000E+06	1.58000E+06	1.61000E+06
ROW 14	3.03000E+06	3.09000E+06	3.16000E+06	3.22000E+06

	COL 21	COL 22	COL 23	COL 24
ROW 1	3.13000E+02	3.28000E+02	3.43000E+02	3.59000E+02
ROW 2	8.01000E+02	8.16000E+02	8.32000E+02	8.47000E+02
ROW 3	1.60000E+03	1.63000E+03	1.66000E+03	1.69000E+03
ROW 4	3.20000E+03	3.27000E+03	3.33000E+03	3.39000E+03
ROW 5	6.41000E+03	6.53000E+03	6.65000E+03	6.77000E+03
ROW 6	1.28000E+04	1.31000E+04	1.33000E+04	1.35000E+04
ROW 7	2.56000E+04	2.61000E+04	2.66000E+04	2.71000E+04
ROW 8	5.13000E+04	5.22000E+04	5.32000E+04	5.42000E+04
ROW 9	1.03000E+05	1.04000E+05	1.06000E+05	1.08000E+05
ROW 10	2.05000E+05	2.09000E+05	2.13000E+05	2.17000E+05
ROW 11	4.10000E+05	4.18000E+05	4.26000E+05	4.34000E+05
ROW 12	8.20000E+05	8.36000E+05	8.52000E+05	8.67000E+05
ROW 13	1.64000E+06	1.67000E+06	1.70000E+06	1.73000E+06
ROW 14	3.28000E+06	3.34000E+06	3.41000E+06	3.47000E+06

FILE 5
LIST OF ARRAY 5

ALL VALUES * 1E-15 AMPS

	COL 25	COL 26	COL 27	COL 28
ROW 1	3.74000E+02	3.89000E+02	4.04000E+02	4.20000E+02
ROW 2	8.62000E+02	8.77000E+02	8.93000E+02	9.08000E+02
ROW 3	1.72000E+03	1.75000E+03	1.79000E+03	1.82000E+03
ROW 4	3.45000E+03	3.51000E+03	3.57000E+03	3.63000E+03
ROW 5	6.90000E+03	7.02000E+03	7.14000E+03	7.26000E+03
ROW 6	1.38000E+04	1.40000E+04	1.43000E+04	1.45000E+04
ROW 7	2.76000E+04	2.81000E+04	2.86000E+04	2.91000E+04
ROW 8	5.52000E+04	5.62000E+04	5.71000E+04	5.81000E+04
ROW 9	1.10000E+05	1.12000E+05	1.14000E+05	1.16000E+05
ROW 10	2.21000E+05	2.25000E+05	2.29000E+05	2.32000E+05
ROW 11	4.41000E+05	4.49000E+05	4.57000E+05	4.65000E+05
ROW 12	8.83000E+05	8.98000E+05	9.14000E+05	9.30000E+05
ROW 13	1.77000E+06	1.80000E+06	1.83000E+06	1.86000E+06
ROW 14	3.53000E+06	3.59000E+06	3.66000E+06	3.72000E+06

	COL 29	COL 30	COL 31	COL 32
ROW 1	4.35000E+02	4.50000E+02	4.65000E+02	4.81000E+02
ROW 2	9.23000E+02	9.38000E+02	9.54000E+02	9.69000E+02
ROW 3	1.85000E+03	1.88000E+03	1.91000E+03	1.94000E+03
ROW 4	3.69000E+03	3.75000E+03	3.81000E+03	3.88000E+03
ROW 5	7.39000E+03	7.51000E+03	7.63000E+03	7.75000E+03
ROW 6	1.48000E+04	1.50000E+04	1.53000E+04	1.55000E+04
ROW 7	2.95000E+04	3.00000E+04	3.05000E+04	3.10000E+04
ROW 8	5.91000E+04	6.01000E+04	6.10000E+04	6.20000E+04
ROW 9	1.18000E+05	1.20000E+05	1.22000E+05	1.24000E+05
ROW 10	2.36000E+05	2.40000E+05	2.44000E+05	2.48000E+05
ROW 11	4.73000E+05	4.80000E+05	4.88000E+05	4.96000E+05
ROW 12	9.45000E+05	9.61000E+05	9.77000E+05	9.92000E+05
ROW 13	1.89000E+06	1.92000E+06	1.95000E+06	1.98000E+06
ROW 14	3.78000E+06	3.84000E+06	3.91000E+06	3.97000E+06



INSTRUMENTS, INC.



PRECISION
VACUUM PRESSURE / FLOW
MEASUREMENT & CONTROL

22-24 THIRD AVENUE

BURLINGTON, MASSACHUSETTS 01803

TELEPHONE 617/272-9255 TELEX 94 9375

CALIBRATION RECORD SHEET

The following data was measured on the MKS Baratron Head identified by Type and Serial Number. Calibration is performed using an MKS transfer standard that has been calibrated with a CEC Air Dead-Weight Tester which is traceable to the National Bureau of Standards.

CALIBRATION DATA

PRESSURE STD. mmHg	COMPUTED LINEAR D.C. OUTPUT	ACTUAL D.C. OUTPUT	ERROR (\pm MV)
.00000	.0000	.0000	0.0
.10521	1.0521	1.0521	0.0
.21043	2.1043	2.1052	+0.9
.31564	3.1564	3.1572	+0.8
.42086	4.2086	4.2095	+0.9
.52607	5.2607	5.2636	+2.9
.63128	6.3128	6.3157	+2.9
.73650	7.3650	7.3680	+3.0
.84171	8.4171	8.4209	+3.8
.94693	9.4693	9.4733	+4.0
1.05214	10.5214	10.5254	+5.0

Head Type 310BHS-1

Data By: BL

Ser. No. 19396-1

65503

Checked By: RE

Date: 5-13-81

Indicator Type 170M-6C

Sys. Ck. : 9.67

Ser. No. 19396-3

- NOTES:
1. Temperature regulated units must be operated on regulated heat approximately 2 hours before check or resetting calibration.
 2. Bakeable Heads are calibrated at 25°C and Temp. Comp. pot set at 500.
 3. MKS DIGITAL READOUTS READ DIRECTLY IN PRESSURE.

ORIGINAL PAGE IS
OF POOR QUALITY



INSTRUMENTS, INC.



PRECISION
VACUUM PRESSURE FLOW
MEASUREMENT & CONTROL

22-24 THIRD AVENUE

BURLINGTON, MASSACHUSETTS 01803

TELEPHONE 617/272-9255 TELEX 94-9375

CALIBRATION RECORD SHEET

The following data was measured on the MKS Baratron Head identified by Type and Serial Number. Calibration is performed using an MKS transfer standard that has been calibrated with a CEC Air Dead-Weight Tester which is traceable to the National Bureau of Standards.

CALIBRATION DATA

PRESSURE STD. mmHg	COMPUTED LINEAR D.C. OUTPUT	ACTUAL D.C. OUTPUT	ERROR (\pm MV)
.000	.0000	.0000	0.0
10.082	1.0082	1.0082	0.0
20.164	2.0164	2.0164	0.0
30.246	3.0246	3.0246	0.0
40.328	4.0328	4.0328	0.0
50.410	5.0410	5.0401	-0.9
60.491	6.0491	6.0473	-1.8
70.573	7.0573	7.0573	0.0
80.138	8.0138	8.0110	-2.8
90.479	9.0479	9.0551	-2.8
100.819	10.0819	10.0819	0.0

Head Type 310BHS-100

Data By: BL

Ser. No. 19396-2 65504

Checked By: EL

Date: 5-5-81

Indicator Type 170KH-6C

Sys. Ck.: 7.8

Ser. No. 19396-3

- NOTES: 1. Temperature regulated units must be operated on regulated heat approximately 2 hours before check or resetting calibration.
2. Bakeable Heads are calibrated at 25°C and Temp. Comp. pot set at 500.
3. MKS DIGITAL READOUTS READ DIRECTLY IN PRESSURE.

ORIGINAL PAGE IS
OF POOR QUALITY

2-19-82

**ORIGINAL PAGE IS
OF POOR QUALITY**

2-19-82

**ORIGINAL PAGE IS
OF POOR QUALITY**


2-19-82

ORIGINAL PAGE IS
OF POOR QUALITY

2-19-82


[illegible]

W A T GAUGE CALIBRATION
0 TO 50 TORR




ORIGINAL PAGE IS
OF POOR QUALITY


W & T GAUGE CALIBRATION
0 TO 200 TORR




ORIGINAL PAGE IS
OF POOR QUALITY




ORIGINAL PAGE IS
OF POOR QUALITY




ORIGINAL PAGE IS
OF POOR QUALITY




ORIGINAL PAGE 19
OF POOR QUALITY



ORIGINAL PAGE 19
OF POOR QUALITY



ORIGINAL PAGE IS
OF POOR QUALITY



ORIGINAL PAGE IS
OF POOR QUALITY



1072

Low Pressure No.

NITROGEN OIL LUBRICATION SERIES STARTED 1 / 28 / 62 1000 HRS
5/8 5 75 BY SCOR 61 PLANTS ONLY

FILAMENT 02



FILAMENT 01





ORIGINAL PAGE IS
OF POOR QUALITY

4-10-64
Page 1

Look in



ORIGINAL PAGE IS
OF POOR QUALITY





302
Haw River, N.C.

NITROGEN CALIBRATION SERIES STARTED 1 / 21 / 62 1530 HRS
SON 1 75 EV SCAN #1 PLOTS ONLY

FILAMENT #2



FILAMENT #1



ORIGINAL PAGE IS
OF POOR QUALITY

1-82

Low Pressure



ORIGINAL PAGE IS
OF POOR QUALITY



2 of 2

Long Pressure O₂


DIVISION

FILAMENT #2

FILAMENT #1





ORIGINAL PAGE IS
OF POOR QUALITY



ORIGINAL PAGE IS
OF POOR QUALITY



242

Heat Pump 02




ORIGINAL PAGE IS
OF POOR QUALITY

Low Pressure M/L





ORIGINAL PAGE 14
OF POOR QUALITY



ORIGINAL PAGE IS
OF POOR QUALITY

1023

High Pressure Water



2/4/82


41

2 of 3

High Pressure Nylon


D2 / M2

FILAMENT #2



2/4/82

FILAMENT #1



ORIGINAL PAGE IS
OF POOR QUALITY



3 of 3

Hot Pressure No. 102

102 / 102

FILAMENT #2

FILAMENT #1



2/4/82
11

SUMS DYNAMIC CALIBRATION
DATA TAPE FORMAT
(200 series)

0	COMMENTS	(72 CHARACTERS)	50	TYPE I	SIZE 50
1	TIME	(SECONDS)	480	TYPE S	SIZE 240
2	INLET P. REDUCER	(VOLTS)	480	TYPE S	SIZE 240
3	BARATRON PRESS.	(TCRR)	480	TYPE S	SIZE 240
4	SUMS HSK WORD	(16 BIT DECIMAL)	480	TYPE S	SIZE 240
5	UAMS HSK WORDS	(8 BIT DECIMAL)	2880	TYPE I	SIZE 240,12
6	AMU 28 (6 SAMPLES)	(9 BIT DECIMAL)	1440	TYPE I	SIZE 240,6
7	AMU 14 (6 SAMPLES)	(9 BIT DECIMAL)	1440	TYPE I	SIZE 240,6
8	AMU 28 (2ND HIGHEST)	(9 BIT DECIMAL)	240	TYPE I	SIZE 240
9	AMU 14 (2ND HIGHEST)	(9 BIT DECIMAL)	240	TYPE I	SIZE 240

ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

DATA COLLECTION TIMING OFFSETS FOR DYNAMIC CALIBRATION

3-23-82

General:

During the SUMS Dynamic Calibration various data is read and stored on tape once every five seconds. One of the values stored is the reading of the HP85 real time clock. This clock is initially set to zero at the beginning of each calibration run. Since the HP85 is a serial machine, timing offsets arise between the time the clock is read, and the time other data is collected. This paper describes these offsets.

Definitions:

Let T_n be the value read from the clock for a given five second group of data. (The "Nth" group)

Note that the clock has an accuracy of ± 1 msec (for the duration of each run) and a resolution of 1 msec. However, due to data tape space restrictions, T_n , as recorded, is rounded off to the nearest 0.1 seconds.

Offset Values:

- 1) Clock Read = T_n (to 0.1 sec resolution)
- 2) SUMS HSK Word = $T_{n-1} + 1.023$ seconds
- 3) SUMS Inlet Pressure Transducer = $T_n + 1.100$ seconds
- time measured to "TRIGGER" command.
- 4) Baratron Pressure = $T_n + 1.118$ seconds
- 5) Output Next Pressure = $T_n + 2.130$ seconds
- 6) Peak Data

For simplicity, assume that the time at which the 9 bit science word for a particular scan step number emerges from SUMS, is the same time as which it was sampled by the UAMS sensor. That is, ignore all delays due to buffering of data by UAMS and SUMS, and the uncertainties introduced due to the asynchronous interface with the PCM. This should introduce an error, conservatively estimated at no greater than 100 msec.

ORIGINAL PAGE IS
OF POOR QUALITY

Peak Data continued ...

Given the above, the time offset for a given scan
step number (SSN) is:

$$T_{ssn} (SSN) = -[(226-SSN) * .0135] -.022 \text{ seconds}$$

Assuming peak center scan step numbers of:

101 for AMU 28
215 for AMU 14

The offsets will be:

$$T_{ssn} (101) = -1.7095 \text{ seconds (AMU 28)}$$

$$T_{ssn} (215) = -0.1705 \text{ seconds (AMU 14)}$$

ORIGINAL PAGE IS
OF POOR QUALITY

Page 1 of 4

DATA REDUCED FOR BARATRON FROM THE FILE

2-2-63, FILE #1, TAPE 200

Time of 28 AMU Sample, Secs	Ratio of Dynamic Drop To Static Drop	Baratron Pressure at time of 28 AMU Sample, Torr	*Corrected 28 AMU Ion Current Amps	Ratio of Inlet Transducer Pressure to Baratron Pressure
3.411	1.00682	1.02882E-04	3.61000E-11	979.867
8.711	1.07943	1.68025E-04	3.70000E-11	1278.82
18.211	1.09246	1.74996E-04	3.90000E-11	920.146
23.411	1.05652	1.80948E-04	3.90000E-11	878.028
28.411	1.04762	1.87165E-04	4.00000E-11	861.785
33.411	1.04969	1.90999E-04	4.09000E-11	842.634
38.411	1.05145	1.95341E-04	4.19000E-11	823.9
43.411	1.04321	2.01588E-04	4.29000E-11	788.823
48.211	1.03224	2.08474E-04	4.39000E-11	772.016
53.311	1.02376	2.14511E-04	4.48000E-11	744.86
58.211	1.03875	2.20852E-04	4.58000E-11	728.876
63.311	1.00923	2.27312E-04	4.68000E-11	702.498
68.411	1.02229	2.34519E-04	4.87000E-11	692.65
73.411	1.02079	2.38665E-04	4.97000E-11	670.435
78.411	1.00258	2.47888E-04	5.07000E-11	648.919
83.311	0.98626	2.56902E-04	5.17000E-11	625.43
88.111	0.982745	2.62869E-04	5.27000E-11	612.569
93.411	0.982026	2.67554E-04	5.36000E-11	605.682
98.211	0.98007	2.72867E-04	5.46000E-11	585.457
103.411	0.960237	2.83835E-04	5.56000E-11	561.08
108.311	0.972111	2.89949E-04	5.75000E-11	564.186
113.211	0.978899	2.94450E-04	5.85000E-11	539.185
118.211	0.985272	3.07967E-04	6.19000E-11	516.47
123.211	1.01363	3.18211E-04	6.58000E-11	506.837
128.211	1.0205	3.25676E-04	6.78000E-11	328.2
133.211	0.992071	3.35009E-04	6.78000E-11	479.135
138.111	1.02135	3.44123E-04	7.17000E-11	466.256
143.211	0.960335	3.52839E-04	6.97000E-11	456.722
148.211	0.981931	3.67423E-04	7.36000E-11	284.628
153.111	0.964935	3.84055E-04	7.56000E-11	421.099
158.211	1.00927	3.86125E-04	7.95000E-11	423.836
163.311	1.00026	3.89602E-04	7.95000E-11	274.425
168.211	0.986526	4.04966E-04	8.15000E-11	390.164
173.211	0.98526	4.24890E-04	8.54000E-11	375.171
178.311	0.961652	4.45006E-04	8.73000E-11	355.382
183.211	0.937078	4.67138E-04	8.93000E-11	340.183
188.211	0.985801	4.84825E-04	9.75000E-11	331.065
193.111	0.928641	5.14667E-04	9.75000E-11	298.08
198.111	0.887394	5.49637E-04	9.95000E-11	294.685
203.111	0.957417	5.55518E-04	1.08500E-10	291.889
208.311	0.954244	5.67639E-04	1.10500E-10	281.556
213.211	0.949807	5.90935E-04	1.14500E-10	268.085
218.111	0.964488	6.27682E-04	1.23500E-10	248.513
223.211	0.931118	6.71236E-04	1.27500E-10	157.238
228.111	0.913222	7.05861E-04	1.31500E-10	224.245

* Corrected for background by subtracting 3.5 E-12 Amps

233.211	0.898299	7.61242E-04	1.39500E-10	134.779
238.111	0.8952707	8.15190E-04	1.42500E-10	134.639
243.111	0.890825	8.50170E-04	1.54500E-10	138.127
248.111	0.900737	8.84352E-04	1.62500E-10	179.156
253.211	0.894836	9.34000E-04	1.70500E-10	168.84
258.111	0.889272	1.00600E-03	1.82500E-10	153.126
263.011	0.870034	1.09022E-03	1.93500E-10	144.637
268.011	0.86065	1.16639E-03	2.05500E-10	133.57
273.011	0.860306	1.26209E-03	2.21500E-10	82.3734
278.011	0.840329	1.35626E-03	2.32500E-10	115.867
283.011	0.866562	1.46228E-03	2.58500E-10	70.6394
288.111	0.837217	1.60136E-03	2.73500E-10	96.8057
293.011	0.895304	1.74608E-03	2.97500E-10	88.7974
298.011	0.835093	1.88132E-03	3.20500E-10	83.8733
303.111	0.853036	2.01989E-03	3.51500E-10	76.8922
308.211	0.83078	2.21561E-03	3.75500E-10	69.6288
313.211	0.820089	2.42981E-03	4.06500E-10	63.886
318.211	0.791303	2.71022E-03	4.37500E-10	55.654
323.111	0.778875	2.99892E-03	4.76500E-10	52.5984
328.111	0.815549	3.21869E-03	5.35500E-10	48.1868
333.111	0.815283	3.50233E-03	5.82500E-10	44.4628
338.111	0.801541	3.84981E-03	6.29500E-10	39.7333
343.011	0.790576	4.28764E-03	6.91500E-10	35.787
348.011	0.779579	4.74426E-03	7.54500E-10	32.5734
353.011	0.761998	5.35550E-03	8.32500E-10	27.9123
358.011	0.764126	6.03983E-03	9.41500E-10	25.8182
363.011	0.795992	6.62941E-03	1.07650E-09	23.0762
368.011	0.8939665	7.43381E-03	1.42500E-10	20.522
373.111	0.8110205	8.31778E-03	1.87000E-11	18.5035
378.011	3.97761E-03	9.11967E-03	7.40000E-12	17.145
383.011	1.70246E-03	0.0112006	3.89000E-12	18.2152
388.111	8.63274	0.0123852	3.40000E-12	12.5848
393.111	6.88854	0.0138321	3.03000E-12	10.8345
398.111	5.0406	0.0165948	2.66000E-12	8.6997
403.111	4.10607	0.0194527	2.54000E-12	7.977
408.111	3.40597	0.0223433	2.42000E-12	8.70052
413.111	2.81686	0.0256764	2.30000E-12	6.12186
418.111	2.41086	0.0284352	2.18000E-12	5.27038
423.111	2.11866	0.0323569	2.18000E-12	6.31462
428.011	1.82541	0.0375549	2.18000E-12	5.18878
433.011	1.50293	0.042893	2.05000E-12	3.6879
438.111	1.50563	0.0455314	2.18000E-12	4.58108
443.011	1.35519	0.0505858	2.18000E-12	3.94189
448.011	1.24237	0.0582169	2.30000E-12	3.49062
453.011	1.13233	0.0672069	2.42000E-12	2.92235
458.011	1.04125	0.0767097	2.54000E-12	2.71991
463.011	1.04615	0.0838652	2.79000E-12	3.05052
468.011	1.02545	0.092918	3.03000E-12	2.22334
473.211	1.03746	0.106694	3.52000E-12	1.96919
478.011	0.813047	0.145427	3.76000E-12	1.3828
483.011	0.672049	0.198866	4.25000E-12	1.34335
488.011	0.849991	0.20015	5.41000E-12	1.37817
493.011	0.920151	0.209837	6.14000E-12	1.42838
498.011	0.938106	0.231297	6.90000E-12	1.38494
503.011	1.02053	0.24343	7.90000E-12	1.28133
508.011	0.971992	0.268527	8.30000E-12	1.32095
513.011	0.929114	0.307996	9.10000E-12	1.13739
518.011	0.870898	0.372256	1.03000E-11	1.02955
523.011	0.849943	0.436581	1.18000E-11	1.07177
528.011	0.896957	0.483816	1.38000E-11	1.03756
533.011	0.890335	0.558054	1.58000E-11	0.980321
538.011	0.908422	0.630023	1.82000E-11	1.07177
543.011	0.928412	0.701136	2.07000E-11	1.00205
548.011	0.900595	0.806594	2.31000E-11	0.993237

ORIGINAL PAGE IS
OF POOR QUALITY

568.811	0.909422	0.885212	2.50000E-11	1.09002
567.811	0.967179	0.949399	2.92000E-11	1.00706
572.811	0.850643	1.1534	3.12000E-11	0.897941
577.811	0.860427	1.35226	3.70000E-11	0.982891
582.811	0.92482	1.42472	4.19000E-11	1.02581
588.811	0.929596	1.54933	4.50000E-11	1.03187
592.811	0.909732	1.71797	4.97000E-11	1.00309
597.811	0.872414	1.96808	5.46000E-11	0.959044
602.811	0.94475	2.25076	6.78000E-11	0.972675
607.811	0.930969	2.48608	7.36000E-11	1.00265
612.811	0.860959	2.72919	8.34000E-11	0.991241
617.711	0.941819	2.98165	8.93000E-11	1.0195
622.711	0.949972	3.2275	9.75000E-11	1.00244
627.811	0.955505	3.50501	1.06500E-10	1.01998
632.811	0.946391	3.73813	1.12500E-10	1.01797
637.711	0.975188	3.98246	1.23500E-10	1.00589
642.711	0.982433	4.20916	1.31500E-10	1.01159
647.711	0.986525	4.44671	1.39500E-10	1.0209
652.811	0.965534	4.64109	1.42500E-10	1.0239
657.911	0.981284	4.82297	1.50500E-10	1.02031
662.811	0.997216	4.99819	1.58500E-10	1.03057
667.911	0.995686	5.1322	1.62500E-10	1.01954
672.811	0.996497	5.25425	1.66500E-10	1.02583
677.711	1.00141	5.35406	1.70500E-10	1.01986
682.711	1.02786	5.46102	1.78500E-10	1.02841
687.811	0.992379	5.52956	1.74500E-10	1.0336
692.711	1.04066	5.6054	1.85500E-10	1.01939
697.811	1.00961	5.68435	1.82500E-10	1.02477
702.711	1.03608	5.75157	1.89500E-10	1.03325
707.811	1.01903	5.8478	1.89500E-10	1.01741
712.711	1.00259	5.94371	1.89500E-10	1.02971
717.711	1.01312	6.00607	1.93500E-10	1.03069
722.711	1.02016	6.08791	1.97500E-10	1.02999
727.811	1.00556	6.17634	1.97500E-10	1.02617
732.811	1.01114	6.26661	2.01500E-10	1.02822
737.811	1.00003	6.33627	2.01500E-10	1.01899
742.811	1.02265	6.44209	2.09500E-10	1.02846
747.811	1.00754	6.53809	2.09500E-10	1.02251
752.811	1.01327	6.62591	2.13500E-10	1.02602
757.811	1.00141	6.70437	2.13500E-10	1.02319
762.811	1.004	6.81234	2.17500E-10	1.02331
767.811	1.00631	6.9217	2.21500E-10	1.03291
772.711	1.01406	6.99286	2.25500E-10	1.02361
777.611	0.99855	7.10149	2.25500E-10	1.02484
782.711	1.01501	7.20313	2.32500E-10	1.02545
787.711	1.00231	7.29442	2.32500E-10	1.02174
792.611	1.00531	7.39776	2.36500E-10	1.02437
797.711	1.006	7.51325	2.40500E-10	1.02139
802.611	1.03738	7.5935	2.50500E-10	1.01619
807.711	1.021	7.71528	2.50500E-10	1.02373
812.811	1.03702	7.83872	2.58500E-10	1.0202
817.711	1.02541	7.92745	2.58500E-10	1.02032
822.611	1.01167	8.03516	2.58500E-10	1.01978
827.811	0.971873	8.62304	2.66500E-10	1.02436
832.811	1.00953	9.267	2.97500E-10	1.02325
837.711	1.01899	9.18098	2.97500E-10	1.03415
842.711	1.04376	8.96307	2.97500E-10	1.03948
847.811	1.06582	8.77755	2.97500E-10	1.02266
852.711	1.03419	8.80275	2.89500E-10	1.01921
857.711	0.994801	8.89846	2.81500E-10	1.01872
862.611	1.0151	8.96828	2.89500E-10	1.0233
867.611	1.01201	8.99567	2.89500E-10	1.01797
872.611	1.02438	9.04434	2.97500E-10	1.01823
877.711	0.999444	9.18883	2.89500E-10	1.01516
882.611	1.00623	9.29735	2.97500E-10	1.01203

887.611	1.00752	9.53513	3.05500E-10	1.0215
892.511	1.02151	9.52011	3.12500E-10	1.01592
897.611	1.00967	9.73288	3.12500E-10	1.015
902.611	1.02329	9.05885	3.20500E-10	1.01134
907.711	1.00807	9.9979	3.20500E-10	1.01447
912.711	1.01944	10.1321	3.28500E-10	1.01593
917.611	1.00189	10.3107	3.28500E-10	1.01457
922.511	1.00521	10.5259	3.36500E-10	1.01092
927.511	1.01144	10.7107	3.44500E-10	1.01635
932.611	1.01515	10.8884	3.51500E-10	1.01261
937.511	0.999273	11.0615	3.51500E-10	1.01415
942.611	1.00791	11.2162	3.59500E-10	1.01413
947.511	1.0161	11.3734	3.67500E-10	1.01411
952.611	1.00144	11.5399	3.67500E-10	1.00907
957.511	1.00911	11.7015	3.75500E-10	1.0133
962.611	0.994247	11.8765	3.75500E-10	1.01185
967.511	1.00196	12.0361	3.83500E-10	1.01337
972.611	0.987346	12.2143	3.83500E-10	1.01316
977.511	0.993192	12.3957	3.91500E-10	1.0147
982.611	0.997456	12.5634	3.98500E-10	1.01203
987.511	1.00399	12.7321	4.06500E-10	1.01346
992.511	0.991108	12.8977	4.06500E-10	1.01514
997.511	0.996924	13.0748	4.14500E-10	1.01145
1002.51	1.00213	13.2579	4.22500E-10	1.01497
1007.51	0.987194	13.4585	4.22500E-10	1.0142
1012.51	0.991833	13.6492	4.30500E-10	1.01393
1017.51	0.992953	13.8555	4.37500E-10	1.01181
1022.41	0.990462	14.031	4.45500E-10	1.01189
1027.51	0.984084	14.236	4.45500E-10	1.01277
1032.61	0.986100	14.4619	4.53500E-10	1.01477
1037.61	0.990849	14.6466	4.61500E-10	1.01289
1042.61	0.994855	14.8405	4.69500E-10	1.01374
1047.51	0.980752	15.0539	4.69500E-10	1.01231
1052.51	0.981847	15.2613	4.76500E-10	1.01231
1057.61	0.98403	15.4831	4.84500E-10	1.01387
1062.61	0.985731	15.7116	4.92500E-10	1.01177
1067.61	0.97361	15.9072	4.92500E-10	1.01149
1072.51	1.01194	16.1436	5.19500E-10	1.01298
1077.51	0.998641	16.3587	5.19500E-10	1.01123
1082.51	0.984202	16.5987	5.19500E-10	1.00996
1087.41	1.00113	16.8206	5.35500E-10	1.0104
1092.41	0.986966	17.062	5.35500E-10	1.01279
1097.51	0.971989	17.3249	5.35500E-10	1.0119
1102.41	0.968287	17.5483	5.51500E-10	1.0112
1107.51	0.975046	17.7866	5.51500E-10	1.01276
1112.41	0.987547	18.0391	5.66500E-10	1.01195
1117.41	0.974165	18.2869	5.66500E-10	1.0103
1122.51	0.960809	18.5411	5.66500E-10	1.01266
1127.41	0.973243	18.8212	5.82500E-10	1.01226
1132.31	0.961771	19.0457	5.82500E-10	1.01157
1137.41	0.974557	19.3121	5.98500E-10	1.01247
1142.41	0.959718	19.6107	5.98500E-10	1.01095
1147.31	0.970665	19.8755	6.13500E-10	1.01045
1152.41	0.957727	20.144	6.13500E-10	1.01088
1157.41	0.968089	20.4481	6.29500E-10	1.01204
1162.41	0.955215	20.7237	6.29500E-10	1.01067
1167.51	0.964457	21.0142	6.44500E-10	1.00951
1172.41	0.950672	21.3189	6.44500E-10	1.0099

ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

Page 1 of 4

CHARGES: 10/20/82 CAL TEL: 601-491-1000 (HOL) (HOL) (HOL)

2-20-82 RUN #2 TAPE 001

Time of 28 AMU Sample, Secs	Ratio of Dynamic Drop To Static Drop	Baratron Pressure at time of 18 AMU Sample, Torr	*Corrected 28 AMU Ion Current Amps	Ratio of Inlet Transducer Pressure to Baratron Pressure
3.011	1.13836	1.51145E-04	3.51000E-11	1403.48
8.211	1.1048	1.55737E-04	3.51000E-11	1386.47
13.211	1.10964	1.59562E-04	3.61000E-11	1330.47
18.011	1.09493	1.65647E-04	3.70000E-11	1285.62
23.111	1.05698	1.71594E-04	3.70000E-11	1242.99
27.911	1.05434	1.76674E-04	3.80000E-11	1211.8
33.211	1.05713	1.80844E-04	3.90000E-11	1190.58
38.211	1.05566	1.85739E-04	4.00000E-11	1143.6
43.011	1.04748	1.91401E-04	4.09000E-11	1124.08
48.011	1.01945	1.96665E-04	4.09000E-11	1080.51
53.211	1.02807	2.04551E-04	4.29000E-11	1041.18
58.011	1.02061	2.10850E-04	4.39000E-11	1015.88
63.111	1.01297	2.16795E-04	4.48000E-11	1232.41
68.011	1.00851	2.22615E-04	4.58000E-11	963.225
73.111	0.996138	2.30301E-04	4.68000E-11	1149.52
78.111	0.999746	2.38786E-04	4.87000E-11	897.975
83.111	1.00198	2.43146E-04	4.97000E-11	888.797
88.011	0.976063	2.49602E-04	4.97000E-11	846.243
93.111	0.976365	2.59566E-04	5.17000E-11	826.301
98.011	0.988718	2.65743E-04	5.36000E-11	806.378
103.111	0.974264	2.74717E-04	5.46000E-11	772.29
108.111	0.963905	2.82755E-04	5.56000E-11	764.146
113.111	0.973965	2.89397E-04	5.75000E-11	733.963
118.011	0.967482	2.96403E-04	5.85000E-11	732.726
122.911	1.0292	3.04346E-04	6.39000E-11	689.064
128.111	1.01482	3.17837E-04	6.58000E-11	847.1
133.011	1.02935	3.22874E-04	6.78000E-11	667.075
137.911	1.03126	3.31309E-04	6.97000E-11	801.149
142.911	1.07751	3.43930E-04	7.56000E-11	775.32
147.911	0.991286	3.54560E-04	7.17000E-11	603.553
153.111	1.0137	3.65579E-04	7.56000E-11	729.725
158.011	1.00521	3.78419E-04	7.76000E-11	701.833
162.911	0.990758	3.93341E-04	7.95000E-11	540.392
167.811	0.97901	4.08075E-04	8.15000E-11	521.968
173.111	0.965659	4.23362E-04	8.34000E-11	629.487
178.011	0.964789	4.40038E-04	8.93000E-11	480.76
182.911	0.991231	4.60904E-04	9.32000E-11	459.036
187.911	0.972804	4.79209E-04	9.51000E-11	446.405
192.911	0.971956	5.01818E-04	9.95000E-11	416.155
198.011	0.949618	5.29108E-04	1.02500E-10	404.088
203.011	0.928664	5.51604E-04	1.04500E-10	285.801
208.011	0.947934	5.81760E-04	1.12500E-10	454.887
213.011	0.930956	6.13432E-04	1.16500E-10	341.984
218.011	0.940067	6.43988E-04	1.23500E-10	331.654
222.911	0.908541	6.87916E-04	1.27500E-10	295.7

* Corrected for background by subtracting 3.5 E-12 Amps

ORIGINAL PAGE IS
OF POOR QUALITY

2 of 4

228.011	0.902762	7.35759E-04	1.35500E-10	368.974
230.011	0.92432	7.47634E-04	1.42500E-10	356.113
238.011	0.919707	7.90764E-04	1.46500E-10	337.451
243.011	0.913351	8.29202E-04	1.54500E-10	252.086
248.011	0.890512	8.94506E-04	1.62500E-10	231.497
253.011	0.865576	9.64467E-04	1.70500E-10	217.465
257.911	0.879048	1.03443E-03	1.85500E-10	200.349
262.911	0.869469	1.11348E-03	1.97500E-10	188.567
268.011	0.874786	1.19637E-03	2.13500E-10	173.364
273.011	0.860327	1.28486E-03	2.25500E-10	163.741
277.911	0.837819	1.40713E-03	2.40500E-10	142.743
282.011	0.848387	1.53983E-03	2.66500E-10	138.966
287.911	0.855588	1.61281E-03	2.81500E-10	129.635
292.711	0.865145	1.73098E-03	3.05500E-10	149.814
298.011	0.851813	1.89043E-03	3.28500E-10	137.012
302.911	0.838005	2.05612E-03	3.51500E-10	100.545
307.811	0.808332	2.27714E-03	3.75500E-10	111.153
312.811	0.812702	2.50013E-03	4.14500E-10	84.3616
317.911	0.819688	2.71232E-03	4.53500E-10	93.9758
322.911	0.812943	2.96972E-03	4.92500E-10	70.6279
327.811	0.830572	3.25490E-03	5.51500E-10	77.3598
332.911	0.811104	3.61707E-03	5.98500E-10	57.8914
337.911	0.805686	3.92127E-03	6.44500E-10	65.4534
342.911	0.795741	4.35837E-03	7.07500E-10	58.4999
347.811	0.797546	4.82792E-03	7.85500E-10	53.3438
352.711	0.777778	5.44222E-03	8.63500E-10	45.6745
357.811	0.781965	6.10265E-03	9.73500E-10	43.0979
362.711	0.823466	6.58681E-03	1.10650E-09	31.069
367.711	0.805813	7.46110E-03	1.22650E-09	33.5274
372.911	0.8970646	8.28658E-03	1.62500E-10	32.6834
377.811	0.810759	9.43115E-03	2.07000E-11	19.7098
382.711	3.45991E-03	0.0111926	7.90000E-12	19.0201
387.711	2.30649E-03	0.0114978	5.41000E-12	18.7542
392.811	11.2468	0.0118831	4.25000E-12	22.1492
397.711	8.78475	0.01303	3.64000E-12	19.2184
402.811	6.23398	0.0164951	3.27000E-12	13.8527
407.711	4.61933	0.0198101	2.91000E-12	10.8202
412.711	4.13791	0.0212029	2.79000E-12	11.9471
417.811	3.42388	0.0244307	2.66000E-12	10.1916
422.911	2.76443	0.0288935	2.54000E-12	8.53244
427.811	2.34406	0.0324652	2.42000E-12	8.14499
432.811	2.12146	0.0358718	2.42000E-12	6.90509
437.811	1.84454	0.0412571	2.42000E-12	6.19034
442.711	1.52088	0.0475559	2.30000E-12	5.13802
447.711	1.40898	0.054011	2.42000E-12	4.8904
452.811	1.33593	0.0597886	2.54000E-12	4.1562
457.811	1.16497	0.0685628	2.54000E-12	4.46846
462.811	1.12384	0.0780673	2.79000E-12	3.19194
468.011	1.03069	0.0887845	2.91000E-12	3.49105
477.711	1.07785	0.102696	3.52000E-12	3.05708
482.711	1.05893	0.111722	3.76000E-12	2.74632
487.811	0.91674	0.133437	3.89000E-12	2.13248
492.811	0.886032	0.157227	4.43000E-12	1.99803
497.811	0.939755	0.173001	5.17000E-12	2.03884
502.811	0.871645	0.204197	5.66000E-12	1.66396
507.811	0.853777	0.235358	6.39000E-12	1.55482
512.811	0.900095	0.258533	7.40000E-12	1.56537
517.811	0.87131	0.299556	8.30000E-12	1.48302
522.811	0.85537	0.341902	9.30000E-12	1.36378
527.711	0.886629	0.383049	1.08000E-11	1.29833
532.611	0.926694	0.43775	1.29000E-11	1.16713
537.711	0.904386	0.497227	1.43000E-11	1.20987
542.611	0.920577	0.556801	1.63000E-11	1.21258
547.611	0.908271	0.630128	1.82000E-11	1.09319

ORIGINAL PAGE IS
OF POOR QUALITY

552.811	0.904419	0.719736	2.07000E-11	1.0079
557.811	0.926392	0.801166	2.36000E-11	1.12141
562.911	0.935043	0.874409	2.60000E-11	1.23931
572.611	0.936508	1.07787	3.21000E-11	1.07411
577.711	0.970612	1.19875	3.70000E-11	1.13492
582.611	0.925394	1.35927	4.00000E-11	0.997377
587.611	0.830372	1.66251	4.39000E-11	0.99757
592.811	0.873299	1.88472	5.27000E-11	1.07249
597.611	0.923	1.99309	5.85000E-11	1.06203
602.511	0.959145	2.22289	6.78000E-11	0.993476
607.511	0.922656	2.50848	7.36000E-11	1.02574
612.611	0.951483	2.75637	8.34000E-11	1.03138
617.611	0.953666	3.00726	9.12000E-11	1.04962
622.511	0.963245	3.24832	9.95000E-11	1.02935
627.511	0.990748	3.50729	1.10500E-10	1.03237
632.611	1.0447	3.71745	1.23500E-10	1.05514
637.511	1.00815	3.85224	1.23500E-10	1.03614
642.611	1.00674	4.1075	1.31500E-10	1.0315
647.611	1.00568	4.362	1.39500E-10	1.02827
652.511	0.980916	4.56831	1.42500E-10	1.0455
657.511	0.99547	4.75424	1.50500E-10	1.04017
662.511	0.985965	4.92765	1.54500E-10	1.03882
667.711	1.00425	5.08843	1.62500E-10	1.04036
672.611	1.00441	5.21285	1.66500E-10	1.0411
677.511	1.03345	5.30977	1.74500E-10	1.04363
682.511	1.01596	5.40121	1.74500E-10	1.03658
687.511	1.04523	5.49065	1.82500E-10	1.04913
692.611	1.02908	5.57681	1.82500E-10	1.04416
697.611	1.03387	5.64222	1.85500E-10	1.05422
702.611	1.02008	5.71846	1.85500E-10	1.03355
707.711	1.02522	5.81252	1.89500E-10	1.04987
712.511	1.03459	5.88146	1.93500E-10	1.04482
717.411	1.01938	5.96922	1.93500E-10	1.03716
722.411	1.02423	6.06372	1.97500E-10	1.03977
727.511	1.03099	6.14597	2.01500E-10	1.04551
732.511	1.01821	6.22314	2.01500E-10	1.03942
737.611	1.02353	6.31368	2.05500E-10	1.04166
742.611	1.02949	6.39932	2.09500E-10	1.04546
747.611	1.03499	6.48682	2.13500E-10	1.0383
752.611	1.03821	6.5784	2.17500E-10	1.03796
757.611	1.02188	6.68315	2.17500E-10	1.03821
762.511	1.00952	6.77506	2.17500E-10	1.04594
767.511	1.01714	6.84803	2.21500E-10	1.039
772.411	1.0207	6.94732	2.25500E-10	1.03904
777.511	1.01826	7.05667	2.28500E-10	1.0382
782.411	1.00256	7.16718	2.28500E-10	1.03643
787.411	1.02057	7.2872	2.36500E-10	1.03418
792.411	1.02446	7.38232	2.40500E-10	1.04056
797.511	1.05551	7.46302	2.50500E-10	1.03292
802.611	0.998595	7.57353	2.40500E-10	1.03878
807.511	1.02537	7.68244	2.50500E-10	1.03843
812.411	1.01084	7.79283	2.50500E-10	1.03016
817.511	1.02305	7.90713	2.58500E-10	1.03675
822.311	1.01419	8.01519	2.58500E-10	1.03495
827.511	1.0173	8.23792	2.66500E-10	1.03812
832.511	1.02765	8.36914	2.73500E-10	1.04292
837.511	1.03340	8.32199	2.73500E-10	1.0322
842.411	1.02204	8.41511	2.73500E-10	1.03212
847.511	1.03829	8.52573	2.81500E-10	1.03776
852.411	1.02845	8.6073	2.81500E-10	1.03235
857.311	1.02233	8.65881	2.81500E-10	1.03136
862.311	1.01451	8.72555	2.81500E-10	1.02898
867.411	1.00423	8.81487	2.81500E-10	1.02859
872.511	1.01873	8.93634	2.89500E-10	1.03093
877.511	1.032	9.06523	2.97500E-10	1.02928

882.411	1.01863	9.18421	2.97500E-10	1.03344
887.411	1.0311	9.31711	3.05500E-10	1.02896
892.511	1.0152	9.46306	3.05500E-10	1.03073
897.511	1.02328	9.60344	3.13500E-10	1.02684
902.511	1.00755	9.75339	3.13500E-10	1.02661
907.411	1.0178	9.90231	3.20500E-10	1.02351
912.311	1.00296	10.0488	3.20500E-10	1.0286
917.511	1.01057	10.2221	3.28500E-10	1.02696
922.411	1.01896	10.3858	3.36500E-10	1.02664
927.411	1.00247	10.5556	3.36500E-10	1.02498
932.411	1.01018	10.7241	3.44500E-10	1.02509
937.411	1.01613	10.8779	3.51500E-10	1.03108
942.311	1.00155	11.0363	3.51500E-10	1.02436
947.311	1.00759	11.2138	3.59500E-10	1.02194
952.411	1.01444	11.392	3.67500E-10	1.02288
957.311	1.00126	11.542	3.67500E-10	1.02282
962.311	0.986849	11.7106	3.67500E-10	1.02139
967.311	0.993678	11.8833	3.75500E-10	1.02067
972.411	1.00036	12.0553	3.83500E-10	1.02403
977.311	1.00721	12.2231	3.91500E-10	1.02314
982.411	0.99388	12.3971	3.91500E-10	1.02227
987.411	0.987456	12.5634	3.98500E-10	1.02174
992.411	1.0041	12.7307	4.06500E-10	1.02523
997.311	1.01058	12.8981	4.14500E-10	1.02436
1002.21	0.997252	13.0705	4.14500E-10	1.02305
1007.21	1.00248	13.2532	4.22500E-10	1.02094
1012.31	1.00644	13.451	4.30500E-10	1.02138
1017.41	0.99023	13.6713	4.30500E-10	1.02346
1022.31	0.991186	13.8802	4.37500E-10	1.02195
1027.31	0.985737	14.0694	4.45500E-10	1.02308
1032.21	0.99993	14.262	4.53500E-10	1.02076
1037.31	0.986136	14.4615	4.53500E-10	1.02174
1042.41	0.989734	14.6631	4.61500E-10	1.02228
1047.31	0.993329	14.8633	4.69500E-10	1.0228
1052.31	0.979626	15.0712	4.69500E-10	1.01966
1057.31	0.980774	15.278	4.76500E-10	1.02001
1062.21	1.02465	15.4831	5.04500E-10	1.02041
1067.31	0.985537	15.7147	4.92500E-10	1.01784
1072.31	0.970347	15.9607	4.92500E-10	1.01935
1077.31	1.00892	16.1919	5.19500E-10	1.01924
1082.31	0.995174	16.4157	5.19500E-10	1.02113
1087.31	0.98134	16.6471	5.19500E-10	1.02039
1092.31	0.998075	16.8721	5.35500E-10	1.01968
1097.31	0.98494	17.0971	5.35500E-10	1.01898
1102.31	1.00111	17.3234	5.51500E-10	1.02124
1107.31	0.98623	17.5849	5.51500E-10	1.01883
1112.31	0.997227	17.864	5.66500E-10	1.01738
1117.21	0.984191	18.1006	5.66500E-10	1.01889
1122.31	0.970884	18.3487	5.66500E-10	1.02003
1127.31	0.985421	18.5886	5.82500E-10	1.02158
1132.31	0.972943	18.827	5.82500E-10	1.02017
1137.21	0.985225	19.103	5.98500E-10	1.01643
1142.21	0.969637	19.4101	5.98500E-10	1.01702
1147.31	0.980706	19.672	6.13500E-10	1.01998
1152.31	0.967991	19.9304	6.13500E-10	1.01765
1157.21	0.979204	20.216	6.29500E-10	1.01708
1162.11	0.964547	20.5232	6.29500E-10	1.01689
1167.21	0.974286	20.8022	6.44500E-10	1.01911

ORIGINAL PAGE IS
OF POOR QUALITY

sample, 10,000,000 and 100,000,000, and 1,000,000,000.

Page 1 of 4

2-23-82 RUN #3 TAIL 201

Time of 28 AMU Sample, Secs	Ratio of Dynamic Drop To Static Drop	Baratron Pressure at time of 28 AMU Sample, Torr	*Corrected 28 AMU Ion Current Amps	Ratio of Inlet Transducer Pressure to Baratron Pressure
2.911	1.17893	1.50102E-04	3.61000E-11	2491.48
8.211	1.14033	1.35183E-04	3.61000E-11	2404.85
13.211	1.09398	1.61758E-04	3.61000E-11	2282.24
18.011	1.08442	1.67252E-04	3.70000E-11	2263.23
23.011	1.0886	1.71113E-04	3.80000E-11	2170.27
28.011	1.08642	1.75969E-04	3.90000E-11	2150.64
33.211	1.08967	1.79943E-04	4.00000E-11	2069.9
38.111	1.09056	1.83840E-04	4.09000E-11	2068.77
43.111	1.08477	1.89341E-04	4.19000E-11	1932.19
48.111	1.06757	1.96983E-04	4.29000E-11	1930.22
53.111	1.06799	2.01495E-04	4.39000E-11	1832.6
57.911	1.06866	2.10084E-04	4.50000E-11	1778.62
63.111	1.05833	2.16766E-04	4.68000E-11	1479.58
68.111	1.05372	2.2367E-04	4.78000E-11	1690.13
73.111	1.04384	2.28699E-04	4.87000E-11	1395.37
78.111	1.05103	2.36462E-04	5.07000E-11	1583.22
83.111	1.04068	2.43523E-04	5.17000E-11	1314.91
88.111	1.01097	2.50679E-04	5.17000E-11	1495.47
93.111	1.00406	2.57288E-04	5.27000E-11	1247.98
98.011	1.01669	2.63252E-04	5.46000E-11	1429.72
103.111	1.01164	2.69411E-04	5.56000E-11	1191.01
108.011	0.993123	2.79372E-04	5.66000E-11	1323.3
112.911	0.986971	2.90550E-04	5.85000E-11	1289.66
117.911	1.08583	2.97051E-04	6.58000E-11	1268.58
123.111	1.05291	3.06338E-04	6.58000E-11	1036.88
128.011	1.08413	3.15150E-04	6.97000E-11	1203.56
133.111	1.0668	3.28271E-04	6.97000E-11	1000.92
138.011	1.03475	3.30192E-04	6.97000E-11	1130.26
142.911	1.08266	3.42294E-04	7.56000E-11	1085.13
148.111	1.02172	3.53113E-04	7.36000E-11	1067.77
153.011	1.02133	3.62848E-04	7.56000E-11	875.67
157.911	1.01151	3.76060E-04	7.76000E-11	997.508
163.011	1.0152	3.93526E-04	8.15000E-11	928.832
168.011	0.994547	4.11065E-04	8.34000E-11	920.962
173.011	0.999106	4.19002E-04	8.54000E-11	890.566
177.811	1.00802	4.34259E-04	8.93000E-11	854.751
182.811	0.972571	4.59667E-04	9.12000E-11	679.516
187.811	0.964757	4.83206E-04	9.51000E-11	779.93
193.111	0.983358	5.00984E-04	1.00500E-10	630.753
197.911	0.975493	5.25124E-04	1.04500E-10	707.681
202.811	0.969021	5.48866E-04	1.08500E-10	673.005
207.811	0.971865	5.77523E-04	1.14500E-10	639.949
212.811	0.950223	6.11369E-04	1.23500E-10	599.321
218.011	0.963022	6.48998E-04	1.27500E-10	488.905

* Corrected for background by subtracting 3.5 E-12 Amps

ORIGINAL PAGE IS
OF POOR QUALITY

2 of 4

222.811	0.938168	6.87092E-04	1.31500E-10	531.057
226.011	0.938361	7.28354E-04	1.39500E-10	439.100
233.011	0.912705	7.65339E-04	1.43500E-10	410.342
233.811	0.911904	8.09016E-04	1.50500E-10	393.412
243.011	0.901204	8.62136E-04	1.58500E-10	418.859
247.811	0.905364	9.22535E-04	1.70500E-10	400.317
253.011	0.910025	9.75900E-04	1.82500E-10	319.324
257.811	0.882049	1.05314E-03	1.89500E-10	345.679
262.811	0.892040	1.12326E-03	2.05500E-10	279.123
267.811	0.877742	1.21468E-03	2.17500E-10	254.949
273.011	0.874503	1.30326E-03	2.32500E-10	285.215
278.011	0.868637	1.41364E-03	2.50500E-10	213.919
283.011	0.846900	1.54252E-03	2.66500E-10	208.011
288.011	0.86945	1.63220E-03	2.89500E-10	220.959
293.011	0.854896	1.79187E-03	3.12500E-10	172.612
297.911	0.844633	1.95293E-03	3.36500E-10	159.391
302.811	0.861181	2.09186E-03	3.67500E-10	151.048
307.811	0.836315	2.29473E-03	3.91500E-10	153.196
312.811	0.841659	2.50730E-03	4.30500E-10	128.359
318.011	0.857752	2.63742E-03	4.61500E-10	118.138
322.911	0.826251	2.92189E-03	4.92500E-10	103.274
327.811	0.823935	3.26112E-03	5.51500E-10	109.915
332.811	0.815524	3.59747E-03	5.98500E-10	86.1194
337.911	0.804824	4.02292E-03	6.60500E-10	75.204
342.911	0.794961	4.46131E-03	7.23500E-10	76.3544
347.911	0.802515	4.89576E-03	8.01500E-10	62.022
352.911	0.788816	5.46550E-03	8.79500E-10	56.6735
357.811	0.794803	6.09659E-03	9.88500E-10	49.4367
362.711	0.820254	6.79189E-03	1.13650E-09	46.0774
367.711	0.829363	7.48566E-03	1.26650E-09	40.4941
372.911	0.8629722	0.0129609	1.66500E-10	16.9993
377.911	8.08632E-03	0.013094	2.16000E-11	82.0465
382.911	0.0131984	3.19408E-03	8.60000E-12	274.032
387.811	0.0322225	8.97557E-04	9.90000E-12	807.748
392.711	48.6334	3.02610E-03	4.68000E-12	56.3379
397.811	11.2856	0.0108392	3.89000E-12	23.4036
402.911	6.33792	0.0168696	3.40000E-12	21.5149
407.911	5.11202	0.018639	3.03000E-12	19.0539
412.811	4.38066	0.0208894	2.91000E-12	17.1103
417.711	3.74317	0.0234389	2.79000E-12	15.1001
422.611	3.06263	0.0273124	2.66000E-12	12.5143
427.611	2.48573	0.0321331	2.54000E-12	9.44149
432.811	2.16663	0.0368655	2.54000E-12	9.55543
437.811	1.92	0.0416011	2.54000E-12	8.63049
442.911	1.6736	0.0477258	2.54000E-12	7.23894
447.711	1.55331	0.0538511	2.66000E-12	6.8132
452.711	1.42071	0.0588773	2.66000E-12	6.02969
457.711	1.31835	0.0694118	2.91000E-12	4.86607
462.811	1.19848	0.0795032	3.03000E-12	4.68233
468.011	1.20044	0.0825166	3.15000E-12	5.1688
477.611	1.18264	0.0967878	3.64000E-12	4.25065
482.611	1.08743	0.115961	4.01000E-12	3.22193
487.811	0.930947	0.143561	4.25000E-12	2.8146
492.711	0.961416	0.160926	4.92000E-12	2.55268
497.611	0.98169	0.181307	5.66000E-12	2.47895
502.711	0.92743	0.20819	6.14000E-12	2.19743
507.811	0.920207	0.235796	6.90000E-12	2.14575
512.811	0.927623	0.267811	7.90000E-12	1.86728
517.811	0.92982	0.297616	8.80000E-12	1.92233
522.811	0.930753	0.337861	1.00000E-11	1.59354
527.711	0.891567	0.387982	1.10000E-11	1.60374
532.611	0.990763	0.422138	1.33000E-11	1.4666
537.611	0.97471	0.477484	1.48000E-11	1.45481
542.711	0.961732	0.549323	1.68000E-11	1.39551

ORIGINAL PAGE IS
OF POOR QUALITY

3 of 4

547.711	0.944192	0.622412	1.87000E-11	1.28733
552.611	0.938619	0.789507	2.12000E-11	1.21714
557.711	0.938645	0.807399	2.41000E-11	1.10502
562.911	0.960022	0.884413	2.70000E-11	1.32722
572.711	0.922447	1.16248	3.41000E-11	1.15292
577.611	1.00767	1.27637	4.09000E-11	1.22982
582.511	1.05074	1.36637	4.39000E-11	1.21451
587.511	1.01872	1.41378	4.58000E-11	1.11372
592.711	0.86747	1.73279	4.78000E-11	0.996626
597.611	0.864987	2.0906	5.75000E-11	1.08419
602.711	0.960963	2.28086	6.97000E-11	1.0959
607.711	0.997136	2.44726	7.76000E-11	1.09127
612.611	0.991588	2.64489	8.34000E-11	1.06839
617.711	0.970342	2.95558	9.12000E-11	1.04763
622.611	0.974141	3.24427	1.00500E-10	1.06742
627.511	0.982319	3.47336	1.08500E-10	1.0607
632.611	1.03929	3.73681	1.23500E-10	1.05389
637.711	1.00654	3.98338	1.27500E-10	1.07738
642.711	1.01589	4.19432	1.35500E-10	1.06805
647.711	0.9991	4.39074	1.39500E-10	1.06259
652.611	0.997809	4.61703	1.46500E-10	1.06125
657.611	1.01224	4.79971	1.54500E-10	1.07107
662.511	1.00277	4.97046	1.58500E-10	1.06737
667.611	1.02536	5.10631	1.66500E-10	1.06755
672.611	1.0235	5.23852	1.70500E-10	1.0661
677.611	1.02781	5.3389	1.74500E-10	1.06878
682.411	1.03487	5.42405	1.78500E-10	1.062
687.411	1.041	5.51294	1.82500E-10	1.06465
692.711	1.04162	5.6002	1.86500E-10	1.06895
697.611	1.05195	5.6648	1.89500E-10	1.06875
702.511	1.03774	5.74237	1.89500E-10	1.05695
707.511	1.04233	5.83776	1.93500E-10	1.06378
712.411	1.0514	5.90702	1.97500E-10	1.05906
717.511	1.03672	5.99066	1.97500E-10	1.06169
722.511	1.02395	6.06542	1.97500E-10	1.06028
727.611	1.02843	6.1613	2.01500E-10	1.06215
732.611	1.03134	6.26584	2.05500E-10	1.06145
737.511	1.04118	6.32748	2.09500E-10	1.0579
742.411	1.02682	6.41597	2.09500E-10	1.05643
747.511	1.03127	6.51025	2.13500E-10	1.05424
752.411	1.03667	6.59765	2.17500E-10	1.05912
757.311	1.03906	6.70355	2.21500E-10	1.05465
762.511	1.02529	6.79354	2.21500E-10	1.05563
767.511	1.02969	6.88669	2.25500E-10	1.05708
772.611	1.0288	6.98434	2.28500E-10	1.04967
777.611	1.03188	7.08541	2.32500E-10	1.04958
782.611	1.01732	7.18681	2.32500E-10	1.05045
787.511	1.02181	7.27835	2.36500E-10	1.053
792.411	1.02432	7.38333	2.40500E-10	1.04879
797.411	1.0506	7.49796	2.50500E-10	1.05135
802.411	1.03751	7.59249	2.50500E-10	1.05078
807.411	1.02328	7.69811	2.50500E-10	1.04384
812.411	1.04163	7.80404	2.58500E-10	1.04997
817.511	1.02683	7.9165	2.58500E-10	1.05556
822.411	1.04448	8.02358	2.66500E-10	1.04183
827.611	0.951767	8.8052	2.66500E-10	1.09628
832.511	1.08063	9.32653	3.20500E-10	1.08613
837.511	1.10882	8.66407	3.05500E-10	1.06343
842.411	1.06598	8.54028	2.89500E-10	1.0491
847.611	1.03186	8.57886	2.81500E-10	1.04688
852.511	1.02187	8.66274	2.81500E-10	1.03992
857.511	1.041	8.74516	2.89500E-10	1.04745
862.511	1.03363	8.80751	2.89500E-10	1.04271
867.411	1.02284	8.90045	2.89500E-10	1.04355

ORIGINAL PAGE IS
OF POOR QUALITY

872.511	1.03322	9.01087	2.97500E-10	1.04139
877.411	1.0252	9.12523	2.97500E-10	1.03495
882.411	1.01227	9.2419	2.97500E-10	1.03868
887.411	1.02562	9.36032	2.05500E-10	1.0422
892.411	1.03491	9.48551	3.12500E-10	1.03806
897.511	1.01978	9.62625	3.12500E-10	1.03454
902.411	1.00556	9.77268	3.12500E-10	1.03728
907.411	1.01666	9.91337	3.20500E-10	1.03808
912.311	1.02729	10.0557	3.28500E-10	1.03477
917.411	1.01206	10.207	3.28500E-10	1.03423
922.311	1.02139	10.3601	3.36500E-10	1.03518
927.411	1.03077	10.5099	3.44500E-10	1.0365
932.411	1.01564	10.6665	3.44500E-10	1.03451
937.511	1.01972	10.8396	3.51500E-10	1.0341
942.411	1.00546	10.9934	3.51500E-10	1.03472
947.311	1.01423	11.1464	3.59500E-10	1.03003
952.311	1.02221	11.3055	3.67500E-10	1.03473
957.311	1.00788	11.4662	3.67500E-10	1.03425
962.411	1.01451	11.6392	3.75500E-10	1.02747
967.311	0.99932	11.8162	3.75500E-10	1.0302
972.411	1.00494	12.0004	3.83500E-10	1.02835
977.411	1.01098	12.1775	3.91500E-10	1.03114
982.311	0.997481	12.3424	3.91500E-10	1.02736
987.211	1.00278	12.4966	3.98500E-10	1.03166
992.311	1.00853	12.6748	4.06500E-10	1.02867
997.411	1.01267	12.8715	4.14500E-10	1.02965
1002.41	1.01706	13.0632	4.22500E-10	1.02741
1007.31	1.00297	13.2468	4.22500E-10	1.02954
1012.41	1.00748	13.4372	4.30500E-10	1.02721
1017.41	1.01019	13.619	4.37500E-10	1.0288
1022.41	0.995933	13.8132	4.37500E-10	1.02539
1027.31	0.99889	14.025	4.45500E-10	1.02561
1032.31	1.00175	14.236	4.53500E-10	1.02589
1037.21	1.00616	14.4237	4.61500E-10	1.02554
1042.31	0.992401	14.6237	4.61500E-10	1.02734
1047.31	0.994051	14.8525	4.69500E-10	1.0267
1052.21	0.995652	15.0497	4.76500E-10	1.02601
1057.31	0.998221	15.263	4.84500E-10	1.02613
1062.21	0.982647	15.5049	4.84500E-10	1.02173
1067.21	1.00944	15.7164	5.04500E-10	1.02696
1072.21	1.02539	15.9319	5.19500E-10	1.024
1077.21	1.01098	16.159	5.19500E-10	1.02578
1082.11	0.997525	16.377	5.19500E-10	1.02528
1087.11	1.01328	16.6189	5.35500E-10	1.02657
1092.11	0.999627	16.8459	5.35500E-10	1.02583
1097.11	1.01291	17.1216	5.51500E-10	1.02214
1102.11	0.998736	17.3647	5.51500E-10	1.02288
1107.21	0.985188	17.6035	5.51500E-10	1.01871
1112.21	0.997629	17.8568	5.66500E-10	1.02153
1117.21	0.985924	18.0688	5.66500E-10	1.02197
1122.31	0.999847	18.3204	5.82500E-10	1.02258
1127.21	0.983997	18.6155	5.82500E-10	1.02394
1132.11	0.996571	18.8855	5.98500E-10	1.02272
1137.11	0.984091	19.125	5.98500E-10	1.02131
1142.21	0.994287	19.4033	6.13500E-10	1.02107
1147.21	0.979844	19.6893	6.13500E-10	1.02231
1152.11	0.991857	19.9581	6.29500E-10	1.01982
1157.11	0.977135	20.2588	6.29500E-10	1.0222
1162.21	0.987324	20.5275	6.44500E-10	1.02001
1167.11	0.973682	20.8151	6.44500E-10	1.01869

ORIGINAL PAGE IS
OF POOR QUALITY

SUN. DYNAMIC CALIBRATION +25% CASE

Page 1 of 4

1-23-82 RUN #1 TAPE 2M1

Time of 28 AMU Sample, Secs	Ratio of Dynamic Drop To Static Drop	Baratron Pressure at time of 28 AMU Sample, Torr	*Corrected 28 AMU Ion Current Amps	Ratio of Inlet Transducer Pressure to Baratron Pressure
3.411	0.749997	9.41180E-06	1.44000E-12	35064.4
8.711	0.704304	1.00224E-05	1.44000E-12	34903.5
18.511	0.636265	1.20957E-05	1.57000E-12	30194.3
23.211	0.594599	1.29433E-05	1.57000E-12	24155.5
28.311	0.598404	1.38440E-05	1.69000E-12	26604.8
33.411	0.537958	1.64930E-05	1.81000E-12	19610.7
38.411	0.553336	1.70977E-05	1.93000E-12	27370.4
43.311	0.555477	1.70318E-05	1.93000E-12	17613.4
48.311	0.526825	1.79581E-05	1.93000E-12	29492.1
53.311	0.652042	1.54116E-05	2.05000E-12	20129.6
58.411	0.574561	1.85990E-05	2.18000E-12	17917.5
63.311	0.643944	1.75085E-05	2.30000E-12	23057.5
68.211	0.615075	1.83303E-05	2.30000E-12	15528.5
73.211	0.67765	1.92418E-05	2.66000E-12	22645.7
78.211	0.655618	2.08604E-05	2.79000E-12	14356.5
83.211	0.586426	2.53279E-05	3.03000E-12	16052.7
88.311	0.694415	2.40010E-05	3.40000E-12	15592.1
93.211	0.756497	2.35865E-05	3.64000E-12	16984.3
98.211	0.816199	2.33627E-05	3.89000E-12	13202.3
103.111	0.757174	2.59608E-05	4.01000E-12	13685.2
108.411	0.725824	2.87030E-05	4.25000E-12	12766.7
113.311	0.747027	2.78883E-05	4.25000E-12	15157.3
118.111	0.847419	2.70718E-05	4.68000E-12	12639.5
123.111	0.811408	2.97232E-05	4.92000E-12	11167.7
128.411	0.860316	3.08254E-05	5.41000E-12	11599
133.311	0.881755	3.28000E-05	5.90000E-12	11599
138.111	0.90888	3.31155E-05	6.14000E-12	11322.8
143.111	0.894365	3.50232E-05	6.39000E-12	8813.5
148.111	0.888029	3.80883E-05	6.90000E-12	9607.31
153.311	0.878836	4.12756E-05	7.40000E-12	8766.12
158.311	0.879567	4.40279E-05	7.90000E-12	7252.8
163.211	0.886873	4.58761E-05	8.30000E-12	8043.33
168.211	0.852777	4.94348E-05	8.60000E-12	6223.28
173.111	0.912951	5.15458E-05	9.60000E-12	6483.09
178.211	0.931542	5.26220E-05	1.00000E-11	6830.33
183.311	0.876692	5.87100E-05	1.05000E-11	6067.77
188.311	0.853256	6.49185E-05	1.13000E-11	4795.58
193.211	0.862988	6.81626E-05	1.20000E-11	5562.12
198.111	0.929935	7.01082E-05	1.33000E-11	4491.73
203.111	0.92654	7.56557E-05	1.43000E-11	4081.34
208.111	0.894871	8.10720E-05	1.48000E-11	4600.35
213.311	0.887772	8.72419E-05	1.58000E-11	4090.85
218.311	0.892979	9.49674E-05	1.73000E-11	3337.76
223.311	0.873804	1.01509E-04	1.82000E-11	3562.26
228.311	0.852839	1.10358E-04	1.92000E-11	2828.26

13

* Corrected for background by subtracting 3.5 E-12 Amps

ORIGINAL PAGE IS
OF POOR QUALITY

235.211	0.001206	1.211301E-04	2.000000E-11	2201.04
238.111	0.824928	1.32501E-04	2.260000E-11	2347.72
243.211	0.815915	1.447911E-04	2.410000E-11	2180.95
248.011	0.012541	1.56603E-04	2.600000E-11	2001.64
253.611	0.786501	1.71357E-04	2.750000E-11	2076.69
258.311	0.010078	1.86790E-04	3.120000E-11	1667.17
263.211	0.764545	2.12113E-04	3.310000E-11	1300.7
268.111	0.746452	2.37704E-04	3.610000E-11	1259.21
273.111	0.780047	2.56406E-04	4.000000E-11	1435.65
278.211	0.770905	2.79147E-04	4.390000E-11	1094.65
283.111	0.759287	3.08597E-04	4.780000E-11	1173.5
288.111	0.751048	3.30646E-04	5.070000E-11	960.247
293.111	0.727827	3.74469E-04	5.560000E-11	999.62
298.011	0.727073	4.30343E-04	6.390000E-11	739.119
303.111	0.751506	4.67698E-04	7.170000E-11	750.661
308.011	0.739822	5.26756E-04	7.950000E-11	677.318
313.011	0.736832	5.81416E-04	8.730000E-11	624.917
318.211	0.701598	6.64449E-04	9.510000E-11	449.673
323.111	0.705698	7.53669E-04	1.085000E-10	417.594
328.011	0.731293	8.27837E-04	1.235000E-10	424.466
333.111	0.71147	9.33581E-04	1.355000E-10	387.028
338.011	0.694662	1.06202E-03	1.505000E-10	276.989
343.111	0.690919	1.20967E-03	1.705000E-10	260.337
348.011	0.720652	1.31621E-03	1.935000E-10	231.439
353.011	0.694373	1.53545E-03	2.175000E-10	222.341
358.011	0.660127	1.78590E-03	2.405000E-10	172.556
362.911	0.681449	2.02495E-03	2.815000E-10	171.211
368.211	0.656843	2.39186E-03	3.205000E-10	125.513
373.111	0.650388	2.74452E-03	3.675000E-10	120.612
378.011	0.6639	3.17863E-03	4.305000E-10	108.69
383.111	0.695726	3.66038E-03	5.195000E-10	84.2113
388.011	0.706836	4.15064E-03	5.985000E-10	71.568
393.111	0.676304	4.90338E-03	6.765000E-10	70.937
398.111	0.694533	5.76279E-03	8.165000E-10	60.2187
403.011	0.696872	6.73527E-03	9.575000E-10	51.8027
408.111	0.707841	7.87052E-03	1.13650E-09	38.0592
413.311	0.0836	8.59015E-03	1.465000E-10	44.1458
422.911	19.4914	0.0114548	7.10000E-12	29.9872
428.111	12.0413	0.0120488	4.92000E-12	24.9807
433.111	7.23826	0.0152926	3.52000E-12	17.7200
438.011	4.86669	0.0195786	3.03000E-12	15.3134
442.911	3.753	0.0222882	2.66000E-12	13.7379
447.911	2.86908	0.0265244	2.42000E-12	12.5163
452.911	2.26736	0.0318991	2.30000E-12	11.1939
458.011	1.81293	0.0378324	2.18000E-12	8.86209
462.911	1.45305	0.0443653	2.05000E-12	7.01908
468.011	1.34753	0.0508733	2.10000E-12	6.7069
473.111	1.15703	0.0592491	2.18000E-12	6.07796
478.011	1.06375	0.0679923	2.30000E-12	5.01482
482.911	0.9087	0.0795939	2.30000E-12	4.47413
488.111	0.931282	0.085768	2.54000E-12	4.38011
493.011	0.863796	0.10157	2.79000E-12	3.08655
498.011	0.770137	0.128622	3.15000E-12	2.79598
503.011	0.753759	0.146853	3.52000E-12	2.68675
508.011	0.707115	0.178331	4.01000E-12	2.16048
513.011	0.742211	0.208454	4.92000E-12	1.99028
518.011	0.786483	0.226308	5.66000E-12	2.06209
522.911	0.797875	0.251848	6.39000E-12	1.79044
528.011	0.780128	0.29829	7.40000E-12	1.63926
533.011	0.755639	0.357896	8.60000E-12	1.51549
537.911	0.723787	0.434472	1.00000E-11	1.32347
542.811	0.73573	0.512903	1.20000E-11	1.30301
547.911	0.787847	0.590735	1.48000E-11	1.24461
552.811	0.794313	0.700736	1.77000E-11	1.13314
557.911	0.791492	0.822425	2.07000E-11	1.15335

ORIGINAL PAGE
OF POOR QUALITY

563.111	0.851753	0.889766	2.41000E-11	1.29301
569.011	0.869552	0.894511	2.75000E-11	1.03291
573.011	0.738420	1.32868	3.12000E-11	0.936888
578.011	0.773309	1.58593	3.90000E-11	1.11179
583.011	0.89183	1.6502	4.68000E-11	1.14985
587.011	0.916410	1.73975	5.07000E-11	1.12005
592.011	0.90656	1.89395	5.46000E-11	1.04021
597.111	0.77159	2.34344	5.75000E-11	0.91577
602.911	0.784177	3.03166	7.56000E-11	1.00925
608.011	0.851444	3.44217	9.32000E-11	1.04776
612.911	0.896546	3.80566	1.08500E-10	1.02497
618.011	0.903381	4.29901	1.23500E-10	1.03521
622.911	0.907579	4.69491	1.35500E-10	1.0306
627.011	0.898402	5.1279	1.46500E-10	1.03102
632.011	0.921143	5.54752	1.62500E-10	1.03353
637.011	0.916695	5.96609	1.74500E-10	1.02349
642.711	0.930634	6.40329	1.89500E-10	1.03705
647.011	0.935527	6.77316	2.01500E-10	1.03291
652.911	0.957843	7.14065	2.17500E-10	1.03813
657.011	0.955472	7.42166	2.25500E-10	1.03577
662.011	0.955625	7.65082	2.32500E-10	1.04057
667.911	0.999751	7.87932	2.50500E-10	1.03843
673.111	0.966404	8.1512	2.50500E-10	1.05008
682.711	0.984489	8.257	2.58500E-10	1.04417
687.911	0.987435	8.23237	2.58500E-10	1.04176
692.911	0.984462	8.25723	2.58500E-10	1.04405
697.911	0.979436	8.2996	2.58500E-10	1.04381
702.911	0.970673	8.37453	2.58500E-10	1.03738
707.011	0.980202	8.48055	2.66500E-10	1.0365
712.711	0.972651	8.61614	2.66500E-10	1.035
717.911	0.977796	8.79593	2.73500E-10	1.0325
722.911	0.959663	8.96213	2.73500E-10	1.03249
727.911	0.968931	9.13684	2.81500E-10	1.03999
732.911	0.975977	9.32785	2.89500E-10	1.03677
737.911	0.984769	9.50004	2.97500E-10	1.03156
742.911	0.994033	9.65681	3.05500E-10	1.03672
747.011	0.979829	9.80468	3.05500E-10	1.03387
752.011	0.98006	9.94579	3.12500E-10	1.03466
757.711	1.00005	10.0781	3.20500E-10	1.03406
762.711	0.986233	10.2193	3.28500E-10	1.03182
767.011	0.994798	10.3842	3.28500E-10	1.0336
772.011	0.981443	10.5255	3.28500E-10	1.02953
777.011	0.99173	10.67	3.36500E-10	1.03119
782.011	0.978877	10.8101	3.36500E-10	1.033
787.711	0.989164	10.952	3.44500E-10	1.03373
792.011	0.99543	11.1042	3.51500E-10	1.03472
797.011	0.982503	11.2503	3.51500E-10	1.03071
802.011	0.991512	11.4018	3.59500E-10	1.031
807.711	0.978197	11.557	3.59500E-10	1.03084
812.011	0.984361	11.7402	3.67500E-10	1.0303
817.711	0.990394	11.9227	3.75500E-10	1.02863
822.711	0.979175	12.0593	3.75500E-10	1.02884
827.011	0.987387	12.2138	3.83500E-10	1.02897
832.711	0.994789	12.3758	3.91500E-10	1.02448
837.011	0.982296	12.5332	3.91500E-10	1.02847
842.011	0.984364	12.7305	3.98500E-10	1.03137
847.711	0.991039	12.8986	4.06500E-10	1.0276
852.711	0.99888	13.0492	4.14500E-10	1.0271
857.011	0.984136	13.2447	4.14500E-10	1.02631
862.711	0.98751	13.4542	4.22500E-10	1.02713
867.011	0.991463	13.6543	4.30500E-10	1.02487
872.711	0.980205	13.8111	4.38500E-10	1.02746
877.011	0.982402	14.0043	4.37500E-10	1.02634
882.711	0.98601	14.2082	4.45500E-10	1.02618

887.611	0.973289	14.3939	4.45500E-10	1.02483
892.611	0.993243	14.6113	4.61500E-10	1.02623
897.611	0.988804	14.7966	4.61500E-10	1.02505
902.711	0.985209	14.9853	4.63500E-10	1.02574
907.611	0.986294	15.1925	4.76500E-10	1.02486
912.611	0.98934	15.4	4.84500E-10	1.02368
917.611	0.976767	15.5992	4.84500E-10	1.02599
922.611	1.00256	15.8242	5.04500E-10	1.02559
927.511	1.01035	16.0421	5.19500E-10	1.02147
932.611	1.00371	16.276	5.19500E-10	1.0234
937.711	1.02007	16.4985	5.35500E-10	1.02053
942.611	1.00771	16.7107	5.35500E-10	1.02254
947.611	0.993769	16.9452	5.35500E-10	1.0215
952.711	1.00965	17.177	5.51500E-10	1.02375
957.611	0.996613	17.4017	5.51500E-10	1.01944
962.611	1.00946	17.6475	5.66500E-10	1.01999
967.711	0.995143	17.9014	5.66500E-10	1.02132
972.711	0.98194	18.1421	5.66500E-10	1.02255
977.711	0.996459	18.3827	5.82500E-10	1.02126
982.611	1.01022	18.6302	5.98500E-10	1.02388
987.611	0.996107	18.8943	5.98500E-10	1.02202
992.611	1.00765	19.1459	6.13500E-10	1.02244
997.511	0.994056	19.4078	6.13500E-10	1.02196
1002.61	1.00351	19.6671	6.29500E-10	1.02174
1007.51	0.992384	19.9475	6.29500E-10	1.02195
1012.71	0.978638	20.2277	6.29500E-10	1.02109
1017.61	0.989285	20.4868	6.44500E-10	1.01935
1022.51	1.00038	20.7625	6.60500E-10	1.01954
1027.51	0.985623	21.0734	6.60500E-10	1.01818
1032.51	0.995735	21.3647	6.76500E-10	1.0198
1037.51	1.00433	21.6515	6.91500E-10	1.01879
1042.51	0.991129	21.9399	6.91500E-10	1.01777
1047.61	0.977377	22.2486	6.91500E-10	1.01989
1052.51	0.986644	22.5496	7.07500E-10	1.01919
1057.41	0.996084	22.841	7.23500E-10	1.01985
1062.51	0.98211	23.166	7.23500E-10	1.01919
1067.61	0.988741	23.4877	7.38500E-10	1.01758
1072.61	0.996615	23.807	7.54500E-10	1.01863
1077.61	0.982895	24.1393	7.54500E-10	1.01686
1082.51	0.989471	24.4556	7.69500E-10	1.01623
1087.51	0.996717	24.7826	7.85500E-10	1.01906
1092.41	0.984294	25.0954	7.85500E-10	1.01853
1097.51	0.989902	25.4615	8.01500E-10	1.01568
1102.41	0.994396	25.8208	8.16500E-10	1.01727
1107.51	1.00042	26.1682	8.32500E-10	1.01625
1112.41	0.987419	26.5128	8.32500E-10	1.01879
1117.41	0.992456	26.8652	8.48500E-10	1.01661
1122.51	0.978897	27.2576	8.48500E-10	1.01732
1127.51	0.982914	27.6261	8.63500E-10	1.01648
1132.41	0.987581	28.005	8.79500E-10	1.01685
1137.41	0.990978	28.385	8.94500E-10	1.01622
1142.41	0.994963	28.777	9.10500E-10	1.0156
1147.61	0.981285	29.1805	9.10500E-10	1.01664
1152.51	0.985319	29.5693	9.26500E-10	1.01546
1157.51	0.987519	29.9811	9.41500E-10	1.01627
1162.41	0.991104	30.3803	9.57500E-10	1.01529
1167.51	0.977555	30.8014	9.57500E-10	1.01549
1172.51	0.980438	31.224	9.73500E-10	1.01527

ORIGINAL PAGE IS
OF POOR QUALITY

SIMS DYNAMIC CALIBRATION #251 CASE

Page 1 of 4

2-28-82 RUN #2 TAPE 202

Time of 28 AMU Sample, Secs	Ratio of Dynamic Drop To Static Drop	Baratron Pressure at time of 28 AMU Sample, Torr	*Corrected 28 AMU Ion Current Amps	Ratio of Inlet Transducer Pressure to Baratron Pressure
3.311	0.907712	1.57150E-05	2.91000E-12	26383.4
8.611	1.32122	1.07966E-05	2.91000E-12	23837.6
18.111	0.802018	1.62580E-05	2.66000E-12	14768.9
23.211	0.884314	1.47450E-05	2.66000E-12	27449.4
28.111	1.13119	1.15269E-05	2.66000E-12	15640.1
33.111	0.910648	1.43186E-05	2.66000E-12	14590.5
38.111	0.885546	1.54441E-05	2.79000E-12	13419.6
43.211	0.880537	1.62000E-05	2.91000E-12	16774.5
48.011	0.917424	1.68310E-05	3.15000E-12	15266.8
53.211	0.885182	1.81086E-05	3.27000E-12	14689.1
58.111	0.914986	1.82152E-05	3.40000E-12	12213.4
63.211	0.956223	1.86600E-05	3.64000E-12	10979.7
68.211	0.900422	2.04697E-05	3.76000E-12	12698.5
73.211	0.9313	2.11069E-05	4.01000E-12	13127.9
78.111	0.998597	2.08626E-05	4.25000E-12	12879.1
83.211	1.00261	2.16590E-05	4.43000E-12	12131.6
88.211	0.959604	2.39069E-05	4.68000E-12	10451.9
93.211	1.01221	2.50372E-05	5.17000E-12	11466.2
98.011	1.08576	2.55535E-05	5.66000E-12	9568.65
103.011	1.02848	2.69767E-05	5.66000E-12	10870
108.011	1.09455	2.64232E-05	5.90000E-12	9568.65
113.211	1.07991	2.78708E-05	6.14000E-12	9990.8
118.111	1.12469	2.78507E-05	6.39000E-12	7548.6
123.211	1.07828	3.00040E-05	6.60000E-12	8599.68
128.111	1.0759	3.14373E-05	6.90000E-12	6967.94
133.011	1.09833	3.16880E-05	7.10000E-12	8387.33
138.111	1.11578	3.33890E-05	7.60000E-12	7831.41
143.211	1.03886	3.58610E-05	7.60000E-12	7266.04
148.111	1.02487	3.87422E-05	8.10000E-12	5341.51
153.011	1.01849	4.13914E-05	8.60000E-12	6409.19
158.211	1.04231	4.27968E-05	9.10000E-12	5020.77
163.111	1.05992	4.43981E-05	9.60000E-12	5907.6
168.211	1.03188	4.75050E-05	1.00000E-11	5489.89
173.111	1.03962	5.09235E-05	1.08000E-11	5127.35
178.011	1.05795	5.32847E-05	1.15000E-11	5060.51
183.011	1.04413	5.63371E-05	1.20000E-11	3623.32
188.111	1.01116	6.25370E-05	1.29000E-11	3298.93
193.211	0.990324	6.83080E-05	1.38000E-11	3800.69
198.211	0.979131	7.40953E-05	1.48000E-11	2797.93
203.111	0.959139	8.07585E-05	1.58000E-11	3189.55
207.911	0.982502	8.38196E-05	1.68000E-11	3326.18
213.211	0.974726	8.90144E-05	1.77000E-11	2775.78
218.111	0.956201	9.84287E-05	1.92000E-11	2739.41
222.911	0.97417	1.01645E-04	2.02000E-11	2570.26
228.011	0.987257	1.07249E-04	2.16000E-11	2477.2
233.111	0.963434	1.14989E-04	2.26000E-11	2227.45

*Corrected for background by subtracting 3.5 E-12 Amps

238.011	0.822215	1.28101E-04	2.41000E-11	1983.56
243.011	0.8797	1.42651E-04	2.56000E-11	1805.63
247.911	0.869624	1.55014E-04	2.75000E-11	1681.61
252.911	0.878578	1.68880E-04	3.02000E-11	1518.14
258.011	0.857024	1.89191E-04	3.31000E-11	1372.52
263.111	0.81728	2.10526E-04	3.51000E-11	1280.19
268.011	0.822505	2.26472E-04	3.80000E-11	926.682
273.011	0.811233	2.53185E-04	4.19000E-11	974.013
278.111	0.806185	2.78484E-04	4.58000E-11	978.221
283.011	0.853255	2.85527E-04	4.97000E-11	915.599
288.011	0.815747	3.16680E-04	5.27000E-11	789.281
292.911	0.756844	3.66589E-04	5.66000E-11	680.906
297.911	0.801565	4.14630E-04	6.78000E-11	622.993
303.111	0.756799	4.76724E-04	7.36000E-11	514.58
308.011	0.743561	5.37292E-04	8.15000E-11	493.402
312.911	0.785237	5.81815E-04	9.32000E-11	433.273
317.911	0.738175	6.67385E-04	1.00500E-10	300.607
322.911	0.807097	7.31865E-04	1.20500E-10	365.303
328.011	0.80691	7.74559E-04	1.27500E-10	266.682
333.111	0.775328	8.81979E-04	1.39500E-10	280.01
337.911	0.719035	1.02602E-03	1.50500E-10	244.532
343.011	0.694023	1.20426E-03	1.70500E-10	163.766
348.011	0.711243	1.36119E-03	1.97500E-10	154.402
353.011	0.769482	1.43654E-03	2.25500E-10	164.086
357.911	0.798473	1.53786E-03	2.50500E-10	133.554
363.011	0.761113	1.76148E-03	2.73500E-10	140.17
367.911	0.719287	2.08199E-03	3.05500E-10	118.615
372.811	0.682145	2.47561E-03	3.44500E-10	99.0016
377.911	0.63783	3.06262E-03	3.98500E-10	62.403
383.011	0.675208	3.66263E-03	5.04500E-10	69.6847
387.911	0.670719	4.25721E-03	5.82500E-10	45.4934
392.911	0.692773	5.00616E-03	7.07500E-10	51.0506
397.011	0.718855	5.78602E-03	8.48500E-10	42.0489
402.811	0.716383	6.76396E-03	9.88500E-10	37.8355
407.811	0.741392	7.91105E-03	1.19650E-09	30.4545
413.011	0.0839185	8.79120E-03	1.50500E-10	31.5108
418.011	61.3081	0.0103611	2.02000E-11	21.2736
422.911	19.5305	0.013042	8.10000E-12	20.2299
427.811	13.504	0.0137392	5.90000E-12	15.3249
432.911	9.53981	0.0154269	4.68000E-12	15.9178
437.011	6.20952	0.0196999	3.89000E-12	11.5475
442.811	4.55289	0.0243124	3.52000E-12	10.7009
447.911	3.91907	0.0262988	3.27000E-12	9.88289
452.811	3.11503	0.0305881	3.03000E-12	7.74282
457.911	2.42856	0.0376804	2.91000E-12	6.61111
462.811	2.02409	0.0433457	2.79000E-12	5.82978
467.711	1.65433	0.0530339	2.79000E-12	4.35509
472.711	1.44967	0.0631242	2.91000E-12	5.08473
477.711	1.41118	0.0675198	3.03000E-12	4.51511
482.711	1.2246	0.0778072	3.03000E-12	3.17605
488.011	1.20622	0.0852495	3.27000E-12	3.20195
492.811	1.17079	0.094544	3.52000E-12	2.9808
497.811	0.951705	0.124239	3.76000E-12	2.25128
502.811	0.853709	0.147709	4.01000E-12	2.14991
507.711	0.973907	0.159009	4.92000E-12	1.92162
512.711	0.90097	0.188825	5.41000E-12	1.76632
517.911	0.810464	0.238236	6.14000E-12	1.42383
522.811	0.818623	0.272739	7.10000E-12	1.54831
527.711	0.874272	0.298541	8.30000E-12	1.34035
532.811	0.854813	0.353161	9.60000E-12	1.25006
537.711	0.800116	0.432327	1.10000E-11	0.993863
542.711	0.810253	0.511136	1.33000E-11	1.11231
547.711	0.853517	0.582127	1.58000E-11	1.09088
552.811	0.843157	0.697438	1.87000E-11	1.06139
557.711	0.854434	0.813367	2.21000E-11	0.988843


ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE 3
OF POOR QUALITY

562.811	0.919564	0.875449	2.56000E-11	1.12421
567.811	0.798178	1.11102	2.82000E-11	0.789580
572.811	0.761501	1.44947	3.51000E-11	1.04591
577.811	0.85378	1.61893	4.39000E-11	0.961378
582.811	0.891526	1.85887	5.27000E-11	1.08658
587.811	0.931135	1.9418	5.75000E-11	1.02166
592.711	0.927161	2.23174	6.58000E-11	0.971797
597.811	0.894157	2.65977	7.56000E-11	0.967478
602.711	0.882795	3.04208	8.54000E-11	0.996348
607.711	0.920617	3.43239	1.00500E-10	1.00518
612.811	0.913751	3.87166	1.12500E-10	1.01778
617.811	0.950938	4.21629	1.27500E-10	1.00475
622.711	0.942014	4.65287	1.39500E-10	0.99518
627.811	0.92259	5.1298	1.50500E-10	1.01742
632.611	0.927439	5.50986	1.62500E-10	1.00826
637.811	0.943318	5.95049	1.78500E-10	1.01981
642.811	0.938216	6.35154	1.89500E-10	1.0149
647.811	0.95741	6.74973	2.05500E-10	1.02063
652.711	0.963317	7.10007	2.17500E-10	1.02262
657.711	0.959731	7.38873	2.25500E-10	1.02382
662.811	0.973317	7.64099	2.36500E-10	1.02726
667.811	1.00101	7.8694	2.50500E-10	1.02621
672.811	0.978928	8.04692	2.50500E-10	1.03128
678.811	0.996773	8.15524	2.58500E-10	1.03996
687.611	1.01715	8.23916	2.66500E-10	1.03379
692.711	1.00948	8.30173	2.66500E-10	1.03307
697.711	0.994537	8.42653	2.66500E-10	1.028
702.611	0.97787	8.57016	2.66500E-10	1.02357
707.711	0.986124	8.72165	2.73500E-10	1.02407
712.711	0.999046	8.86065	2.81500E-10	1.02237
717.711	0.98545	8.9829	2.81500E-10	1.02637
722.711	0.998875	9.11402	2.89500E-10	1.02246
727.611	1.01026	9.26026	2.97500E-10	1.02843
732.611	0.994801	9.40423	2.97500E-10	1.02687
737.611	0.982354	9.52339	2.97500E-10	1.02557
742.611	0.992717	9.67739	3.05500E-10	1.02086
747.611	1.00009	9.82613	3.12500E-10	1.02994
752.711	0.987373	9.95271	3.12500E-10	1.02058
757.611	0.998208	10.0967	3.20500E-10	1.02344
762.511	0.988739	10.1934	3.20500E-10	1.02167
767.611	0.996804	10.3633	3.28500E-10	1.02058
772.511	1.00514	10.5276	3.36500E-10	1.02731
777.611	0.994741	10.6377	3.36500E-10	1.01972
782.611	1.00265	10.8046	3.44500E-10	1.02415
787.711	0.98737	10.9719	3.44500E-10	1.02044
792.711	0.997514	11.081	3.51500E-10	1.0228
797.611	0.985376	11.2175	3.51500E-10	1.01939
802.511	0.991443	11.4026	3.59500E-10	1.02129
807.611	0.998074	11.5789	3.67500E-10	1.02432
812.511	0.988529	11.6907	3.67500E-10	1.02303
817.511	0.992959	11.8919	3.75500E-10	1.01668
822.711	0.977894	12.0751	3.75500E-10	1.02116
827.611	0.988828	12.196	3.83500E-10	1.02196
832.511	0.996868	12.35	3.91500E-10	1.02192
837.611	0.980388	12.5576	3.91500E-10	1.01796
842.611	1.0034	12.7396	4.06500E-10	1.02025
847.511	0.993272	12.8696	4.06500E-10	1.02065
852.511	0.997832	13.0629	4.14500E-10	1.02009
857.411	0.985118	13.2315	4.14500E-10	1.01885
862.511	0.988171	13.4452	4.22500E-10	1.01981
867.511	0.982153	13.6448	4.30500E-10	1.02195
872.611	0.997221	13.7962	4.37500E-10	1.02082
877.611	0.982367	14.0048	4.37500E-10	1.01742
882.611	0.985656	14.2133	4.45500E-10	1.01908
887.611	0.992125	14.3742	4.53500E-10	1.01669


892.511	0.97737	14.5912	4.53500E-10	1.02164
897.511	0.981216	14.7964	4.61500E-10	1.02002
902.511	0.980354	14.9684	4.69500E-10	1.01739
907.411	0.985982	15.1973	4.76500E-10	1.01509
912.511	0.988994	15.4054	4.84500E-10	1.01853
917.411	0.992217	15.6089	4.92500E-10	1.01947
922.511	1.00319	15.8142	5.04500E-10	1.01671
927.411	0.990848	16.0113	5.04500E-10	1.01758
932.411	1.00485	16.2576	5.19500E-10	1.01854
937.511	0.989939	16.5025	5.19500E-10	1.01873
942.511	1.00848	16.6979	5.35500E-10	1.01633
947.411	0.993898	16.943	5.35500E-10	1.01472
952.411	1.00968	17.1764	5.51500E-10	1.01776
957.511	0.996836	17.3978	5.51500E-10	1.01411
962.411	0.98469	17.6124	5.51500E-10	1.01714
967.511	0.996256	17.8814	5.66500E-10	1.01667
972.411	0.982222	18.1359	5.66500E-10	1.0163
977.511	0.997234	18.3684	5.82500E-10	1.01407
982.511	0.982514	18.6436	5.82500E-10	1.01569
987.411	0.996951	18.8783	5.98500E-10	1.01447
992.511	0.984235	19.1222	5.98500E-10	1.01593
997.411	0.994553	19.3981	6.13500E-10	1.01485
1002.51	1.00451	19.7067	6.29500E-10	1.01322
1007.41	0.992066	19.9539	6.29500E-10	1.01619
1012.51	0.978923	20.2218	6.29500E-10	1.01656
1017.51	0.989875	20.4746	6.44500E-10	1.01477
1022.51	1.00037	20.7627	6.60500E-10	1.01382
1027.51	0.985422	21.0777	6.60500E-10	1.0133
1032.51	0.996108	21.3567	6.76500E-10	1.01532
1037.51	0.983449	21.6316	6.76500E-10	1.01525
1042.51	0.99126	21.937	6.91500E-10	1.01611
1047.51	0.977839	22.2381	6.91500E-10	1.01561
1052.51	0.98812	22.5159	7.07500E-10	1.01427
1057.41	0.996486	22.8318	7.23500E-10	1.0116
1062.51	0.982861	23.1483	7.23500E-10	1.01388
1067.41	0.988257	23.4992	7.38500E-10	1.01498
1072.41	0.997075	23.796	7.54500E-10	1.01336
1077.31	0.983698	24.1196	7.54500E-10	1.01409
1082.41	0.988804	24.4721	7.69500E-10	1.0117
1087.31	0.99687	24.7788	7.85500E-10	1.01491
1092.41	0.984541	25.0891	7.85500E-10	1.01313
1097.41	0.990828	25.4377	8.01500E-10	1.01396
1102.41	0.993822	25.8357	8.16500E-10	1.01362
1107.41	0.980662	26.1824	8.16500E-10	1.01259
1112.31	0.987638	26.5069	8.32500E-10	1.01258
1117.31	0.992148	26.8773	8.48500E-10	1.01146
1122.41	0.978904	27.2574	8.48500E-10	1.01226
1127.31	0.982533	27.6368	8.63500E-10	1.0128
1132.41	0.987359	28.0113	8.79500E-10	1.0129
1137.41	0.973938	28.3973	8.79500E-10	1.01154
1142.41	0.976926	28.7933	8.94500E-10	1.01171
1147.41	0.981639	29.1676	9.10500E-10	1.01161
1152.31	0.985413	29.5665	9.26500E-10	1.0113
1157.31	0.987371	29.9856	9.41500E-10	1.01301
1162.41	0.974549	30.3801	9.41500E-10	1.01203
1167.31	0.977739	30.7956	9.57500E-10	1.01124

SUMS DYN CAL NOM CASE 1




LOG10 OF ION CURRENT

SUMS DYNAMIC CALIBRATION
NOMINAL CASE 1




SUMS DYN CAL NOM CASE 2




LOG10 OF ION CURRENT

SUMS DYNAMIC CALIBRATION
NOMINAL CASE 2




SUMS DYN CAL NOM CASE 3




LOG10 OF ION CURRENT

SUMS DYNAMIC CALIBRATION
NOMINAL CASE 3




SUMS DYN CAL +25% CASE 1




LOG10 OF ION CURRENT

SUMS DYNAMIC CALIBRATION
+25% CASE 1




SUMS DYN CAL +25% CASE 2



LOG10 OF ION CURRENT

SUMS DYNAMIC CALIBRATION
+25% CASE 2



SUMS COMPOSITION CHANGE CALIBRATION
DATA TAPE FORMAT
(300 SERIES)

0	COMMENTS	(72 CHARACTERS)	50	TYPE I	SIZE 50
1	TIME	(SECONDS)	240	TYPE S	SIZE 120
2	INLET P. XDUCER	(VOLTS)	240	TYPE S	SIZE 120
3	BARATRON PRESS.	(TORR)	240	TYPE S	SIZE 120
4	UAMS HSK WORDS (2)	(16 BIT DECIMAL)	240	TYPE I	SIZE 120.2
5	AMU 32 (6 SAMPLES)	(9 BIT DECIMAL)	720	TYPE I	SIZE 120.6
6	AMU 32 (2ND HIGHEST)	(9 BIT DECIMAL)	120	TYPE I	SIZE 120
7	AMU 28 (6 SAMPLES)	(9 BIT DECIMAL)	720	TYPE I	SIZE 120.6
8	AMU 28 (2ND HIGHEST)	(9 BIT DECIMAL)	120	TYPE I	SIZE 120
9	AMU 16 (6 SAMPLES)	(9 BIT DECIMAL)	720	TYPE I	SIZE 120.6
10	AMU 16 (2ND HIGHEST)	(9 BIT DECIMAL)	120	TYPE I	SIZE 120
11	AMU 14 (6 SAMPLES)	(9 BIT DECIMAL)	720	TYPE I	SIZE 120.6
12	AMU 14 (2ND HIGHEST)	(9 BIT DECIMAL)	120	TYPE I	SIZE 120

ORIGINAL PAGE IS
OF POOR QUALITY

DATA COLLECTION TIMING OFFSETS FOR COMPOSITION CHANGE CALIBRATION

3-23-82

General:

During the SUMS Composition Change Calibration various data is read and stored on tape once every five seconds. One of the values stored is the reading of the HP85 real time clock. This clock is initially set to zero at the beginning of each calibration run. Since the HP85 is a serial machine, timing offsets arise between the time the clock is read, and the time other data is collected. This paper describes these offsets.

Definitions:

Let T_n be the value read from the clock for a given five second group of data. (The "Nth" group)

Note that the clock has an accuracy of ± 1 msec (for the duration of each run) and a resolution of 1 msec. However, due to data tape space restrictions, T_n , as recorded, is rounded off to the nearest 0.1 seconds.

Offset Values:

- 1) Clock Read = T_n (to 0.1 sec resolution)
- 2) SUMS Inlet Pressure Transducer = $T_n + .052$ seconds
- time measured to "TRIGGER" command.
- 3) Baratron Pressure = $T_n + .102$ seconds
- 4) Peak Data

For simplicity, assume that the time at which the 9 bit science word for a particular scan step number emerges from SUMS, is the same time as which it was sampled by the UAMS sensor. That is, ignore all delays due to buffering of data by UAMS and SUMS, and the uncertainties introduced due to the asynchronous interface with the PCM. This should introduce an error, conservatively estimated at no greater than 100 msec.

Given the above, the time offset for a given scan step number (SSN) is:

$$T_{ssn} (SSN) = -[(222-SSN) * .0135] - .977 \text{ seconds}$$

ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

Peak Data continued ...

Assuming peak center scan step numbers of:

80 for AMU 32
101 for AMU 28
194 for AMU 16
215 for AMU 14

The offsets will be:

$T_{ssn} (80) = -2.8940 \text{ second, (AMU 32)}$
 $T_{ssn} (101) = -2.6105 \text{ second, (AMU 28)}$
 $T_{ssn} (194) = -1.3550 \text{ second, (AMU 16)}$
 $T_{ssn} (215) = -1.0715 \text{ second, (AMU 14)}$

NOTE:

Tables of Corrected Time, Pressure and
Current of 28 and 32 Peaks

†

Corrected Ion Current vs. Time

To be supplied at a later date under
separate cover.

G. Robertson
3/23/82

RELIABILITY		R E V I S I O N S			CONFIG MGT
APPD	PREDICTION	LTR	DESCRIPTION	DATE	APPV'D
		-	STD RELEASE - ER-1973-62	1/18/82	C. MILLER

ORIGINAL PAGE IS
OF POOR QUALITY

SUMS Calibration Procedure
(Static, Dynamic and Composition Change)

As-Run

DRAWING AND PART APPLICATION			
PART NO.	NEXT ASSY	END ITEM NO.	SERIAL NO.
TP3290648	-	3290600	-

SUMS S/N 1
UAMS S/N 6
Date 1/19/82 (start)
T/C G. Robertson

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES.	CONTR NO.		THE BENDIX COMMUNICATIONS DIVISION	
	DRAWN	ROBERTSON 1-12-82	AEROSPACE SYSTEMS OPERATIONS - ANN ARBOR, MICHIGAN	
MATERIAL:	CHECKED	ROBERTSON 1-18-82	TITLE	
	STRESS/WT		SUMS Calibration Procedure	
DRAWING CLASS	DSGN SUPV	J.D.	SIZE	CODE IDENT NO.
	PROJ ENGR	Robertson 1-18-82	A	07038
A <input type="checkbox"/> B <input type="checkbox"/> C <input type="checkbox"/>	QUAL CONT		DRAWING NUMBER	REV
	SYS SPT		TP3290648	X B
	DSGN APPL	G. Robertson 1-18-82	SCALE	WEIGHT
	MFG		SHEET 1 OF 63	
	CUSTOMER			

ORIGINAL PAGE IS
OF POOR QUALITY

1.0 PURPOSE

The purpose of this test is to determine the instrument sensitivity to specific gases, the dynamic response of the inlet system and to determine the time response to gas composition changes at selected pressures.

2.0 SCOPE

This procedure specifies the test methods, test equipment and data to be recorded to effect the calibration of the SUMS instrument.

3.0 APPLICABLE DOCUMENTS

3290635 Performance and Design Requirements Specification
TP2374339 Calibration Station Molecular Leak Test Procedure
BSR 4400 Test Plan for SUMS.

4.0 PARTICIPANTS REQUIRED

Bendix Engineering Representative
Quality Engineering Representative (optional)
NASA Representative.

5.0 EQUIPMENT REQUIRED

Item	Manufacturer	Part Number or Model	Qty	Serial No.	Calib. Due Date
UAMS Test Set (Small)	BxA	2373400	1	N/A	N/A
Calibration Stand	BxA	N/A	1	N/A	N/A
Nitrogen	Matheson	Research Purity	AR	N/A	N/A
Oxygen	Matheson	Research Purity	AR	N/A	N/A
Test Gas	Union Carbide	80% N ₂ , 20% O ₂	1	71444/24 (5-20-81)	N/A
MKS Baratron Pressure Meter	MKS Inst.	210	1	17020C	N/A
Pressure Gauge 0.1-20 mm Hg	Wallace & Tiernan	FA160	1	66123	N/A
Pressure Gauge 0-50 mm Hg	Wallace & Tiernan	FA160	1	66126	N/A
Pressure Gauge 0-200 mm Hg	Wallace & Tiernan	FA160	1	66125	N/A
Pressure Gauge 0-800 mm Hg	Wallace & Tiernan	FA160	1	66124	N/A

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
—

SCALE

WEIGHT

SHEET 2

ORIGINAL PAGE 13
OF POOR QUALITY

Item	Manufacturer	Part Number or Model	Qty	Serial No.	Calib. Due Date
Ion Gauge Controller (Plenum chamber)	Varian	971-1008	1	66130	11-26-81
Ion Gauge Controller (Calibration chamber)	Varian	971-1008	1	66131	11-26-81
Ion Gauge (Plenum chamber)	Varian	971-5008	1	---	---
Ion Gauge (Calibration chamber)	Varian	971-5008	1	---	---
Ion Pump Controller (Calibration station)	Varian	921-0066	1	66141	N/A
Ion Pump Controller (Gas manifold system)	Varian	921-0062	1	---	N/A
Calculator	HP	9830A	1	N/A	N/A
Printer	HP	9866A	1	N/A	N/A
Calculator Plotter	HP	9862A	1	N/A	N/A
Cassette Memory	HP	9865A	1	N/A	N/A
SUMS GSE Interface Unit	BxA	N/A	1	N/A	N/A
1 Torr Baratron Head	MKS	310BHS-1	1	---	N/A
100 Torr Baratron Head	MKS	310BHS-100	1	---	N/A
Servo Valve	MKS	245	1	---	N/A
Servo Valve Controller	MKS	244A	1	---	N/A
Range Multiplier	MKS	170M-6C	1	---	N/A
Digital Readout Unit	MKS	170M-270	1	---	N/A
Head Selector	MKS	170M-34C	1	---	N/A
Data Logger	Fluke	2240C	1	---	---

Equivalent items may be substituted. These and any additional items must be listed below prior to testing.

DVM	Fluke	8022A	1	52445	4-16-82
Chart Recorder	HP	299A	1	16266	N/A
Flow Meters	Union-Carbide	201-4336	2	---	---

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
—

SCALE

WEIGHT

SHEET 3

6.0 PROCEDURE

ORIGINAL PAGE 12 WARNING OF POOR QUALITY

Never turn on SUMS instrument power without first verifying sensor pressure is less than 3×10^{-4} Torr. Higher pressures will reduce filament life and may cause burnout.

NOTES:

1. The analysis of data required in this TP is not a constraint upon continuation of testing.
2. During this test it is required that the molecular leaks be calibrated per TP2374339.
3. To insure that valid data is taken during this test; the printer, strip chart recorder, oscilloscope, and DVM may be used at any time at the direction of the test conductor.

6.1 STATIC CALIBRATION

6.1.1 Test Set-Up

6.1.1.1 Verify that the SUMS instrument is mounted onto the calibration station, via the inlet simulator and that equipment is connected in accordance with Figure 1.

6.1.1.2 Verify or connect thermocouples to each of the following four areas. Also record channels on the Fluke data logger which will record these temperatures.

Vacuum station near inlet simulator.
Channel number

11

SUMS inlet system tube near inlet simulator.
Channel number

12

Calibration panel large leak.
Channel number

13

Calibration panel variable volume
Channel number

14

6.1.1.3 Turn on Fluke data logger and verify all thermocouples are giving valid readings.

Vacuum station near 50/101/sec.
Channel number

15

75.0°F

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
—

SCALE

WEIGHT

SHEET 4

ORIGINAL PAGE 13
OF POOR QUALITY




Figure 1 - Calibration System Gas Schematic

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP 3290648	REV 1
SCALE	WEIGHT	SHEET 5	

6.1.1.4 Verify or perform interconnection of SUMS and GSE in accordance with Figure 2. ✓

6.1.1.5 Verify or turn ON the power for each Ion Gauge Controller. ✓

6.1.2 SUMS and Inlet Simulator Pump Down

6.1.2.1 Verify that the calibration chamber pressure is $\leq 1 \times 10^{-6}$ torr. Record reading. ✓ Torr

~~8.5×10^{-8}~~
 4×10^{-8}

Verify or perform the following:

6.1.2.2 Using the cryopump and Ion Pump, pump down the inlet simulator to $\leq 1 \times 10^{-5}$. Record reading from calibration chamber pressure gauge. ✓ Torr

PRESSURE DROPPED WHEN INLET TO MKS VALVE WAS EVACUATED (V30 CLOSED, V31 OPEN) ~~8.5×10^{-8}~~
 4×10^{-8}




Figure 2 - Test Configuration

THE BENDIX COMMUNICATIONS DIVISION AEROSPACE SYSTEMS OPERATIONS ANN ARBOR, MICHIGAN	SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP3290648	REV —
	SCALE	WEIGHT	SHEET 6	

ORIGINAL PAGE IS
OF POOR QUALITY

Calibration Station
Molecular Leak Test Procedure
for the Viking UAMS



VALVE
TERMINAL
BLOCKS

WALL
TERMINAL
BLOCKS



micrometers

TC LINE

V1 LINE

V2 LINE

V3 LINE

V4 LINE

V5 LINE

V6 LINE

V7 LINE

V8 LINE

V9 LINE

V10 LINE

V11 LINE

V12 LINE

V13 LINE

V14 LINE

V15 LINE

V16 LINE

V17 LINE

V18 LINE

V19 LINE

V20 LINE

V21 LINE

V22 LINE

V23 LINE

V24 LINE

V25 LINE

V26 LINE

V27 LINE

V28 LINE

V29 LINE

V30 LINE

V31 LINE

V32 LINE

V33 LINE

V34 LINE

V35 LINE

V36 LINE

V37 LINE

V38 LINE

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
1

SCALE

WEIGHT

SHEET 7

FOR REFERENCE ONLY

ORIGINAL PAGE 18
OF POOR QUALITY

6.1.2.3 Pump down liquid helium pump. ✓

6.1.2.4 Close off liquid helium pump. ✓

6.1.2.5 Adjust the zero, span and full scale settings on the MKS baratrons and the MKS control valve. ✓

6.1.3 Initial Test Equipment Adjustments

6.1.3.1 Set the clock source switch on the upper panel of the UAMS test set to "CLK EXT". ✓

6.1.3.2 Set the power configuration switch on the lower panel of the UAMS test set to "SUMS" ✓

6.1.3.3 Move the "Instrument" and "Test Set" power switches on the lower panel of the UAMS test set to the ON position. ✓

6.1.3.4 Set the two power supplies in the lower panel of the UAMS test set to 28.0 V. This voltage may be measured at the terminals on the front of each supply.

Instrument
Ion Pump

28.2 V
28.2 V

6.1.3.5 Verify that the inlet system is connected to the SUMS electronics package. ✓

6.1.3.6 Verify that the valve control select switch on the GSE I/F is in the "GSE" position and that all valve switches are in the "CLOSED" position. ✓

WARNING

Never operate the valves unless the SUMS instrument is connected to a vacuum station. Exposure of the mass sensor to pressures in excess of 1×10^{-5} Torr may cause instrument contamination and/or filament damage.

6.1.3.7 Turn on the GSE I/F unit power. ✓

6.1.3.8 On the UAMS test set upper panel, push the number of frames switch until "CNT" lights. Push the "RESET" button. Push the START/DECODE switch to begin sending shift and enable pulses. ✓

6.1.3.9 Record the GSE I/F hour meter readings.

Power A 4396.8 hrs
Power B 6391.4 hrs

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
—

SCALE

WEIGHT

SHEET 8

ORIGINAL PAGE IS
OF POOR QUALITY

6.1.3.10 Connect the test set to the calculator using the special HP cable. ✓

6.1.3.11 Verify the Plotter and Cassette Memory are connected to the calculator. ✓

6.1.3.12 Turn ON the Calculator, Printer, Plotter and Cassette Memory. ✓

6.1.4 Calibration, General Instructions

6.1.4.1 When a new gas is let into the gas-inlet system the system first must be evacuated per paragraph 6.6 of TP2374339. ✓

6.1.4.2 Whenever a gas is changed set the emission current of the plenum ionization gauge below the orifice plate so that its reading agrees with that of the ionization gauge in the calibration chamber. This can be done when equilibrium is achieved anywhere in the indicated range of 10^{-5} torr \pm 50% with both pumps shut off, the butterfly valve in the open position and the inlet valves closed. ✓

NOTE: Nowhere in this procedure is pressure to be determined from ionization gauge readings. This step of the procedure is performed only to permit determination of the pressure ratio across the calibrated orifice so that small corrections can be made to the more accurate pressure determinations of this section. However, ionization gauge readings may be used as a tool to achieve approximate pressure settings.

6.1.4.3 Chamber pressure is calculated according to the equation

$$P_c = \frac{P_G S_L}{S_o (1 - \frac{I_p}{I_c})} \frac{T_c}{T_s}$$

where: P_c = chamber pressure, Torr
 P_G = Gauge Pressure of upstream gas, Torr
 S_L = Leak conductance in liters/sec. as determined per TP2374339
 I_p = I-gauge reading in the plenum below orifice plate
 I_c = Chamber I-gauge reading
 S_o = Orifice conductance in liters/sec.
 T_c = Chamber temperature in °K or °R
 T_s = Displacement meter temperature in same units as T_c .

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
—

SCALE

WEIGHT

SHEET 9

Values of S_o in liters/sec. are tabulated below:

Gas	AMU	Small Orifice			Large Orifice		
		-40°F	+77°F	+100°F	-40°F	+77°F	+100°F
N ₂	28	8.842	10.00	10.21	44.17	49.95	51.01
O ₂	32	8.271	9.354	9.551	41.32	46.72	47.71

At any other temperature, $T(^{\circ}\text{F})$, the conductance can be calculated from the equation

Variation

$$S_T = S_{77} \left(\frac{T + 459.4}{536.4} \right)^{\frac{1}{2}}$$

where

S_T = Orifice conductance at temperature T .

S_{77} = Orifice conductance at 77°F (25°C)

6.1.4.4 Calibration chamber pressure stabilization. Before taking any science data with the instrument, the pressure in the calibration chamber as determined by its ionization gauge must have been stable for at least 8 minutes.

ORIGINAL PAGE IS
OF POOR QUALITY

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP3290648	REV —
SCALE	WEIGHT	SHEET 10	

6.1.5 Nitrogen Gas Calibration

The SUMS instrument will be calibrated over a pressure range from 1×10^{-6} torr to 20 torr. In order to achieve this dynamic range, the SUMS instrument and the calibration are operated in several configurations. For those pressures at the inlet of 1×10^{-3} torr and below the range valve on the SUMS instrument is open. Above 1×10^{-3} torr the range valve is closed. In order to protect the SUMS instrument the instrument should never be exposed to an inlet pressure greater than 1.2×10^{-3} with the range valve open. The calibration system operates as a dynamic flow through system up to 10^{-2} torr. For pressures up to and including 10^{-5} torr the system is pumped through the 50 l/s orifice and the pressures are determined by the known calibrated leak and corrections calculated from the ion gauge readings. Above 10^{-3} torr to 3×10^{-4} torr, the system is pumped by the 10 l/s orifice. From 10^{-3} torr to 10^{-2} torr the calibrated leak is no longer used, and the gas is admitted via the MKS valve into the inlet plenum which has been partially isolated via the throttling valve. The pressure is measured via the 1 torr baratron head. The ion pump is still operating. From 3×10^{-2} torr to 20 torr the pressure is set statically using the MKS valve. The ion pump is off and the pressure is read using the 1 torr and 100 torr baratrons as appropriate.

6.1.5.1 CALIBRATE THE LARGE VIKING INLET LEAK FOR NITROGEN PER TP2374339. RECORD VALUE HERE.

5.16 x 10⁻⁶ LITERS/SEC

5.14 x 10⁻⁶ @ 43.5 Torr
5.17 x 10⁻⁶ @ 44.2 Torr

(ave of 40 Torr)
400 Torr run.)

6.1.5.2 CLOSE VALVE V38.

6.1.5.3 VERIFY OR EVACUATE THE GAS INLET SYSTEM PER PARAGRAPH 6.6 OF TP2374339. VERIFY THROTTLING VALVE AT SUMS PLENUM IS OPEN

6.1.5.4 VERIFY THAT VALVE V1 IS NOW CLOSED.

6.1.5.5 VERIFY THAT THE REGULATOR AND VALVES ON THE NITROGEN TANK HAVE BEEN PROPERLY FLUSHED WITH NITROGEN AND THAT THE GAS SUPPLY LINE BETWEEN THE BLACK VALVE AND THE CALIBRATION STAND INLET IS NOW EVACUATED.

6.1.5.6 ADJUST ION GAGES PER PARAGRAPH 6.1.4.2

6.1.5.7 PUMP THE CALIBRATION CHAMBER DOWN TO A PRESSURE $\leq 2 \times 10^{-8}$ TORR. RECORD THE PRESSURE.

6.7 x 10⁻⁸ TORR

w/ 50 l/sec

6.1.5.8 TURN ON THE "SUMS ION PUMP POWER".

6.1.5.9 OPEN THE SUMS INLET, RANGE AND PROTECTION VALVES.

6.1.5.10 VERIFY THE INSTRUMENT SENSOR INTERNAL PRESSURE IS LESS THAN OR EQUAL TO 1×10^{-5} TORR.

6.1.5.11 TURN ON THE "SUMS INSTRUMENT POWER".

6.1.5.12 VERIFY THAT THE NITROGEN STATIC CALIBRATION TAPE IS INSERTED IN THE HP9838 CALCULATOR.

ORIGINAL PAGE IS
OF POOR QUALITY

Valve positions
prior to taking
of residual data.

OPEN: V2, V5, V6,
V7, V8, V11, V12, V21,
V22, V31

CLOSED: V1, V3, V4,
V9, V10, V13, V14, V30

large orifice
used (50 l./sec)

THE BENDIX CORPORATION
Aerospace Systems Operations
ANN ARBOR, MICHIGAN

SIZE

A

CODE IDENT NO.

07038

DRAWING NUMBER

TP3290648

REV

-

SCALE

WEIGHT

SHEET

11

6.1.5.13 WAIT 30 MINUTES MINIMUM FOR THE INSTRUMENT ION SOURCE TEMPERATURE TO STABILIZE.

✓ power on at 8:10 Hrs
1-20-82

6.1.5.14 RECORD THE CALIBRATION CHAMBER AND THE GAS INLET SYSTEM TEMPERATURES USING THE FLUXE DATA LOGGER.

T12 CALIBRATION CHAMBER 76.8 DEG F
T13 GAS INLET SYSTEM 72.5 DEG F

T11 77.3
T14 77.5
T15 83.3

6.1.5.15 VERIFY THE SPECIAL CONDITIONS OF TABLE 6.1.5.1 HAVE BEEN SET.

6.1.5.16 ON THE HP9830 TYPE LOAD 0, EXECUTE, FOLLOWED BY RUN, EXECUTE. THE PROGRAM IS INTERACTIVE. BE CERTAIN TO COMPLY WITH ALL CALCULATOR REQUESTS THROUGHOUT THE TEST.

6.1.5.17 VERIFY THAT THE CHAMBER PRESSURE AS READ ON THE ION GUAGE HAS BEEN STABLE FOR AT LEAST 8 MINUTES.

6.1.5.18 FILL IN THE REQUESTED DATA IN TABLE 6.1.5.1 AND TABLE 6.1.5.6 AS THE FOLLOWING STEPS ARE PERFORMED:

PRESS
(TORR)

CHAMBER PRESS
STABILIZED

RECORD
ION PUMP

DATA
TAKEN

RESIDUALS

ORIGINAL PAGE IS
OF POOR QUALITY

BE CERTAIN NOT TO PROCEED UNTIL THE HP9830 HAS TAKEN DATA FOR BOTH FILAMENTS.

6.1.5.19 VERIFY THAT VALVES V6, V7, V8, V11, V12, V21 AND V22 ARE OPEN.

6.1.5.20 CLOSE VALVE V10 AND REMOVE THE KNOB.

6.1.5.21 VERIFY OR CLOSE VALVES V2, V4, V9, V13 AND V14.

6.1.5.22 CLOSE VALVE V3.

6.1.5.23 OPEN BLACK VALVE AT NITROGEN TANK.

6.1.5.24 OPEN VALVE V4.

6.1.5.25 TAKING DATA FOR A GIVEN PRESSURE POINT IS A FOUR STEP PROCESS. THESE STEPS ARE: 1) SET THE PRESSURE; 2) WATCH THE CALIBRATION CHAMBER ION GUAGE AND DO NOT PROCEED UNTIL THE PRESSURE IS STABLE FOR AT LEAST 8 MINUTES; 3) RECORD INSTRUMENT ION PUMP CURRENT MONITOR VOLTAGE (AS READ FROM UHMS TEST SET) IN TABLE 6.1.5.6; 4) LET THE HP9830 CALCULATOR TAKE DATA FOR BOTH FILAMENTS.

SETTING A PRESSURE IS ACCOMPLISHED BY SLOWLY OPENING VALVE V3 UNTIL THE DESIRED PRESSURE IS REACHED ON THE WALLACE & TIERNAN GAUGES. THEN CLOSE VALVES V3 AND V4 AND ALLOW AT LEAST 8 MINUTES AFTER THE PRESSURE ON THE ION GUAGE HAS STABILIZED.

THE BENDIX CORPORATION
Aerospace Systems Operations
ANN ARBOR, MICHIGAN

SIZE

A

CODE IDENT NO.

07038

DRAWING NUMBER

TP3290648

REV

-

SCALE

WEIGHT

SHEET 12

FILL IN THE REQUESTED DATA IN TABLE 6.1.5.1 AS THE FOLLOWING STEPS ARE PERFORMED:

ORIGINAL PAGE IS
OF POOR QUALITY

PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
1X10-6	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
3X10-6	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1X10-5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

valve V21 closed

WHEN ALL DATA HAS BEEN TAKEN FOR THE ABOVE THREE PRESSURE POINTS PROCEED TO THE NEXT STEP.

6.1.5.26 VERIFY THAT THE CRYO PUMP IS STILL COLD. ✓

6.1.5.27 REDUCE THE PRESSURE UPSTREAM OF THE LARGE VIKING LEAK BY OPENING VALVES V4 AND V1. WHEN THE PRESSURE ON THE WALLACE & TIERNAN GAUGES HAS BEEN REDUCED TO LESS THAN 48 TORR CLOSE VALVE V1 AND PROCEED. ✓

6.1.5.28 SWITCH IN THE SMALL ORIFICE (10 LITERS/SEC) AND VERIFY THE SPECIAL CONDITIONS OF TABLE 6.1.5.2. ✓

6.1.5.29 CONTINUE FOR THE NEXT THREE PRESSURE POINTS AS LISTED IN TABLE 6.1.5.2, SETTING THE PRESSURE AGAIN BY FIRST OPENING VALVE V4, SLOWLY OPENING VALVE V3 TO OBTAIN THE DESIRED PRESSURE, THEN CLOSING BOTH V3 AND V4. BE SURE TO STABILIZE THE PRESSURE PER PARAGRAPH 6.1.4.4. MONITOR THE ION PUMP CURRENT AND TURN THE INSTRUMENT POWER OFF IF THE MONITOR EXCEEDS 50MV. RECORD DATA IN TABLE 6.1.5.2 AS THE FOLLOWING STEPS ARE PERFORMED:

PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
3X10-5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1X10-4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
3X10-4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Variation.

open V21, V1, V4 and pump down inlet system. ✓

6.1.5.30 CLOSE OFF THE VIKING INLET LEAK BY CLOSING VALVES V11 AND V12 AND SET THE SPECIAL CONDITIONS LISTED IN TABLE 6.1.5.3.

6.1.5.31 CONTINUE FOR THE NEXT PRESSURE POINT AS LISTED IN TABLE 6.1.5.3. THE PRESSURE IS NOW SET BY USING THE MKS SERVO VALVE AND ITS CONTROLLER. THE VALVE INPUT CONTROL IS SET UNTIL THE MKS DIGITAL READOUT SHOWS THE DESIRED PRESSURE. BE SURE TO WAIT AT LEAST 8 MINUTES FOR THE PRESSURE TO STABILIZE. MONITOR THE ION PUMP CURRENT AND TURN THE INSTRUMENT POWER OFF IF THE MONITOR EXCEEDS 50MV. RECORD DATA IN TABLE 6.1.5.3 AS THE FOLLOWING STEPS ARE PERFORMED:

Variation

After reaching the desired pressure, "freeze" the servo valve.

THE BENDIX CORPORATION
Aerospace Systems Operations
ANN ARBOR, MICHIGAN

SIZE	CODE IDENT NO.	DRAWING NUMBER	REV
A	07038	TP3290648	—
SCALE	WEIGHT	SHEET	13

Baratron heads were re-zeroed at this point when chamber pressure was 4×10^{-8} Torr and throttling valve was open.

PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
3×10^{-3}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Variation

6.1.5.32 CLOSE THE SUMP RANGE VALVE AND SET THE SPECIAL CONDITIONS LISTED IN TABLE 6.1.5.4.

← do not do at this time.

6.1.5.33 CONTINUE FOR THE NEXT TWO PRESSURE POINTS AS LISTED IN TABLE 6.1.5.4. THE PRESSURE IS AGAIN SET WITH THE MKS SERVO VALVE AND ITS CONTROLLER. MONITOR THE ION PUMP CURRENT AND TURN THE INSTRUMENT POWER OFF IF THE MONITOR EXCEEDS 50MV. RECORD DATA IN TABLE 6.1.5.4 AS THE FOLLOWING STEPS ARE PERFORMED:

← servo valve controller left in loop this time.

PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
3×10^{-3}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1×10^{-2}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Variation

range valve closed when pressure was raised to 4.8×10^{-3} Torr.

6.1.5.34 CLOSE THE MKS INLET VALVE AND SET THE SPECIAL CONDITIONS LISTED IN TABLE 6.1.5.5.

Range valve was then manually reopened and pressure was reduced to 4.60×10^{-3} and data was taken.

6.1.5.35 CONTINUE FOR THE NEXT SEVEN PRESSURE POINTS AS LISTED IN TABLE 6.1.5.5. THE PRESSURES ARE NOW SET STATICLY BY MANUALLY OPENING THE MKS VALVE UNTIL THE DESIRED PRESSURE IS OBTAINED AND THEN CLOSING THE VALVE. BE SURE TO WAIT 8 MINUTES FOR THE PRESSURE TO STABILIZE. MONITOR THE ION PUMP CURRENT AND TURN THE INSTRUMENT POWER OFF IF THE MONITOR EXCEEDS 50MV. RECORD DATA IN TABLE 6.1.5.5 AS THE FOLLOWING STEPS ARE PERFORMED:

PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
3×10^{-2}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1×10^{-1}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
3×10^{-1}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
20	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
32.72	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Variation

ion pump (cal. chamber) left on
10 liter/sec orifice used
ion pump off but MKS valve left slightly open to stabilize pressure

6.1.5.36 CLOSE OFF NITROGEN SUPPLY.

6.1.5.37 USING THE CYROPUMP, REDUCE THE CALIBRATION CHAMBER PRESSURE TO 50 MICRONS OR LESS.

ORIGINAL PAGE IS OF POOR QUALITY

6.1.5.38 TURN ON THE MAIN ION PUMP AND REDUCE PRESSURE TO 1×10^{-6} TORR OR LESS.

THE BENDIX CORPORATION
Aerospace Systems Operations
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
—

SCALE

WEIGHT

SHEET 14

6.1.5.39 OPEN THE SUMS RANGE VALVE.

6.1.5.40 TURN THE SUMS INSTRUMENT POWER OFF.

END OF NITROGEN CALIBRATION

ORIGINAL PAGE IS
OF POOR QUALITY

6.1.6 OXYGEN GAS CALIBRATION

THE OXYGEN CALIBRATION IS SIMILAR TO THE NITROGEN CALIBRATION EXCEPT THE ION SOURCE PRESSURE SHOULD NOT EXCEED 2×10^{-5} TORR. THIS PRESSURE IS INDICATED WHEN THE ION PUMP CURRENT MONITOR AS READ ON THE UMS TEST SET EXCEEDS ABOUT 7 MV.

- 6.1.6.1 CALIBRATE THE LARGE VIKING INLET LEAK FOR OXYGEN PER TP2374339. RECORD VALUE HERE. 4.85×10^{-6} LITERS/SEC (AVE.) 4.85×10^{-6} @ 43.85 Torr
- 6.1.6.2 CLOSE VALVE V30. 4.87×10^{-6} @ 75.2 °F
- 6.1.6.3 VERIFY OR EVACUATE THE GAS INLET SYSTEM PER PARAGRAPH 6.6 OF TP2374339. VERIFY THROTTLING VALVE AT SUMS PLENUM IS OPEN. @ 75.3 °F
- 6.1.6.4 VERIFY THAT VALVE V1 IS NOW CLOSED.
- 6.1.6.5 VERIFY THAT THE REGULATOR AND VALVES ON THE OXYGEN TANK HAVE BEEN PROPERLY FLUSHED WITH OXYGEN AND THAT THE GAS SUPPLY LINE BETWEEN THE BLACK VALVE AND THE CALIBRATION STAND INLET IS NOW EVACUATED.
- 6.1.6.6 ADJUST ION GAGES PER PARAGRAPH 6.1.4.2
- 6.1.6.7 PUMP THE CALIBRATION CHAMBER DOWN TO A PRESSURE $\leq 2 \times 10^{-8}$ TORR. RECORD THE PRESSURE. 6.4×10^{-8} TORR
- 6.1.6.8 TURN ON THE "SUMS ION PUMP POWER".
- 6.1.6.9 OPEN THE SUMS INLET, RANGE AND PROTECTION VALVES.
- 6.1.6.10 VERIFY THE INSTRUMENT SENSOR INTERNAL PRESSURE IS LESS THAN OR EQUAL TO 1×10^{-5} TORR.
- 6.1.6.11 TURN ON THE "SUMS INSTRUMENT POWER".
- 6.1.6.12 VERIFY THAT THE OXYGEN STATIC CALIBRATION TAPE IS INSERTED IN THE HP9830 CALCULATOR.

Variation

no adjustment
necessary

w/ 50 liter/sec !
set up per table
6.1.6.1

THE BENDIX CORPORATION
Aerospace Systems Operations
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP3290648	REV 1
SCALE	WEIGHT	SHEET 15	

6.1.6.13 WAIT 20 MINUTES MINIMUM FOR THE INSTRUMENT ION SOURCE TEMPERATURE TO STABILIZE. ✓

6.1.6.14 RECORD THE CALIBRATION CHAMBER AND THE OAS INLET SYSTEM TEMPERATURES USING THE FLUXE DATA LOGGER.

T12 CALIBRATION CHAMBER 75.3 DEG F
T13 OAS INLET SYSTEM 76.4 DEG F

T11 76.2
T14 75.9
T15 82.4

6.1.6.15 VERIFY THE SPECIAL CONDITIONS OF TABLE 6.1.6.1 HAVE BEEN SET. ✓

6.1.6.16 ON THE HP9830 TYPE LOAD 8, EXECUTE, FOLLOWED BY RUN, EXECUTE. THE PROGRAM IS INTERACTIVE. BE CERTAIN TO COMPLY WITH ALL CALCULATOR REQUESTS THROUGHOUT THE TEST. ✓

6.1.6.17 VERIFY THAT THE CHAMBER PRESSURE AS READ ON THE ION GUAGE HAS BEEN STABLE FOR AT LEAST 8 MINUTES. ✓

6.1.6.18 FILL IN THE REQUESTED DATA IN TABLE 6.1.6.1 AND TABLE 6.1.6.5 AS THE FOLLOWING STEPS ARE PERFORMED:

PRESS
(TORR)

CHAMBER PRESS
STABILIZED ✓

RECORD
ION PUMP ✓

DATA
TAKEN ✓

RESIDUALS

BE CERTAIN NOT TO PROCEED UNTIL THE HP9830 HAS TAKEN DATA FOR BOTH FILAMENTS.

ORIGINAL PAGE IS
OF POOR QUALITY

6.1.6.19 VERIFY THAT VALVES V6, V7, V8, V11, V12, V21 AND V22 ARE OPEN. ✓

6.1.6.20 CLOSE VALVE V10 AND REMOVE THE KNOB. ✓ (already closed)

6.1.6.21 VERIFY OR CLOSE VALVES V2, V4, V9, V13 AND V14. ✓ (all already closed)

6.1.6.22 CLOSE VALVE V3. ✓

6.1.6.23 OPEN BLACK VALVE AT OXYGEN TANK. ✓

6.1.6.24 OPEN VALVE V4. ✓

6.1.6.25 TAKING DATA FOR A GIVEN PRESSURE POINT IS A FOUR STEP PROCESS. THESE STEPS ARE: 1) SET THE PRESSURE; 2) WATCH THE CALIBRATION CHAMBER ION GUAGE AND DO NOT PROCEED UNTIL THE PRESSURE IS STABLE FOR AT LEAST 8 MINUTES; 3) RECORD INSTRUMENT ION PUMP CURRENT MONITOR VOLTAGE (AS READ FROM UMMS TEST SET) IN TABLE 6.1.6.5; 4) LET THE HP9830 CALCULATOR TAKE DATA FOR BOTH FILAMENTS.

SETTING A PRESSURE IS ACCOMPLISHED BY SLOWLY OPENING VALVE V3 UNTIL THE DESIRED PRESSURE IS REACHED ON THE WALLACE & TIERNAN GAUGES. THEN CLOSE VALVES V3 AND V4 AND ALLOW AT LEAST 8 MINUTES AFTER THE PRESSURE ON THE ION GUAGE HAS STABILIZED.

THE BENDIX CORPORATION
Aerospace Systems Operations
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
—

SCALE

WEIGHT

SHEET 16

FILL IN THE REQUESTED DATA IN TABLE 6.1.6.1 AS THE FOLLOWING STEPS ARE PERFORMED:

ORIGINAL PAGE 19
OF POOR QUALITY

PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
1×10^{-6}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
3×10^{-6}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1×10^{-5}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
5×10^{-5}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

WHEN ALL DATA HAS BEEN TAKEN FOR THE ABOVE THREE PRESSURE POINTS PROCEED TO THE NEXT STEP.

← same wgt pressure as at 1×10^{-5} , but with small (10/1) orifice in.

6.1.6.26 VERIFY THAT THE CRYO PUMP IS STILL COLD.

6.1.6.27 REDUCE THE PRESSURE UPSTREAM OF THE LARGE VIKING LEAK BY OPENING VALVES V4 AND V1. WHEN THE PRESSURE ON THE WALLACE & TIEMAN GAUGES HAS BEEN REDUCED TO LESS THAN 48 TORR CLOSE VALVE V1 AND PROCEED.

6.1.6.28 SWITCH IN THE SMALL ORIFICE (10 LITERS/SEC) AND VERIFY THE SPECIAL CONDITIONS OF TABLE 6.1.6.2.

6.1.6.29 CONTINUE FOR THE NEXT TWO PRESSURE POINTS AS LISTED IN TABLE 6.1.6.2, SETTING THE PRESSURE AGAIN BY FIRST OPENING VALVE V4, SLOWLY OPENING VALVE V3 TO OBTAIN THE DESIRED PRESSURE, THEN CLOSING BOTH V3 AND V4. BE SURE TO STABILIZE THE PRESSURE PER PARAGRAPH 6.1.4.4. MONITOR THE ION PUMP CURRENT AND TURN THE INSTRUMENT POWER OFF IF THE MONITOR EXCEEDS 7mV. RECORD DATA IN TABLE 6.1.6.2 AS THE FOLLOWING STEPS ARE PERFORMED:

PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
3×10^{-5}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1×10^{-4}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
2×10^{-4}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

6.1.6.30 CLOSE OFF THE VIKING INLET LEAK BY CLOSING VALVES V11 AND V12 AND SET THE SPECIAL CONDITIONS LISTED IN TABLE 6.1.6.3.

6.1.6.31 CONTINUE FOR THE NEXT FOUR PRESSURE POINTS AS LISTED IN TABLE 6.1.6.3. THE PRESSURE IS NOW SET BY USING THE MKS SERVO VALVE AND ITS CONTROLLER. THE VALVE INPUT CONTROL IS SET UNTIL THE MKS DIGITAL READOUT SHOWS THE DESIRED PRESSURE. BE SURE TO WAIT AT LEAST 8 MINUTES FOR THE PRESSURE TO STABILIZE. MONITOR THE ION PUMP CURRENT AND TURN THE INSTRUMENT POWER OFF IF THE MONITOR EXCEEDS 7mV. RECORD DATA IN TABLE 6.1.6.3 AS THE FOLLOWING STEPS ARE PERFORMED:

✓ do not do until data at 3×10^{-4} is taken

THE BENDIX CORPORATION
Aerospace Systems Operations
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP3290648	REV —
SCALE	WEIGHT	SHEET 17	

	PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN	
Variation	3X10-4	✓	✓	✓	✓	use Viking leak still. Note: Cal. station ion pump is pulling 135mA.
Variation	2X10-3	✓	✓	✓	✓	
	3X10-3	✓	✓	✓	✓	
	2X10-2	✓	✓	✓	✓	

6.1.6.32 CLOSE THE MKS INLET VALVE AND SET THE SPECIAL CONDITIONS LISTED IN TABLE 6.1.6.4.

Variation 6.1.6.33 CONTINUE FOR THE NEXT FIVE PRESSURE POINTS AS LISTED IN TABLE 6.1.6.4. THE PRESSURES ARE NOW SET STATICLY BY MANUALLY OPENING THE MKS VALVE UNTIL THE DESIRED PRESSURE IS OBTAINED AND THEN CLOSING THE VALVE. BE SURE TO WAIT 8 MINUTES FOR THE PRESSURE TO STABILIZE. MONITOR THE ION PUMP CURRENT AND TURN THE INSTRUMENT POWER OFF IF THE MONITOR EXCEEDS 7mV. RECORD DATA IN TABLE 6.1.6.4 AS THE FOLLOWING STEPS ARE PERFORMED:

	PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
Variation	3X10-2	✓	✓	✓	✓
	2X10-1	✓	✓	✓	✓
	3X10-1	✓	✓	✓	✓
	1	✓	✓	✓	✓
	3	✓	✓	✓	✓
	10	✓	✓	✓	✓

6.1.6.34 CLOSE OFF OXYGEN SUPPLY.

6.1.6.35 USING THE CYROPUMP, REDUCE THE CALIBRATION CHAMBER PRESSURE TO 50 MICRONS OR LESS.

6.1.6.36 TURN ON THE MAIN ION PUMP AND REDUCE PRESSURE TO 1×10^{-6} TORR OR LESS.

6.1.6.37 OPEN THE SAMS RANGE VALVE.

6.1.6.38 TURN THE SAMS INSTRUMENT POWER OFF.

END OF OXYGEN CALIBRATION

THE BENDIX CORPORATION
Aerospace Systems Operations
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
—

SCALE

WEIGHT

SHEET 18

date 2-2-82

6.1.7 OXYGEN/NITROGEN MIXTURE GAS CALIBRATION

ORIGINAL PAGE 18
OF POOR QUALITY

THE O2/N2 MIXTURE CALIBRATION IS SIMILAR TO THE NITROGEN CALIBRATION. THE ION SOURCE PRESSURE SHOULD NOT EXCEED 1×10^{-4} TORR. THIS PRESSURE IS INDICATED WHEN THE ION PUMP CURRENT MONITOR AS READ ON THE UMS TEST SET EXCEEDS ABOUT 7 MV.

Variation

6.1.7.1 CALIBRATE THE LARGE VIKING INLET LEAK FOR N2/O2 PER TP2374339. RECORD VALUE HERE.

5.65×10^{-6} LITERS/SEC
@ $T = 76.6^\circ\text{F}$ (ave)
 5.63×10^{-6} @ 76.8°F @ 40 Torr
 5.66×10^{-6} @ 76.4°F @ 400 Torr

6.1.7.2 CLOSE VALVE V38.

6.1.7.3 VERIFY OR EVACUATE THE GAS INLET SYSTEM PER PARAGRAPH 6.6 OF TP2374339. VERIFY THROTTLING VALVE AT SUMS PLENUM IS OPEN

6.1.7.4 VERIFY THAT VALVE V1 IS NOW CLOSED.

6.1.7.5 VERIFY THAT THE REGULATOR AND VALVES ON THE N2/O2 TANK HAVE BEEN PROPERLY FLUSHED WITH N2/O2 AND THAT THE GAS SUPPLY LINE BETWEEN THE BLACK VALVE AND THE CALIBRATION STAND INLET IS NOW EVACUATED.

Variation

6.1.7.6 ADJUST ION GAGES PER PARAGRAPH 6.1.4.2

6.1.7.7 PUMP THE CALIBRATION CHAMBER DOWN TO A PRESSURE $\leq 2 \times 10^{-8}$ TORR. RECORD THE PRESSURE.

9.7×10^{-8} TORR
(501/s orifice)

6.1.7.8 TURN ON THE "SUMS ION PUMP POWER".

6.1.7.9 OPEN THE SUMS INLET, RANGE AND PROTECTION VALVES.

6.1.7.10 VERIFY THE INSTRUMENT SENSOR INTERNAL PRESSURE IS LESS THAN OR EQUAL TO 1×10^{-5} TORR.

6.1.7.11 TURN ON THE "SUMS INSTRUMENT POWER".

6.1.7.12 VERIFY THAT THE N2/O2 STATIC CALIBRATION TAPE IS INSERTED IN THE HP9830 CALCULATOR.

Conductances above were measured using N_2 after baking Viking leak. Correction of this value to N_2/O_2 not required since correction factor appears in both numerator and denominator of HP9830 calculations.

THE BENDIX CORPORATION
Aerospace Systems Operations
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP3290648	REV —
SCALE	WEIGHT	SHEET 19	

6.1.7.13 WAIT 30 MINUTES MINIMUM FOR THE INSTRUMENT ION SOURCE TEMPERATURE TO STABILIZE.

6.1.7.14 RECORD THE CALIBRATION CHAMBER AND THE GAS INLET SYSTEM TEMPERATURES USING THE FLUKE DATA LOGGER.

T12 CALIBRATION CHAMBER 22.8 DEG F
T13 GAS INLET SYSTEM 75.5 DEG F

T11 = 73.9 °F
T14 = 75.3 °F
T15 = 79.8 °F

6.1.7.15 VERIFY THE SPECIAL CONDITIONS OF TABLE 6.1.7.1 HAVE BEEN SET.

6.1.7.16 ON THE HP9830 TYPE LOAD 0, EXECUTE, FOLLOWED BY RUN, EXECUTE. THE PROGRAM IS INTERACTIVE. BE CERTAIN TO COMPLY WITH ALL CALCULATOR REQUESTS THROUGHOUT THE TEST.

6.1.7.17 VERIFY THAT THE CHAMBER PRESSURE AS READ ON THE ION GAUGE HAS BEEN STABLE FOR AT LEAST 0 MINUTES.

6.1.7.18 FILL IN THE REQUESTED DATA IN TABLE 6.1.7.1 AND TABLE 6.1.7.6 AS THE FOLLOWING STEPS ARE PERFORMED:

PRESS
(TORR)

CHAMBER PRESS
STABILIZED

RECORD
ION PUMP

DATA
TAKEN

RESIDUALS

BE CERTAIN NOT TO PROCEED UNTIL THE HP9830 HAS TAKEN DATA FOR BOTH FILAMENTS.

6.1.7.19 VERIFY THAT VALVES V6, V7, V8, V11, V12, V21 AND V22 ARE OPEN.

6.1.7.20 CLOSE VALVE V10 AND REMOVE THE KNOB.

6.1.7.21 VERIFY OR CLOSE VALVES V2, V4, V9, V13 AND V14.

6.1.7.22 CLOSE VALVE V3.

6.1.7.23 OPEN BLACK VALVE AT N2/O2 TANK.

6.1.7.24 OPEN VALVE V4.

6.1.7.25 TAKING DATA FOR A GIVEN PRESSURE POINT IS A FOUR STEP PROCESS. THESE STEPS ARE: 1) SET THE PRESSURE; 2) WATCH THE CALIBRATION CHAMBER ION GAUGE AND DO NOT PROCEED UNTIL THE PRESSURE IS STABLE FOR AT LEAST 0 MINUTES; 3) RECORD INSTRUMENT ION PUMP CURRENT MONITOR VOLTAGE (AS READ FROM UMPS TEST SET) IN TABLE 6.1.7.6; 4) LET THE HP9830 CALCULATOR TAKE DATA FOR BOTH FILAMENTS.

SETTING A PRESSURE IS ACCOMPLISHED BY SLOWLY OPENING VALVE V3 UNTIL THE DESIRED PRESSURE IS REACHED ON THE WALLACE & TIERNAN GAUGES. THEN CLOSE VALVES V7 AND V4 AND ALLOW AT LEAST 0 MINUTES AFTER THE PRESSURE ON THE ION GAUGE HAS STABILIZED.

ORIGINAL PAGE IS
OF POOR QUALITY

THE BENDIX CORPORATION
Aerospace Systems Operations

ANN ARBOR, MICHIGAN

SIZE

A

CODE IDENT NO.

07038

DRAWING NUMBER

TP3290648

REV

—

SCALE

WEIGHT

SHEET

20

FILL IN THE REQUESTED DATA IN TABLE 6.1.7.1 AS THE FOLLOWING STEPS ARE PERFORMED:

ORIGINAL PAGE 18
OF POOR QUALITY

Variation	PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
	1X10-5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	3X10-6	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	1X10-5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	3X10-5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

(large orifice still)

WHEN ALL DATA HAS BEEN TAKEN FOR THE ABOVE THREE PRESSURE POINTS PROCEED TO THE NEXT STEP.

6.1.7.26 VERIFY THAT THE CRYO PUMP IS STILL COLD.

6.1.7.27 REDUCE THE PRESSURE UPSTREAM OF THE LARGE VIKING LEAK BY OPENING VALVES V4 AND V1. WHEN THE PRESSURE ON THE WALLACE & TIERNAN GAUGES HAS BEEN REDUCED TO LESS THAN 48 TORR CLOSE VALVE V1 AND PROCEED.

6.1.7.28 SWITCH IN THE SMALL ORIFICE (10 LITERS/SEC) AND VERIFY THE SPECIAL CONDITIONS OF TABLE 6.1.7.2

6.1.7.29 CONTINUE FOR THE NEXT THREE PRESSURE POINTS AS LISTED IN TABLE 6.1.7.2, SETTING THE PRESSURE AGAIN BY FIRST OPENING VALVE V4, SLOWLY OPENING VALVE V3 TO OBTAIN THE DESIRED PRESSURE, THEN CLOSING BOTH V3 AND V4. BE SURE TO STABILIZE THE PRESSURE PER PARAGRAPH 6.1.4.4. MONITOR THE ION PUMP CURRENT AND TURN THE INSTRUMENT POWER OFF IF THE MONITOR EXCEEDS 50MV. RECORD DATA IN TABLE 6.1.7.2 AS THE FOLLOWING STEPS ARE PERFORMED:

Variation	PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
	1.5X10-4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	3X10-5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	1X10-4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	3X10-4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

6.1.7.30 CLOSE OFF THE VIKING INLET LEAK BY CLOSING VALVES V11 AND V12 AND SET THE SPECIAL CONDITIONS LISTED IN TABLE 6.1.7.3

6.1.7.31 CONTINUE FOR THE NEXT PRESSURE POINT AS LISTED IN TABLE 6.1.7.3. THE PRESSURE IS NOW SET BY USING THE MKS SERVO VALVE AND ITS CONTROLLER. THE VALVE INPUT CONTROL IS SET UNTIL THE MKS DIGITAL READOUT SHOWS THE DESIRED PRESSURE. BE SURE TO WAIT AT LEAST 8 MINUTES FOR THE PRESSURE TO STABILIZE. MONITOR THE ION PUMP CURRENT AND TURN THE INSTRUMENT POWER OFF IF THE MONITOR EXCEEDS 50MV. RECORD DATA IN TABLE 6.1.7.3 AS THE FOLLOWING STEPS ARE PERFORMED:

V15 also closed
this time

THE BENDIX CORPORATION
Aerospace Systems Operations
ANN ARBOR, MICHIGAN

SIZE	CODE IDENT NO.	DRAWING NUMBER	REV
A	07038	TP3290648	-
SCALE	WEIGHT	SHEET	
		21	

Date 2-3-82

ORIGINAL PAGE 18
OF POOR QUALITY

	PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
variation	1X10-3	✓	✓	✓	✓
	5X10-3	✓	✓	✓	✓

6.1.7.32 CLOSE THE SUPS RANGE VALVE AND SET THE SPECIAL CONDITIONS LISTED IN TABLE 6.1.7.4

6.1.7.33 CONTINUE FOR THE NEXT TWO PRESSURE POINTS AS LISTED IN TABLE 6.1.7.4. THE PRESSURE IS AGAIN SET WITH THE MKS SERVO VALVE AND ITS CONTROLLER. MONITOR THE ION PUMP CURRENT AND TURN THE INSTRUMENT POWER OFF IF THE MONITOR EXCEEDS 50MV. RECORD DATA IN TABLE 6.1.7.4 AS THE FOLLOWING STEPS ARE PERFORMED:

	PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
3X10-3	—	—	—	—	—
1X10-2	—	—	—	—	—

6.1.7.34 CLOSE THE MKS INLET VALVE AND SET THE SPECIAL CONDITIONS LISTED IN TABLE 6.1.7.5

6.1.7.35 CONTINUE FOR THE NEXT SEVEN PRESSURE POINTS AS LISTED IN TABLE 6.1.7.5. THE PRESSURES ARE NOW SET STATICLY BY MANUALLY OPENING THE MKS VALVE UNTIL THE DESIRED PRESSURE IS OBTAINED AND THEN CLOSING THE VALVE. BE SURE TO WAIT 8 MINUTES FOR THE PRESSURE TO STABILIZE. MONITOR THE ION PUMP CURRENT AND TURN THE INSTRUMENT POWER OFF IF THE MONITOR EXCEEDS 50MV. RECORD DATA IN TABLE 6.1.7.5 AS THE FOLLOWING STEPS ARE PERFORMED:

	PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
3X10-2	—	—	—	—	—
1X10-1	—	—	—	—	—
3X10-1	—	—	—	—	—
1	—	—	—	—	—
3	—	—	—	—	—
10	—	—	—	—	—
20	—	—	—	—	—

6.1.7.36 CLOSE OFF N2/O2 SUPPLY.

6.1.7.37 USING THE CYROPUMP, REDUCE THE CALIBRATION CHAMBER PRESSURE TO 30 MICRONS OR LESS.

6.1.7.38 TURN ON THE MAIN ION PUMP AND REDUCE PRESSURE TO 1 X 10-6 TORR OR LESS.

Test stopped at this point. It was determined that the large chamber of the calibration station was somehow absorbing the O₂ from the test gas. Large chamber was valved off and test was continued. Go to page 21A for continuation of test.

THE BENDIX CORPORATION
Aerospace Systems Operations
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
—

SCALE

WEIGHT

SHEET 22

6.1.7.39 OPEN THE SUNS RANGE VALVE.

6.1.7.40 TURN THE SUNS INSTRUMENT POWER OFF.

END OF NITROGEN/OXYGEN MIXTURE CALIBRATION

END OF SUNS STATIC CALIBRATION

ORIGINAL PAGE IS
OF POOR QUALITY

THE BENDIX CORPORATION
Aerospace Systems Operations
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
—

SCALE

WEIGHT

SHEET 23

TABLE 6.1.5.1

ORIGINAL PAGE 18
OF POOR QUALITY

NITROGEN CALIBRATION RUN

SPECIAL CONDITIONS REQUIRED THROUGHOUT THE RUN FROM PRESSURE
RESIDUALS THROUGH 1×10^{-5} TORR

1. LIQUID HELIUM PUMP VALVED OFF
2. INLET THROTTLING VALVE OPEN
3. CALIBRATION ION PUMP ON
4. MKS SERVO VALVE CLOSED
5. VALVE V20 CLOSED
6. LARGE ORIFICE (50 LITERS/SEC) SET IN CALIBRATION CHAMBER (OUT)
7. LARGE VIKING LEAK USED AS GAS INLET
8. RECORD LARGE LEAK VALUE FROM TP2374339
9. SUNS RANGE VALVE OPEN
10. SUNS INSTRUMENT ION PUMP ON

 5.16×10^{-6}
(AVE)

NOMINAL CALIBRATION CHAMBER PRESSURE (TORR)	TYPE & FILE NUMBER	NOMINAL WALLACE TIEMAN PRESSURE (TORR)	CALIBRATION CHAMBER ION GUAGE PRESSURE (TORR)	PLENUM CHAMBER ION GUAGE PRESSURE (TORR)	WALLACE TIEMAN PRESSURE (TORR)	*** CALCULATED CHAMBER PRESSURE +/- 28% OF NOMINAL (TORR)	BRITRON READING 1 TORR HEAD (TORR)
RESIDUALS	101 1	0	6.35×10^{-8}	2.1×10^{-8}	0	(6.35×10^{-8})	0.000*
1×10^{-6}	101 2	7.4	9.35×10^{-7}	1.9×10^{-7}	7.26	9.32×10^{-7}	-3 $\times 10^{-5}$ **
3×10^{-6}	101 3	22	2.7×10^{-6}	5.0×10^{-7}	23.7	2.98×10^{-6}	-6 $\times 10^{-5}$ **
1×10^{-5}	101 4	74	8.7×10^{-6}	1.55×10^{-6}	77.0	9.59×10^{-6}	-6.5 $\times 10^{-5}$ **

* noise in last place

** MKS readout drifts increasingly negative with time (both heads)

*** as calculated by HP9830 program (corrected)

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP3290648	REV —
SCALE	WEIGHT	SHEET 24	

ORIGINAL PAGE IS
OF POOR QUALITY

TABLE 6.1.3.2

NITROGEN CALIBRATION RUN

SPECIAL CONDITIONS REQUIRED THROUGHOUT THE RUN FROM PRESSURE
3 X 10⁻⁵ THROUGH 3 X 10⁻⁴ TORR

1. LIQUID HELIUM PUMP VALVED OFF
2. INLET THROTTLING VALVE OPEN
3. CALIBRATION ION PUMP ON
4. MKS SERVO VALVE CLOSED
5. VALVE V30 CLOSED
6. SMALL ORIFICE (10 LITERS/SEC) SET IN CALIBRATION CHAMBER (IN)
7. LARGE VIKING LEAK USED AS GAS INLET
8. RECORD LARGE LEAK VALUE FROM TP2374339 5.16×10^{-6} LITERS/SEC (ave)
9. SUMS RANGE VALVE OPEN
10. SUMS INSTRUMENT ION PUMP ON

• CHANGE FROM PREVIOUS RUN

NOMINAL CALIBRATION CHAMBER PRESSURE (TORR)	TAPE & FILE NUMBER	NOMINAL WALLACE TIERMAN PRESSURE (TORR)	CALIBRATION CHAMBER ION GAUGE PRESSURE (TORR)	PLENUM CHAMBER ION GAUGE PRESSURE (TORR)	WALLACE TIERMAN PRESSURE (TORR)	CALCULATED* CHAMBER PRESSURE +/- 20% OF NOMINAL (TORR)	BARITRON READING 1 TORR HEAD (TORR)
3 X 10 ⁻⁵	101 5	40	2.1×10^{-5}	10.2×10^{-7}	49.5	2.66×10^{-5}	-6×10^{-5}
1 X 10 ⁻⁴	101 6	160	8.0×10^{-5}	3.6×10^{-6}	184.5	9.9×10^{-5}	9.9×10^{-5} **
3 X 10 ⁻⁴	102 1	400	2.5×10^{-4}	11.3×10^{-6}	548	2.94×10^{-4}	2.95×10^{-4} ***

* as calculated by HP9830 program (corrected)

** MKS baratrons rezeroed at this point. 1 Torr head set to 9.8×10^{-5} .
100 Torr head set to zero.

*** noise in the third digit.

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP3290648	REV —
SCALE	WEIGHT	SHEET 25	

**ORIGINAL PAGE IS
OF POOR QUALITY**

TABLE 6.1.5.3

NITROGEN CALIBRATION RUN

SPECIAL CONDITIONS REQUIRED AT PRESSURE OF 1×10^{-3} TORR

1. LIQUID HELIUM PUMP VALVED OFF
- 2. INLET THROTTLING VALVE NEARLY CLOSED
3. CALIBRATION ION PUMP ON
- 4. HKS VALVE USED TO SET PRESSURE
- 5. VALVE V34 CLOSED AND V38 OPEN
- 6. ORIFICE BUTTERFLY VALVE OPEN
- 7. VIKING INLET LEAK CLOSED
- 8. ION GURGES OFF AND NOT USED
9. SUMS RANGE VALVE OPEN
10. SUMS INSTRUMENT ION PUMP ON
- 11. PRIMARY MEASUREMENT MADE WITH BARATRON

Handwritten vertical text: kkkkkkkkkk

• **CHANGES REQUIRED FROM PREVIOUS RUN**

NOMINAL	:	TAPE &	:	1 TORR
CALIBRATION	:	FILE	:	BARATRON
CHAMBER	:	NUMBER	:	READING
PRESSURE	:		:	+/- 28%
(TORR)	:		:	OF NOMINAL
	:		:	(TORR)

1×10^{-3}	:	102	:	$1.00 \times 10^{-3} \pm 1\%$
	:	2	:	

← by the end of data taking, pressure had built up to 1.03×10^{-3} .
Turning servo valve controller back on (after) brought pressure back to 1.00×10^{-3} .

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
—

SCALE

WEIGHT

SHEET 26


ORIGINAL PAGE IS
OF POOR QUALITY

TABLE 6.1.5.4

NITROGEN CALIBRATION RUN

SPECIAL CONDITIONS REQUIRED THROUGHOUT THE RUN FROM 3×10^{-3} TO 1×10^{-2} TORR

1. LIQUID HELIUM PUMP VALVED OFF
2. INLET THROTTLING VALVE NEARLY CLOSED
3. CALIBRATION ION PUMP ON
4. MKS VALVE USED TO SET PRESSURE
5. VALVE V31 CLOSED AND V38 OPEN
6. ORIFICE BUTTERFLY VALVE OPEN
7. VIKING INLET LEAK CLOSED
8. ION GAGES OFF AND NOT USED
- 9. SUNS RANGE VALVE CLOSED (leave open)
10. SUNS INSTRUMENT ION PUMP ON
11. PRIMARY MEASUREMENT MADE WITH BARATRON



see variation
TP 6.1.5.32

• CHANGES REQUIRED FROM PREVIOUS RUN

NOMINAL CALIBRATION CHAMBER PRESSURE (TORR)	TAPE & FILE NUMBER	1 TORR BARATRON READING +/- 20% OF NOMINAL (TORR)
3×10^{-3}	102 3	$3.00 \times 10^{-3} \pm 1\%$ ← range valve open
1×10^{-2}	103 1	$1.00 \times 10^{-2} \pm \frac{1}{2}\%$ ← range valve closed
4.6×10^{-3}	102 4	$4.60 \times 10^{-3} \pm \frac{1}{2}\%$ ← range valve open

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
—

SCALE

WEIGHT

SHEET 27

NITROGEN CALIBRATION RUN

ORIGINAL PAGE IS
OF POOR QUALITY

1. LIQUID HELIUM PUMP VALVED OFF
- 2. CALIBRATION CHAMBER ION PUMP OFF
- 3. INLET THROTTLING VALVE OPEN
- 4. MKS VALVE CLOSED AFTER USE
5. VALVE V31 CLOSED AND V30 OPEN
6. ORIFICE BUTTERFLY VALVE OPEN
7. VIKING INLET LEAK CLOSED
8. ION GURGES OFF AND NOT USED
9. SUMS RANGE VALVE CLOSED
10. SUMS INSTRUMENT ION PUMP ON
11. PRIMARY MEASUREMENT MADE WITH BARATRON

see variation
6.1.5.35

• CHANGES REQUIRED FROM PREVIOUS RUN — NOTE THIS IS A COMPLETELY STATIC CALIBRATION.

NOMINAL CALIBRATION CHAMBER PRESSURE (TORR)	TYPE & FILE NUMBER	1 TORR BARATRON READING +/- 28% OF NOMINAL (TORR)	100 TORR BARATRON READING +/- 28% OF NOMINAL (TORR)
3 X 10 ⁻²	103 2	.0300 ± 1%	.0305
1 X 10 ⁻¹	103 3	.100 ± 1/2%	.1002
3 X 10 ⁻¹	103 4	.300 ± 1/2%	.300
1	103 5	1.002	1.002
3	103 6	N/A	3.001
10	104 1	N/A	10.00
20	104 2	N/A	21.00
32.72	104 3	N/A	32.72

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP32906-18

REV

SCALE

WEIGHT

SHEET 28

TABLE 6.1.5.6

ORIGINAL PAGE 13
OF POOR QUALITYNITROGEN CALIBRATION RUN
ION PUMP CURRENT MONITOR CALIBRATION

NOMINAL CALIBRATION PRESSURE (TORR)	CALCULATED* CALIBRATION PRESSURE (TORR)	ION PUMP CURRENT MONITOR (mV)
--	--	----------------------------------

RESIDUALS	(6.85×10^{-8})	2.1 mV
-----------	-------------------------	--------

1×10^{-6}	9.32×10^{-7}	2.3
--------------------	-----------------------	-----

3×10^{-6}	2.98×10^{-6}	2.5
--------------------	-----------------------	-----

1×10^{-5}	9.59×10^{-6}	2.5
--------------------	-----------------------	-----

3×10^{-5}	2.66×10^{-5}	2.5
--------------------	-----------------------	-----

1×10^{-4}	9.9×10^{-5}	2.7
--------------------	----------------------	-----

3×10^{-4}	2.94×10^{-4}	3.5
--------------------	-----------------------	-----

1×10^{-3}	1.00×10^{-3}	6.3
--------------------	-----------------------	-----

3×10^{-3}	3.00×10^{-3}	14.4 (range valve open)
--------------------	-----------------------	-------------------------

1×10^{-2}	1.00×10^{-2}	2.1 (range valve closed)
--------------------	-----------------------	--------------------------

3×10^{-2}	3.00×10^{-2}	2.1
--------------------	-----------------------	-----

1×10^{-1}	1.00×10^{-1}	2.1
--------------------	-----------------------	-----

3×10^{-1}	3.00×10^{-1}	2.3
--------------------	-----------------------	-----

1	1.002	2.8
---	-------	-----

3	3.001	4.1
---	-------	-----

10	10.00	8.3
----	-------	-----

20	21.00	14.5
----	-------	------

4.6×10^{-3}	4.60×10^{-3}	21.2 (range valve open)
----------------------	-----------------------	-------------------------

32.72	32.72	21.1 (inlet pressure transducer 3.07 V * 10.78 = 33.1 Torr)
-------	-------	---

* as calculated by HP9830 (pressure external to sums inlet)

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
ACODE IDENT NO.
07038DRAWING NUMBER
TP3290648REV
—

SCALE

WEIGHT

SHEET 29

TABLE 6.1.6.1

ORIGINAL PAGE 12
OF POOR QUALITY

OXYGEN CALIBRATION RUN

SPECIAL CONDITIONS REQUIRED THROUGHOUT THE RUN FROM PRESSURE
RESIDUALS THROUGH 1×10^{-5} TORR

1. LIQUID HELIUM PUMP VALVED OFF
2. INLET THROTTLING VALVE OPEN
3. CALIBRATION ION PUMP ON
4. MKS SERVO VALVE CLOSED
5. VALVE V38 CLOSED
6. LARGE ORIFICE (50 LITERS/SEC) SET IN CALIBRATION CHAMBER (OUT)
7. LARGE VIKING LEAK USED AS OFS INLET
8. RECORD LARGE LEAK VALUE FROM TP2374339 4.86×10^{-6} LITERS/SEC
9. SWS RANGE VALVE OPEN
10. SWS INSTRUMENT ION PUMP ON

NOMINAL CALIBRATION CHAMBER PRESSURE (TORR)	TAPE & FILE NUMBER	NOMINAL WALLACE TIERNAN PRESSURE (TORR)	CALIBRATION CHAMBER ION GAUGE PRESSURE (TORR)	PLENUM CHAMBER ION GAUGE PRESSURE (TORR)	WALLACE TIERNAN PRESSURE (TORR)	CALCULATED CHAMBER * PRESSURE 4/- 28% OF NOMINAL (TORR)	BARITRON READING 1 TORR HEAD (TORR)
RESIDUALS	105 1	0	6.15×10^{-8} 6.15×10^{-8}	2.35×10^{-8}	0	(6.4×10^{-8})	0.000 ± 0.005 $\times 10^{-3}$
1×10^{-6}	105 2	7.4	1.09×10^{-6} 2.4×10^{-7}	1.50×10^{-7} 1.4×10^{-7}	9.86 7.5	1.1×10^{-6}	"
3×10^{-6}	105 3	22	2.90×10^{-6}	4.0×10^{-7}	28.35	3.4×10^{-6}	-0.015×10^{-3}
1×10^{-5}	105 4	74	3.2×10^{-6} **	1.35×10^{-6}	82.7	8.55×10^{-6}	0.000 ± 0.005 $\times 10^{-3}$

* as calculated by HP9B30 program

** value is not accurate. when pressure was first set on wft gauge,
chamber ion gauge read 8.6×10^{-6} . Over a period of minutes it
decreased to 2.9×10^{-6} and lower. Ion gauge was turned off at this point.THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGANSIZE
ACODE IDENT NO.
07038DRAWING NUMBER
TP3290648REV
—

SCALE

WEIGHT

SHEET 30

TABLE 6.1.6.2

ORIGINAL PAGE 8.1
OF POOR QUALITY

OXYGEN CALIBRATION RUN

SPECIAL CONDITIONS REQUIRED THROUGHOUT THE RUN FROM PRESSURE
3 X 10⁻⁵ THROUGH 1 X 10⁻⁴ TORR

1. LIQUID HELIUM PUMP VALVED OFF
2. INLET THROTTLING VALVE OPEN
3. CALIBRATION ION PUMP ON
4. MKS SERVO VALVE CLOSED
5. VALVE V30 CLOSED
6. SMALL ORIFICE (10 LITERS/SEC) SET IN CALIBRATION CHAMBER (IN)
7. LARGE VIKING LEAK USED AS GAS INLET
8. RECORD LARGE LEAK VALUE FROM TP2374339
9. SUMS RANGE VALVE OPEN
10. SUMS INSTRUMENT ION PUMP ON

 4.86×10^{-6} LITERS/SEC

• CHANGE FROM PREVIOUS RUN

NOMINAL CALIBRATION CHAMBER PRESSURE (TORR)	TAPE & FILE NUMBER	NOMINAL WALLACE TIERMAN PRESSURE (TORR)	CALIBRATION CHAMBER ION GAUGE PRESSURE (TORR)	PLENUM CHAMBER ION GAUGE PRESSURE (TORR)	WALLACE TIERMAN PRESSURE (TORR)	CALCULATED CHAMBER PRESSURE +/- 20% OF NOMINAL (TORR)	BARITRON READING 1 TORR HEAD (TORR)
3 X 10 ⁻⁵	105 6	48	4.6×10^{-6}	7.4×10^{-7}	39.85	2.06×10^{-5} 2.45×10^{-5}	0.020×10^{-3}
1 X 10 ⁻⁴	106 1	168	6.65×10^{-5}	3.25×10^{-6}	174.8	9.49×10^{-5}	0.080×10^{-3}
5 X 10 ⁻⁵	105 5	74	0.44	1.45×10^{-6}	82.2	4.24 4.24×10^{-5}	0.032×10^{-3}
	106 2	160	1.65×10^{-5}	3.35×10^{-6}	174.0	2.26×10^{-5}	0.010×10^{-3} ± 0.005

↖ extra data point taken with large orifice in.

*# ion gauges working properly again at this point.
 * 2.06 is uncorrected. 2.45 corrected, but ion gauges are not working properly so correction is not valid probably.

THE BENDIX COMMUNICATIONS DIVISION
 AEROSPACE SYSTEMS OPERATIONS
 ANN ARBOR, MICHIGAN

SIZE	CODE IDENT NO.	DRAWING NUMBER	REV
A	07038	TP3290648	—
SCALE	WEIGHT	SHEET 31	

ORIGINAL PAGE 13
OF POOR QUALITY

SPECIAL CONDITIONS REQUIRED THROUGHOUT RUN FROM PRESSURE
3 X 10-4 THROUGH 1 X 10-2 TORR

- 2. LIQUID HELIUM PUMP VALVED OFF
- 3. INLET THROTTLING VALVE NEARLY CLOSED
- 3. CALIBRATION ION PUMP ON
- 4. MKS VALVE USED TO SET PRESSURE
- 5. VALVE V31 CLOSED AND V38 OPEN
- 6. ORIFICE BUTTERFLY VALVE OPEN
- 7. VIKING INLET LEAK CLOSED
- 8. ION GURGES OFF AND NOT USED
- 9. SUMS RANGE VALVE CLOSED
- 10. SUMS INSTRUMENT ION PUMP ON
- 11. PRIMARY MEASUREMENT MADE WITH BARATRON

(active)
variation as noted below

• CHANGES REQUIRED FROM PREVIOUS RUN

NOMINAL CALIBRATION CHAMBER PRESSURE (TORR)	TAPE & FILE NUMBER	1 TORR BARATRON READING ± 20% OF NOMINAL (TORR)	cal chamber	plenum chamber	w/T	calculated
range valve open 3×10^{-4}	106 3	0.292 $\times 10^{-3}$	2.35×10^{-4}	1.20×10^{-5}	547	2.97×10^{-4}
range valve open 1×10^{-3}	106 4	1.00×10^{-3} $\pm 1\%$	} MKS servo valve with active control.			
range valve open 3×10^{-3}	106 5	3.00×10^{-3} $\pm 1\%$				
range valve open 1×10^{-2}	107 1	1.00×10^{-2} $\pm 1/2\%$				
range valve closed						

MKS servo
valve with
active control.

THE BENDIX COMMUNICATIONS DIVISION AEROSPACE SYSTEMS OPERATIONS ANN ARBOR, MICHIGAN	SIZE	CODE IDENT NO.	DRAWING NUMBER	REV
	A	07038	TP3290648	—
	SCALE	WEIGHT	SHEET	32

ORIGINAL PAGE 15
OF POOR QUALITY

TABLE 6.1.6.4

OXYGEN CALIBRATION RUN

SPECIAL CONDITIONS REQUIRED THROUGHOUT THE RUN FROM 3 X 10⁻² TO 3 TORR

1. LIQUID HELIUM PUMP VALVED OFF
2. CALIBRATION CHAMBER ION PUMP OFF
3. THROTTLING VALVE OPEN
4. MKS SERVO VALVE CLOSED AFTER USE
5. VALVE V31 CLOSED AND V38 OPEN
6. ORIFICE BUTTERFLY VALVE OPEN
7. VIKING INLET LEAK CLOSED
8. ION GUARDS OFF AND NOT USED
9. SCANS RANGE VALVE CLOSED
10. SCANS INSTRUMENT ION PUMP ON
11. PRIMARY MEASUREMENT MADE WITH BARATRON

still used until
noted
10 l/sec used

• CHANGES REQUIRED FROM PREVIOUS RUN — NOTE THIS IS A COMPLETELY STATIC CALIBRATION

NOMINAL CALIBRATION CHAMBER PRESSURE (TORR)	TAPE # FILE NUMBER	1 TORR BARATRON READING +/- 28% OF NOMINAL (TORR)	100 TORR BARATRON READING +/- 28% OF NOMINAL (TORR)
3 X 10 ⁻²	107 2	3.00 X 10 ⁻² ± 1/2%	.0299
1 X 10 ⁻¹	107 3	1.00 X 10 ⁻¹ ± 0.29	.
3 X 10 ⁻¹	107 4	3.00 X 10 ⁻¹ ± 0.29	.299
1	107 5	N/A	1.0005 ± .0005
3	107 6	N/A	3.004 ± .003
10	108 1	N/A	10.005 10.005

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV

SCALE

WEIGHT

SHEET 33

ORIGINAL FROM
OF POOR QUALITY

TABLE 6.1.6.5

OXYGEN CALIBRATION RUN
ION PUMP CURRENT MONITOR CALIBRATION

NOMINAL CALIBRATION PRESSURE (TORR)	* CALCULATED CALIBRATION PRESSURE (TORR)	ION PUMP CURRENT MONITOR (mV)		SUMS Inlet Pressure (Volts) GSE channel #9
RESIDUALS	6.4×10^{-8}	2.0 mV	range valve open	
1×10^{-6}	1.1×10^{-6}	2.1 mV	"	
3×10^{-6}	3.4×10^{-6}	2.2	"	
1×10^{-5}	8.55×10^{-6}	2.2	"	
3×10^{-5}		2.3	"	0.14
1×10^{-4}	9.49×10^{-5}	2.5	"	0.13
3×10^{-4}	2.97×10^{-4}	2.8 3.1	"	0.4 0.4
1×10^{-3}	1.00×10^{-3}	4.9	"	0.35
3×10^{-3}	3.00×10^{-3}	9.9	"	0.24
1×10^{-2}	1.00×10^{-2}	2.1	range valve closed	0.45
3×10^{-2}	3.00×10^{-2}	2.1	"	0.46
1×10^{-1}	1.00×10^{-1}	2.1	"	0.33
3×10^{-1}	3.00×10^{-1}	2.1	"	0.26
1	1.000	2.4	"	0.31
3	3.003	3.2	"	0.48
5×10^{-5}	4.24×10^{-5}	2.3		
	2.26×10^{-5}	2.4		0.15
10	10.005 10.005	7.1 7.1	range closed	1.39 1.39

* as read with Baratron; set using active servo valve.
* as calculated by HP9830 program

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP3290648	REV —
SCALE	WEIGHT	SHEET 34	

TABLE 6.1.7.1

ORIGINAL PAGE #1
OF POOR QUALITY

N2/O2 CALIBRATION RUN

SPECIAL CONDITIONS REQUIRED THROUGHOUT THE RUN FROM PRESSURE
RESIDUALS THROUGH 1×10^{-5} TORR

1. LIQUID HELIUM PUMP VALVED OFF
2. INLET THROTTLING VALVE OPEN
3. CALIBRATION ION PUMP ON
4. MKS SERVO VALVE CLOSED
5. VALVE V30 CLOSED
6. LARGE ORIFICE (50 LITERS/SEC) SET IN CALIBRATION CHAMBER (OUT)
7. LARGE VIKING LEAK USED AS GAS INLET
8. RECORD LARGE LEAK VALUE FROM TP2374339
9. SAMS RANGE VALVE OPEN
10. SAMS INSTRUMENT ION PUMP ON

$$\frac{5.65 \times 10^{-6}}{(\text{ave})} \text{ LITERS/SEC}$$

NOMINAL CALIBRATION CHAMBER PRESSURE (TORR)	TAPE & FILE NUMBER	NOMINAL WALLACE TIERNAN PRESSURE (TORR)	CALIBRATION CHAMBER ION GUAGE PRESSURE (TORR)	PLENUM CHAMBER ION GUAGE PRESSURE (TORR)	WALLACE TIERNAN PRESSURE (TORR)	CALCULATED CHAMBER PRESSURE +/- 20% OF NOMINAL (TORR)	BARITRON READING 1 TORR HEAD (TORR)
RESIDUALS	110 1	0	9.7×10^{-8}	2.35×10^{-8}	0	—	0.005×10^{-3}
1×10^{-6}	110 2	7.4	1.05×10^{-6}	1.85×10^{-7}	7.52	1.10×10^{-6}	0.010×10^{-3}
3×10^{-6}	110 3	22	2.7×10^{-6}	4.75×10^{-7}	21.95	3.21×10^{-6}	0.015×10^{-3}
1×10^{-5}	110 4	74	9.05×10^{-6}	1.55×10^{-6}	74.0	1.08×10^{-5}	0.015×10^{-3}
3×10^{-5}	110 5	220	2.5×10^{-5}	4.6×10^{-6}	219	3.24×10^{-5}	0.040×10^{-3}

E BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
ACODE IDENT NO.
07038DRAWING NUMBER
TP3290648REV
—

SCALE

WEIGHT

SHEET 35

ORIGINAL PAGE 13
OF POOR QUALITY

TABLE 6.17.2

02/02 CALIBRATION RUN

SPECIAL CONDITIONS REQUIRED THROUGHOUT THE RUN FROM PRESSURE
3 X 10⁻⁵ THROUGH 3 X 10⁻⁴ TORR

1. LIQUID HELIUM PUMP VALVED OFF
2. INLET THROTTLING VALVE OPEN
3. CALIBRATION ION PUMP ON
4. MKS SERVO VALVE CLOSED
5. VALVE V38 CLOSED
6. SMALL ORIFICE (10 LITERS/SEC) SET IN CALIBRATION CHAMBER (IN)
7. LARGE VIKING LEAK USED AS OPS INLET
8. RECORD LARGE LEAK VALUE FROM TP2374339
9. SUNS RANGE VALVE OPEN
10. SUNS INSTRUMENT ION PUMP ON

5.65 x 10⁻⁶ LITERS/SEC
(AVE)

= CHANGE FROM PREVIOUS RUN

NOMINAL CALIBRATION CHAMBER PRESSURE (TORR)	TAPE & FILE NUMBER	NOMINAL WALLACE TIERNAN PRESSURE (TORR)	CALIBRATION CHAMBER ION GUAGE PRESSURE (TORR)	PLENUM CHAMBER ION GUAGE PRESSURE (TORR)	WALLACE TIERNAN PRESSURE (TORR)	CALCULATED CHAMBER PRESSURE +/- 20% OF NOMINAL (TORR)	BARITRON READING 1 TORR HEAD (TORR)
3 X 10 ⁻⁵	III 1	48	2.3 x 10 ⁻⁵	9.75 x 10 ⁻⁷	48.1	3.03 x 10 ⁻⁵	0.043 x 10 ⁻³
1 X 10 ⁻⁴	III 2	160	7.65 x 10 ⁻⁵	3.0 x 10 ⁻⁶	159.8	1.00 x 10 ⁻⁴	0.105 x 10 ⁻³
3 X 10 ⁻⁴	III 3	400	2.4 x 10 ⁻⁴	9.25 x 10 ⁻⁶	478	3.00 x 10 ⁻⁴	0.299 x 10 ⁻³
1.5 x 10 ⁻⁴	II 6	220	1.06 x 10 ⁻⁴	4.4 x 10 ⁻⁶	218	1.37 x 10 ⁻⁴	0.140 x 10 ⁻³

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP3290648	REV -
SCALE	WEIGHT	SHEET 36	

ORIGINAL PAGE IS
OF POOR QUALITY

TABLE 6.1.7.3

12/02 CALIBRATION RUN

SPECIAL CONDITIONS REQUIRED AT PRESSURE OF 1×10^{-3} TORR

Variation

1. LIQUID HELIUM PUMP VALVED OFF
2. INLET THROTTLING VALVE NEARLY CLOSED - OPEN
3. CALIBRATION ION PUMP ON - OFF
4. MKS VALVE USED TO SET PRESSURE
5. VALVE V21 CLOSED AND V30 OPEN
6. ORIFICE BUTTERFLY VALVE OPEN
7. VIKING INLET LEAK CLOSED
8. ION GAUGES OFF AND NOT USED
9. SUMS RANGE VALVE OPEN
10. SUMS INSTRUMENT ION PUMP ON
11. PRIMARY MEASUREMENT MADE WITH BARATRON

KKKKKKKKKK

MKS valve not used in feedback mode. Totally closed after setting pressure and cryo pump put on back side of valve.

• CHANGES REQUIRED FROM PREVIOUS RUN

NOMINAL CALIBRATION CHAMBER PRESSURE (TORR)	TAPE & FILE NUMBER	1 TORR BARATRON READING +/- 20% OF NOMINAL (TORR)	100 Torr Baratron
1×10^{-3}	III 4	$1.0 / \sqrt{6}$ $\pm 1/2\%$	noise
5×10^{-3}			.0024
3×10^{-3}	III 5	3.34×10^{-3}	.0024
3×10^{-3}	III 6	3.17×10^{-3}	.0020

← last reading of ion gauges before turning them off $I_c = 1.02 \times 10^{-8} A$
 $I_p = 9.8 \times 10^{-4} A$

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP3290648	REV —
SCALE	WEIGHT	SHEET 37	

TABLE 6.17.4

ORIGINAL PAGE 12
OF POOR QUALITY

N2/O2 CALIBRATION RUN

SPECIAL CONDITIONS REQUIRED THROUGHOUT THE RUN FROM 3×10^{-3} TO 1×10^{-2} TORR

1. LIQUID HELIUM PUMP VALVED OFF
2. INLET THROTTLING VALVE NEARLY CLOSED
3. CALIBRATION ION PUMP ON
4. MKS VALVE USED TO SET PRESSURE
5. VALVE V31 CLOSED AND V20 OPEN
6. ORIFICE BUTTERFLY VALVE OPEN
7. VIKING INLET LEAK CLOSED
8. ION GUGGES OFF AND NOT USED
- 9. SUMS RANGE VALVE CLOSED
10. SUMS INSTRUMENT ION PUMP ON
11. PRIMARY MEASUREMENT MADE WITH BARATRON

—
—
—
—
—
—
—
—
—
—
—

• CHANGES REQUIRED FROM PREVIOUS RUN

NOMINAL CALIBRATION CHAMBER PRESSURE (TORR)	TAPE & FILE NUMBER	1 TORR BARATRON READING +/- 20% OF NOMINAL (TORR)	100 Torr Baratron
3×10^{-3}			
1×10^{-2}			

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
←

SCALE

WEIGHT

SHEET 38

TABLE 6.17.5

02/02 CALIBRATION RUN

ORIGINAL PAGE IS
OF POOR QUALITYSPECIAL CONDITIONS REQUIRED THROUGHOUT THE RUN FROM 3×10^{-2} TO 20 TORR

1. LIQUID HELIUM PUMP VALVED OFF
2. CALIBRATION CHAMBER ION PUMP OFF
3. INLET THROTTLING VALVE OPEN
4. MKS VALVE CLOSED AFTER USE
5. VALVE V31 CLOSED AND V30 OPEN
6. ORIFICE BUTTERFLY VALVE OPEN
7. VIKING INLET LEAK CLOSED
8. ION GAGES OFF AND NOT USED
9. SUMS RANGE VALVE CLOSED
10. SUMS INSTRUMENT ION PUMP ON
11. PRIMARY MEASUREMENT MADE WITH BARATRON

—
—
—
—
—
—
—
—
—
—
—

• CHANGES REQUIRED FROM PREVIOUS RUN — NOTE THIS IS A COMPLETELY STATIC CALIBRATION

NOMINAL CALIBRATION CHAMBER PRESSURE (TORR)	TYPE & FILE NUMBER	1 TORR BARATRON READING +/- 20% OF NOMINAL (TORR)	100 TORR BARATRON READING +/- 20% OF NOMINAL (TORR)
3×10^{-2}			
1×10^{-1}			
3×10^{-1}			
1			
3			
10			
20			

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
—

SCALE

WEIGHT

SHEET 39

TABLE 6.17.6

ORIGINAL PAGE IS
OF POOR QUALITY

12/02 CALIBRATION RUN

ION PUMP CURRENT MONITOR CALIBRATION

NOMINAL CALIBRATION PRESSURE (TORR)	CALCULATED CALIBRATION PRESSURE (TORR)	ION PUMP CURRENT MONITOR (MV)	range Valve	SUM 5 Inlet Pressure 6SE Channel #9 (Volts)
RESIDUALS	9.7×10^{-8}	2.1	open	0.10
1×10^{-6}	1.10×10^{-6}	2.1	open	0.09
3×10^{-6}	3.21×10^{-6}	2.2	open	0.08
1×10^{-5}	1.08×10^{-5}	2.2	open	0.10
3×10^{-5}	3.03×10^{-5}	2.3	open	0.08 (small orifice)
1×10^{-4}	1.00×10^{-4}	2.5	open	0.09
3×10^{-4}	3.00×10^{-4}	3.2	open	0.07
1×10^{-3}	1.01×10^{-3}	6.5	open	0.11
3×10^{-3}				
1×10^{-2}				
3×10^{-2}				
1×10^{-1}				
3×10^{-1}				
1				
3				
10				
20				
3×10^{-5}	3.24×10^{-5}	2.3	open	0.15 (large orifice)
1.5×10^{-4}	1.37×10^{-4}	2.7	open	0.09 (small orifice)
3×10^{-3}	3.24×10^{-3}	15.8	open	0.10

Calculated by HP9830

IE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGANSIZE
A

CODE IDENT NO.

07038

DRAWING NUMBER

TP0290648

REV

SCALE

WEIGHT

SHEET 40

FILL IN THE REQUESTED DATA IN TABLE 6.1.7.1 AS THE FOLLOWING STEPS ARE PERFORMED:

ORIGINAL PAGE IS
OF POOR QUALITY

PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
1X10-6	==	==	==	==
3X10-6	==	==	==	==
1X10-5	==	==	==	==

WHEN ALL DATA HAS BEEN TAKEN FOR THE ABOVE THREE PRESSURE POINTS PROCEED TO THE NEXT STEP.

6.1.7.26 VERIFY THAT THE CRYO PUMP IS STILL COLD. —

6.1.7.27 REDUCE THE PRESSURE UPSTREAM OF THE LARGE VIKING LEAK BY OPENING VALVES V4 AND V1. WHEN THE PRESSURE ON THE WALLACE & TIERNAN GAGES HAS BEEN REDUCED TO LESS THAN 40 TORR CLOSE VALVE V1 AND PROCEED. —

6.1.7.28 SWITCH IN THE SMALL ORIFICE (10 LITERS/SEC) AND VERIFY THE SPECIAL CONDITIONS OF TABLE 6.1.7.2. —

6.1.7.29 CONTINUE FOR THE NEXT THREE PRESSURE POINTS AS LISTED IN TABLE 6.1.7.2, SETTING THE PRESSURE AGAIN BY FIRST OPENING VALVE V4, SLOWLY OPENING VALVE V3 TO OBTAIN THE DESIRED PRESSURE, THEN CLOSING BOTH V3 AND V4. BE SURE TO STABILIZE THE PRESSURE PER PARAGRAPH 6.1.4.4. MONITOR THE ION PUMP CURRENT AND TURN THE INSTRUMENT POWER OFF IF THE MONITOR EXCEEDS 50MV. RECORD DATA IN TABLE 6.1.7.2 AS THE FOLLOWING STEPS ARE PERFORMED:

PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
3X10-5	==	==	==	==
1X10-4	==	==	==	==
3X10-4	==	==	==	==

6.1.7.30 CLOSE OFF THE VIKING INLET LEAK BY CLOSING VALVES V11 AND V12 AND SET THE SPECIAL CONDITIONS LISTED IN TABLE 6.1.7.3.A

6.1.7.31 CONTINUE FOR THE NEXT PRESSURE POINT AS LISTED IN TABLE 6.1.7.3.A THE PRESSURE IS NOW SET BY USING THE MKS SERVO VALVE AND ITS CONTROLLER. THE VALVE INPUT CONTROL IS SET UNTIL THE MKS DIGITAL READOUT SHOWS THE DESIRED PRESSURE. BE SURE TO WAIT AT LEAST 8 MINUTES FOR THE PRESSURE TO STABILIZE. MONITOR THE ION PUMP CURRENT AND TURN THE INSTRUMENT POWER OFF IF THE MONITOR EXCEEDS 50MV. RECORD DATA IN TABLE 6.1.7.3.A THE FOLLOWING STEPS ARE PERFORMED:

Restart from
here on 2-4-82.
Throttling Valve
closed for all
remaining pressures

THE BENDIX CORPORATION
Aerospace Systems Operations
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP3290648	REV —
SCALE	WEIGHT	SHEET 21 A	

	PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
Variation	5×10^{-4}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	1×10^{-3}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	4×10^{-3}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

6.1.7.32 CLOSE THE SUMS RANGE VALVE AND SET THE SPECIAL CONDITIONS LISTED IN TABLE 6.1.7.4.A

MKS Valve used in closed loop servo mode.

6.1.7.33 CONTINUE FOR THE NEXT TWO PRESSURE POINTS AS LISTED IN TABLE 6.1.7.4.A THE PRESSURE IS AGAIN SET WITH THE MKS SERVO VALVE AND ITS CONTROLLER. MONITOR THE ION PUMP CURRENT AND TURN THE INSTRUMENT POWER OFF IF THE MONITOR EXCEEDS 50MV. RECORD DATA IN TABLE 6.1.7.4.A AS THE FOLLOWING STEPS ARE PERFORMED:

Sums Range Valve Closed Automatically at 6.1×10^{-3} Torr.

	PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
Variation	4×10^{-3}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	1×10^{-2}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Valve MKS closed after setting pressure.

6.1.7.34 CLOSE THE MKS INLET VALVE AND SET THE SPECIAL CONDITIONS LISTED IN TABLE 6.1.7.5.A

6.1.7.35 CONTINUE FOR THE NEXT SEVEN PRESSURE POINTS AS LISTED IN TABLE 6.1.7.5.A THE PRESSURES ARE NOW SET STATICLY BY MANUALLY OPENING THE MKS VALVE UNTIL THE DESIRED PRESSURE IS OBTAINED AND THEN CLOSING THE VALVE. BE SURE TO WAIT 8 MINUTES FOR THE PRESSURE TO STABILIZE. MONITOR THE ION PUMP CURRENT AND TURN THE INSTRUMENT POWER OFF IF THE MONITOR EXCEEDS 50MV. RECORD DATA IN TABLE 6.1.7.5.A AS THE FOLLOWING STEPS ARE PERFORMED:

ORIGINAL PAGE IS OF POOR QUALITY

	PRESS (TORR)	SET PRESS POINT	CHAMBER PRESS STABILIZED	RECORD ION PUMP	DATA TAKEN
Variation	3×10^{-2}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	1×10^{-1}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	3×10^{-1}	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	20	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	30	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

System automatically closes valves at 48.1 Torr.

6.1.7.36 CLOSE OFF N2/O2 SUPPLY.

6.1.7.37 USING THE CYROPUMP, REDUCE THE CALIBRATION CHAMBER PRESSURE TO 90 MICRONS OR LESS.

6.1.7.38 TURN ON THE MAIN ION PUMP AND REDUCE PRESSURE TO 1×10^{-6} TORR OR LESS.

THE BENDIX CORPORATION
Aerospace Systems Operations
ANN ARBOR, MICHIGAN

SIZE	CODE IDENT NO.	DRAWING NUMBER	REV
A	07038	TP3290648	—
SCALE	WEIGHT	SHEET	
		22 A	

6.1.7.39 OPEN THE SUNS RANGE VALVE

6.1.7.40 TURN THE SUNS INSTRUMENT POWER OFF.

END OF NITROGEN/OXYGEN MIXTURE CALIBRATION

END OF SUNS STATIC CALIBRATION

ORIGINAL PAGE IS
OF POOR QUALITY

THE BENDIX CORPORATION
Aerospace Systems Operations
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
—

SCALE

WEIGHT

SHEET 23 A

2-4-82

ORIGINAL PAGE 13
OF POOR QUALITY

TABLE 6.1.7.3 A

N2/O2 CALIBRATION RUN

SPECIAL CONDITIONS REQUIRED AT PRESSURE OF 1×10^{-3} TORR

Variation

1. LIQUID HELIUM PUMP VALVED OFF
- * 2. INLET THROTTLING VALVE NEARLY CLOSED ALL THE WAY
3. CALIBRATION ION PUMP ON (OUT OF THE PICTURE)
- * 4. MKS VALVE USED TO SET PRESSURE
- * 5. VALVE V31 CLOSED AND V30 OPEN
- * 6. ORIFICE BUTTERFLY VALVE OPEN
- * 7. VIKING INLET LEAK CLOSED
- * 8. ION GAUGES OFF AND NOT USED
9. SUNS RANGE VALVE OPEN
10. SUNS INSTRUMENT ION PUMP ON
- * 11. PRIMARY MEASUREMENT MADE WITH BARATRON

(closed loop servo mode)

* CHANGES REQUIRED FROM PREVIOUS RUN

NOMINAL CALIBRATION CHAMBER PRESSURE (TORR)	TAPE & FILE NUMBER	1 TORR BARATRON READING +/- 28% OF NOMINAL (TORR)	100 Torr Baratron
1×10^{-3}	113 2	1.00×10^{-3}	
5×10^{-4}	113 1	5.10×10^{-4}	
4×10^{-3}	113 3	4.00×10^{-3}	

range valve closed
automatically at
 6.10×10^{-3} Torr.

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV

SCALE

WEIGHT

SHEET

37 A

2-4-82

ORIGINAL PAGE NO.
OF POOR QUALITY

TABLE 6.17.4 A

N2/O2 CALIBRATION RUN

SPECIAL CONDITIONS REQUIRED THROUGHOUT THE RUN FROM 3×10^{-3} TO 1×10^{-2} TORR

1. LIQUID HELIUM PUMP VALVED OFF
2. INLET THROTTLING VALVE ~~NOT~~ CLOSED ALL THE WAY
3. CALIBRATION ION PUMP ON OUT OF THE PICTURE
4. HKS VALVE USED TO SET PRESSURE
5. VALVE ~~421~~ CLOSED AND ~~422~~ OPEN V31 OPEN V30 CLOSED
6. ORIFICE BUTTERFLY VALVE OPEN AFTER SETTING PRESS
7. VIKING INLET LEAK CLOSED
8. ION GUARDS OFF AND NOT USED
9. SUMS RANGE VALVE CLOSED
10. SUMS INSTRUMENT ION PUMP ON
11. PRIMARY MEASUREMENT MADE WITH BARATRON

(closed after use)

* CHANGES REQUIRED FROM PREVIOUS RUN

large chamber valved off

NOMINAL CALIBRATION CHAMBER PRESSURE (TORR)	TAPE & FILE NUMBER	1 TORR BARATRON READING +/- 28% OF NOMINAL (TORR)	100 Torr
3×10^{-3}	114	4.22×10^{-3}	0.0033
4×10^{-3}	1		
1×10^{-2}	114	1.00×10^{-2}	0.0090
	2		

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGANSIZE
ACODE IDENT NO.
07038DRAWING NUMBER
TP3290648REV
—

SCALE

WEIGHT

SHEET 38 A

ORIGINAL PAGE IS
OF POOR QUALITY

M2/02 CALIBRATION RUN

SPECIAL CONDITIONS REQUIRED THROUGHOUT THE RUN FROM 3×10^{-2} TO 20 TORR

- Variation
1. LIQUID HELIUM PUMP VALVED OFF
 2. CALIBRATION CHAMBER ION PUMP OFF
 3. INLET THROTTLING VALVE ~~ON~~ CLOSED
 4. MKS VALVE CLOSED AFTER USE
 5. VALVE V31 CLOSED AND V30 OPEN V31 OPEN, V30 CLOSED
 6. ORIFICE BUTTERFLY VALVE OPEN AFTER USE
 7. VIKING INLET LEAK CLOSED
 8. ION GAGES OFF AND NOT USED
 9. SUMS RANGE VALVE CLOSED
 10. SUMS INSTRUMENT ION PUMP ON
 11. PRIMARY MEASUREMENT MADE WITH BARATRON

• CHANGES REQUIRED FROM PREVIOUS RUN — NOTE THIS IS A COMPLETELY STATIC CALIBRATION

large chamber is valved off

NOMINAL CALIBRATION CHAMBER PRESSURE (TORR)	TAPE & FILE NUMBER	1 TORR BARATRON READING +/- 28% OF NOMINAL (TORR)	100 TORR BARATRON READING +/- 28% OF NOMINAL (TORR)
3×10^{-2}	114 3	2.985×10^3	0.0290
1×10^{-1}	114 4	1.003×10^{-1}	0.0995
3×10^{-1}	114 5	3.023×10^{-1}	0.3012
1	114 6	1.00	1.000
3	115 1	N/A	3.071 3.03
10	115 2	N/A	10.05
30	115 3	N/A	30.1

system shut down at 48.1 Torr

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE	CODE IDENT NO.	DRAWING NUMBER	REV
A	07038	TP3290648	—
SCALE	WEIGHT	SHEET	
		34 A	

TABLE 6.17.6 A

N2/O2 CALIBRATION RUN

ION PUMP CURRENT MONITOR CALIBRATION

NOMINAL CALIBRATION PRESSURE (TORR)	CALCULATED CALIBRATION PRESSURE (TORR)	ION PUMP CURRENT MONITOR (mV)	range valve	Sum Inlet Pressure (Volts)
RESIDUALS	!	!		
1 X 10 ⁻⁶	!	!		
3 X 10 ⁻⁶	!	!		
1 X 10 ⁻⁵	!	!		
3 X 10 ⁻⁵	!	!		
1 X 10 ⁻⁴	!	!		
3 X 10 ⁻⁴	!	!		
1 X 10 ⁻³	1.00 X 10 ⁻³	5.9	open	0.18
5 X 10⁻³	4.00 X 10 ⁻³	16.7	open	0.26
1 X 10 ⁻²	1.00 X 10 ⁻²	2.0	closed	0.03
3 X 10 ⁻²	2.99 X 10 ⁻²	2.0	closed	0.03
1 X 10 ⁻¹	1.00 X 10 ⁻¹	2.1	closed	—
3 X 10 ⁻¹	3.02 X 10 ⁻¹	2.2	closed	0.05
1	1.00	2.6	closed	0.12
3	3.03	3.9	closed	0.31
10	10.05	7.6	closed	0.96
30	30.1	17.4	closed	2.83
5 X 10 ⁻⁴	5.1 X 10 ⁻⁴	3.9 mV	open	0.24
4 X 10 ⁻³	4.22 X 10 ⁻³	2.1	closed	0.03

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TPC290648	REV —
SCALE	WEIGHT	SHEET 40 A	

ORIGINAL PAGE 11
OF POOR QUALITY

RELIABILITY		REVISIONS			CONFIC MGT
APPD	PREDICTION	LTR	DESCRIPTION	DATE	APPR'D
		X-1	EXPERIMENTAL RELEASE ER190AA-72	1-17-73	1-19-73
		-	STANDARD RELEASE	1-22-73	2-1-73
		A	REVISED DUE TO TEST EQUIP. REDESIGN	6-18-73	6-18-73

TABLE OF CONTENTS

	Page
REVISION STATUS INDEX	2
1.0 PURPOSE OF TEST	3
2.0 SCOPE OF TEST	3
3.0 APPLICABLE DOCUMENTS	3
4.0 PARTICIPANTS	3
5.0 EQUIPMENT REQUIRED	4
6.0 PROCEDURE	5
7.0 VARIATION SHEET	16
8.0 TDL SHEET	17
9.0 TEST WITNESS SIGN-OFF SHEET	18
DATA SHEETS	
AS-Run	
1-19-82 (N ₂)	
1-22-82 (O ₂)	
1-29-82 (N ₂)	


DRAWING AND PART APPLICATION			EFFECTIVITY
PART NO	NEXT ASSY	END ITEM NO.	
		2370700-101	EXPERIMENTAL
		2370700-201	TPC FLIGHT

DRAWING CLASS

A ☐ B ☒ C ☐

COMPL. NO.	
FREE	
CHECKED	
TEST	
QUAL CONT	
ENG	
SYS SPT	

THE BENDIX CORPORATION AEROSPACE SYSTEMS DIVISION - ANN ARBOR, MICHIGAN			
TITLE Calibration Station Molecular Leak Test Procedure for the Viking UAMS			
SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP2374339	REV A
SCALE	WEIGHT	SHEET 1 of 18	



Systems Division

**Calibration Station
Molecular Leak Test Procedure
for the Viking UAMS**

QA	REV. NO.
TP2374339	-
PAGE 2	OF
DATE	

REVISION STATUS INDEX

Revision Letter

Page

Section

A

8 thru 9

Section 6 rewritten

**ORIGINAL PAGE IS
OF POOR QUALITY**



**Aerospace
Systems Division**

**Calibration Station
Molecular Leak Test Procedure
for the Viking UAMS**

No.	Rev. No.
TP2374339	
Page 3 of	
Date	

1.0 PURPOSE OF TEST

The purpose of this test is to establish the molecular leak rate of each leak of the calibration station for each species of the test gas and to determine the linearity with pressure.

2.0 SCOPE OF TEST

It is assumed personnel familiar with the calibration station and the necessary procedures will conduct the test.

3.0 APPLICABLE DOCUMENTS

PD6400445 Upper Atmosphere Mass Spectrometer

4.0 PARTICIPANTS

See Work Order Operations Sheet

ORIGINAL PAGE III
OF POOR QUALITY



**Aerospace
Systems Division**

**Calibration Station
Molecular Leak Test Procedure
for the Viking UAMS**

PAGE <u>4</u> OF <u> </u>
DATE <u> </u>

5.0 EQUIPMENT REQUIRED

<u>Item</u>	<u>Manufacturer</u>	<u>Part No. or Model</u>	<u>Qty</u>	<u>Serial No.</u>	<u>Calib. Date</u>
-------------	---------------------	------------------------------	------------	-----------------------	------------------------

Calibration Station

Timer

Pure Gases;

~~Hydrogen~~

~~Helium~~

Nitrogen

Oxygen

~~Argon~~


~~Carbon Dioxide~~

~~Carbon Monoxide~~

80% N₂ / 20% O₂

ORIGINAL PAGE IS
OF POOR QUALITY

Equivalent items may be substituted. These and any additional items must be listed below prior to testing.



**Aerospace
Systems Division**

**Calibration Station
Molecular Leak Test Procedure
for the Viking UAMS**

No.	Rev. No.
TP2374339	A
Page <u>5</u> of <u> </u>	
Date <u> </u>	

6.0

PROCEDURE

✓✓ 6.1

Verify that the system is in standby conditions, i.e. the inlet system is being pumped by its internal vacuum system. See Section 6.2

✓✓ 6.2

Standby Condition for Gas Inlet System

✓✓ 6.2.1

Valve V₁ CLOSED.

✓✓ 6.2.2

Valves V₂ through V₁₄, V₂₁, V₂₂ OPEN.

✓✓ 6.2.3

20 l/s Ion Pump RUNNING.

Pressure, depending on condition of gas inlet system (prior use, bake, etc.) should be less than 5×10^{-6} torr.

✓✓ 6.2.4

Gas Supply valves (Black) - CLOSED.

✓✓ 6.2.5

Gas cylinder valves - CLOSED.

✓✓ 6.2.6

Regular Set Handles - BACKED OFF.

✓✓ 6.2.7

Indicated gas pressures

High- Less than 50#

Low- Less than 2#

✓✓ 6.3

Low Pressure (40-50 torr) Leak Calibration

✓✓ 6.3.1

Turn Baratron ON.

✓✓ 6.3.2

Liquid nitrogen chill the cryo pod for at least 20 minutes for all gases except hydrogen and helium. For these gases, connect the mechanical pump with a liquid nitrogen cooled molecular sieve in the foreline.

✓✓ 6.3.3

Backfilling with desired gas.

✓✓ 6.3.4

Torque valves V₂, 3, 9, 10, 11, 13, 14 to 2 1/2 in. lbs. This assumes small calibrated leak and buffer volume will not be used.

✓✓ 6.3.4.1

Remove nut from valve V₁₀.




Aerospac
Systems Division

Calibration Station
Molecular Leak Test Procedures
for the Viking UAMS

No.	Rev. No.
TP2374339	A
Page 6 of	
Date	

- ✓✓ 6.3.5 Open gas cylinder to be used and set regulator at about 3 psi.
- ✓✓ 6.3.6 Close gas cylinder (same gas as 6.3.5).
- ✓✓ 6.3.7 Open bleed valve to atmosphere of gas cylinder until input regulator pressure drops to about 50 psi.
- ✓✓ 6.3.8 Repeat steps 6.3.5 thru 6.3.7 two more times.
- ✓✓ 6.3.9 Reopen gas cylinder and leave open.
- ✓✓✓ 6.3.10 Slowly open the Black gas supply valve. Slowly open V₃ (Inlet) and admit gas to a pressure of 20 torr, close V₂₁ to 15 in lbs. Open V₃ to a pressure of 40 to 50 torr. A minimum of 20 seconds should be allowed for each of the 3 Wallace and Tiernan gages to reach full scale. Close and torque the valve after this pressure range has been reached.
- ✓✓✓ 6.3.11 Open V₁₁ for 30 seconds and then torque closed. Torque valve V₄ closed to 2 1/2 in lbs.
- ✓✓✓ 6.3.12 Wait 20 minutes. Reset the clock, set both micrometers to 10 millimeters.
- ✓✓✓ 6.3.13 Zero baratron-keep set to appropriate scale.
- ✓✓✓ 6.3.14 Close ~~V₅, V₈~~ V₆ & V₇
- ✓✓✓ 6.3.15 Wait 5 minutes.
- ✓✓✓ 6.3.16 Rzero Baratron with large micrometer - keep small micrometer set at 10mm.
- ✓✓✓ 6.3.17 When the baratron is nulled, start the clock - record small micrometer.
- ✓✓✓ 6.3.18 Maintain a null reading for 10 minutes or 10mm on the micrometer, which ever comes first, adjusting the small micrometer.
- ✓✓✓ 6.3.19 Turn off clock when the baratron is again nulled.
- ✓✓✓ 6.3.20 Open valves ~~V₅ and V₈~~ V₆ & V₇

ORIGINAL PAGE 13
OF POOR QUALITY



**Aerospace
Systems Division**

**Calibration Station
Molecular Leak Test Procedures
for the Viking UAMS**

No.	Rev. No.
TP2374339	A
Page <u>7</u> of <u> </u>	
Draw	

✓✓✓ 6.3.21

Record the small micrometer reading and the clock readings.
Calculate leak rate per direction on Data Table.

✓✓✓ 6.3.22

Also determine whether this effective leak rate is acceptable
by comparison with limits in the table.

✓✓✓ 6.3.23

If leak rate is not acceptable, repeat steps 6.3.22 thru 6.3.22.

✓✓✓ 6.3.24

Open inlet valve V11.

✓✓✓ 6.3.25

Reset the clock and set both micrometers to 20 millimeters.

✓✓✓ 6.3.26

Wait 10 minutes.

✓✓✓ 6.3.27

Zero baratron.

✓✓✓ 6.3.28

Close valves V5 and V8. $V_6 \neq V_7$

✓✓✓ 6.3.29

Quickly set the large micrometer to 15 millimeters.
Keep the Baratron on an appropriate scale (readable).

✓✓✓ 6.3.30

When the Baratron passes through zero, start the clock.

✓✓✓ 6.3.31

Reset the large micrometer to 5 millimeters.

✓✓✓ 6.3.32

When the Baratron again passes through zero, stop the clock.

✓✓✓ 6.3.33

Immediately open valves V5, and V8. $V_6 \neq V_7$

✓✓✓ 6.3.34

Record the large micrometer readings and the clock readings
in appropriate table.

✓✓✓ 6.3.35

~~Calculate the leak rates per paragraph 6.3.22 of TP2374339.~~

✓✓✓ 6.4

High Pressure (400 torr) Leak Calibration

✓✓✓ 6.4.1

Open valve V4.

✓✓✓ 6.4.2

Repeat steps 6.3.30 thru 6.3.35 except at a pressure of 400
to 500 torr.

✓✓✓ 6.5

Gas inlet system is now ready for use.

**ORIGINAL PAGE 13
OF POOR QUALITY**

6.6 Inlet System evacuation

After the inlet system has been calibrated and used for UAMS testing, it should be returned to the standby condition as follows.

- 6.6.1 Check to see if cryo pump or mechanical pump trap is full of LN₂.
- 6.6.2 Close gas cylinder valve.
- 6.6.3 Close Black gas supply valve.
- 6.6.4 Bleed gas inlet pressure to 50f.
- 6.6.5 Open V23.
- 6.6.6 Open appropriate roughing valve V18, V19 or V20.
- 6.6.7 Open V1, 3, and 11.
- 6.6.8 Open V4. When pressure is less than 20 torr, open V21.
- 6.6.9 When the pressure is less than 1 torr, open V9, V13 and V14 slowly.
- 6.6.10 Slowly open V2 to a 201/s ion pump current of 15 ma maximum.
- 6.6.10.1 Replace nut on valve V10.
- 6.6.11 Slowly open V10 - Do not let Calibration Station pressure exceed 5×10^{-6} torr.
- 6.6.12 Continue pumping until V2 and V10 are open.
- 6.6.13 Continue pumping until V1 can be closed.
- 6.6.14 If the pressures rise when V1 is closed, reopen.
- 6.6.15 If the pressures decreases when V1 is closed, leave closed and torque to 2 1/2 inch pound.
- 6.6.16 Switch 20 l/sec pump control unit to PRESSURE. Inlet system is now in standby.

ORIGINAL PAGE IS
OF POOR QUALITY

TP2374339 Rev. A

PAGE 9


DATE

Calibration Station Molecular Leak Test Procedure for the Viking UAMS




WALL
THERM
GAUGES

MICROMETERS



BUFFER



V15 CALIBRATED
CHAMBER


V12A

V10 CRYO

V11 CRYO

V12 SYSTEM PUT
FOR RECALIBRATION
PUMP

HEAT EXCHANGE
TO GAS RACK



ORIGINAL PAGE 19
OF POOR QUALITY

TO
PUMP

TO
PUMP



Calibration Station
Molecular Leak Test Procedure
for the Viking UASMS

Calibration Station
Molecular Leak Test Procedure
for the Viking UASMS

TP2374339
PAGE 10
DATE

DATA SHEET

LEAK CHECK

Run No. 1 (40 Torr)

Gas Used Nitrogen

Clock Time

Temperature, °F

Pressure, Torr

Small micrometer, reading 1

Small micrometer, reading 2

Small micrometer, difference

Multiply by 0.9855×10^{-6} li/mm

Time, seconds

Divide by Time

(If available)

Chamber 1 gauge, Torr

Pump 1 gauge, Torr

Nitrogen

1:22 p.m. t = 0

75.9

44.4

10.0 mm

20.0 mm

10.0 mm

0.9855 $\times 10^{-5}$

212

4.65 $\times 10^{-8}$ liters/sec

Maximum Permissible	
H ₂	4×10^{-7}
He	2×10^{-7}
N ₂	1×10^{-7}
O ₂	9×10^{-8}
Ar	8×10^{-8}
CO ₂	8×10^{-8}
CO	1×10^{-7}

LEAK CALIBRATION

Run No. 1 (40 Torr)

Gas Used

Clock Time

Temperature, °F

Pressure, Torr

Large micrometer, reading 1

Large micrometer, reading 2

Large micrometer, difference

Multiply by 1.0079×10^{-6} li/mm

Time, seconds

Divide by time

(If available)

Chamber 1 gauge, Torr

Pump 1 gauge, Torr

Nitrogen

2:01 p.m.

75.7

43.5

15.0 mm

5.0 mm

10.0 mm

1.0079 $\times 10^{-3}$

196

5.14 $\times 10^{-6}$ liters/sec

Minimum Permissible	
H ₂	2×10^{-5}
He	1×10^{-5}
N ₂	5×10^{-6}
O ₂	4×10^{-6}
Ar	4×10^{-6}
CO ₂	4×10^{-6}
CO	5×10^{-6}

ORIGINAL PAGE 10
OF POOR QUALITY

TP2574339

PAGE

DATE

Calibra' Station
Molecular I Test Procedure
for the Viking UAMS

DATA SHEET

LEAK CHECK

Run No. 1 (400 Torr)

Gas Used

Clock Time

Temperature, °F

Pressure, Torr

Small micrometer, reading 1

Small micrometer, reading 2

Small micrometer, difference

Multiply by $0.9255 \times 10^{-6} / \text{mm}$

Time, seconds

Divide by Time

(If available)

Chamber I gauge, Torr

Pump I gauge, Torr

Nitrogen

3:11 p.m.

75.0

449

10.00 mm

11.45 mm

1.45 mm

 1.43×10^{-6}

6.00

 $2.38 \times 10^{-9} \text{ liters/sec}$

Maximum Permissible

H₂ 4×10^{-7} He 2×10^{-7} N₂ 1×10^{-7} O₂ 9×10^{-8} Ar 8×10^{-8} CO₂ 8×10^{-8} CO 1×10^{-7}

LEAK CALIBRATION

Run No. 1 (400 Torr)

Gas Used

Clock Time

Temperature, °F

Pressure, Torr

Large micrometer, reading 1

Large micrometer, reading 2

Large micrometer, difference

Multiply by 1.0079×10^{-6}

Time, seconds

Divide by time

(If available)

Chamber I gauge, Torr

Pump I gauge, Torr

Nitrogen

3:45 p.m.

74.6

447

15.0 mm

5.0 mm

10.0 mm

 $1.0079 \times 10^{-3} \text{ liters}$

195

 $5.17 \times 10^{-6} \text{ liters/sec}$

Minimum Permissible

H₂ 2×10^{-5} He 1×10^{-5} N₂ 5×10^{-6} O₂ 4×10^{-6} Ar 4×10^{-6} CO₂ 4×10^{-6} CO 5×10^{-6} ORIGINAL PAGE IS
OF POOR QUALITY

Form

Aerospace
Systems Division

Calibration at Procedure
Molecular Leak for the Viking UAMS

TP2374339

12

PAGE

DATE

DATA SHEET

LEAK CHECK (40 Torr)

Run No. 1	Oxygen
Gas Used	2:00 p.m. 1-25-82
Clock Time	75.0 °F
Temperature, °F	44.5
Pressure, Torr	10.0 mm
Small micrometer, reading 1	20.0 mm
Small micrometer, reading 2	10.0 mm
Small micrometer, difference	0.9855 x 10 ⁻⁵ liters
Multiply by 0.9855 x 10 ⁻⁶ l/mm	6.82
Time, seconds	1.45 x 10 ⁻⁸ liters/second
Divide by Time	
(If available)	
Chamber 1 gauge, Torr	
Pump 1 gauge, Torr	


Maximum Permissible	
H ₂	4 x 10 ⁻⁷
He	2 x 10 ⁻⁷
N ₂	1 x 10 ⁻⁷
O ₂	9 x 10 ⁻⁸
Ar	8 x 10 ⁻⁸
CO ₂	3 x 10 ⁻⁸
CO	1 x 10 ⁻⁷

LEAK CALIBRATION (40 Torr)

Run No. 1	Oxygen
Gas Used	2:30 p.m. 1-25-82
Clock Time	75.2 °F
Temperature, °F	43.85
Pressure, Torr	15.0 mm
Large micrometer, reading 1	5.0 mm
Large micrometer, reading 2	10.0 mm
Large micrometer, difference	1.0079 x 10 ⁻³ liters
Multiply by 1.0079 x 10 ⁻³ l/mm	2.08
Time, seconds	4.85 x 10 ⁻⁶ liters/second
Divide by time	
(If available)	
Chamber 1 gauge, Torr	
Pump 1 gauge, Torr	

Minimum Permissible	
H ₂	2 x 10 ⁻⁵
He	1 x 10 ⁻⁵
N ₂	5 x 10 ⁻⁵
O ₂	4 x 10 ⁻⁶
Ar	4 x 10 ⁻⁶
CO ₂	4 x 10 ⁻⁶
CO	5 x 10 ⁻⁶

ORIGINAL PAGE IS
OF POOR QUALITY



Environmental
Engineering Division

Calibration Station
Molecular Leak Test Procedure
for the Viking UAMS

NO. TP2374339

REV. NO.

PAGE 13

4478

DATA SHEET

LEAK CHECK
Run No. 1 (400 Torr)


Gas Used	Oxygen
Clock Time	3:15 p.m. 1-25-82
Temperature, °F	75.3 °F
Pressure, Torr	450.0
Small micrometer, reading 1	10.0 mm
Small micrometer, reading 2	0.0 mm
Small micrometer, difference	10.0 mm
Multiply by $0.9555 \times 10^{-6} \text{ l/mm}$	$0.9555 \times 10^{-5} \text{ liters}$
Time, seconds	409
Divide by Time	$2.4 \times 10^{-8} \text{ liters/sec}$
(If available)	
Chamber 1 gauge, Torr	
Pump 1 gauge, Torr	

Maximum Permissible	
H ₂	4×10^{-7}
He	2×10^{-7}
N ₂	1×10^{-7}
O ₂	9×10^{-8}
Ar	8×10^{-8}
CO ₂	8×10^{-8}
CO	1×10^{-7}

LEAK CALIBRATION
Run No. 1 (400 Torr)

Gas Used	Oxygen
Clock Time	3:35 p.m. 1-25-82
Temperature, °F	75.3 °F
Pressure, Torr	445.0
Large micrometer, reading 1	15.0 mm
Large micrometer, reading 2	5.0 mm
Large micrometer, difference	10.0 mm
Multiply by $1.0079 \times 10^{-6} \text{ l/mm}$	$1.0079 \times 10^{-5} \text{ liters}$
Time, seconds	207
Divide by time	$4.87 \times 10^{-6} \text{ liters/sec}$
(If available)	
Chamber 1 gauge, Torr	1100 Torr
Pump 1 gauge, Torr	

Minimum Permissible	
H ₂	2×10^{-5}
He	1×10^{-5}
N ₂	5×10^{-6}
O ₂	4×10^{-6}
Ar	4×10^{-6}
CO ₂	4×10^{-6}
CO	5×10^{-6}



Aviation
Systems Division

Calibration Station
Molecular Leak Test Procedure
for the Viking UAMS

NO. TP2374339

REV. NO.

PAGE

14

DATE

DATA SHEET

LEAK CHECK

Run No. 2 (40 Torr)

Gas Used

Clock Time

Temperature, °F

Pressure, Torr

Small micrometer, reading 1

Small micrometer, reading 2

Small micrometer, difference

Multiply by 0.9855×10^{-6}

Time, seconds

Divide by Time

(if available)

Chamber 1 gauge, Torr

Pump 1 gauge, Torr

Nitrogen

1:15 p.m. 1-29-82

77.3 °F

45 Torr

10.0 mm

17.2 mm

7.2 mm

7.10×10^{-6} liters

6.03

1.18×10^{-8} liters/sec

Maximum Permissible

H ₂	4×10^{-7}
He	2×10^{-7}
N ₂	1×10^{-7}
O ₂	9×10^{-8}
Ar	8×10^{-8}
CO ₂	8×10^{-8}
CO	1×10^{-7}

LEAK CALIBRATION

Run No. 2 (40 Torr)

Gas Used

Clock Time

Temperature, °F

Pressure, Torr

Large micrometer, reading 1

Large micrometer, reading 2

Large micrometer, difference

Multiply by 1.0079×10^{-4}

Time, seconds

Divide by time

(if available)

Chamber 1 gauge, Torr

Pump 1 gauge, Torr

Nitrogen

1:45

76.8 °F

43 Torr

15.0 mm

5.0 mm

10.0 mm

1.0079×10^{-3}

179

5.63×10^{-6} liters/sec

Minimum Permissible

H ₂	2×10^{-5}
He	1×10^{-5}
N ₂	5×10^{-6}
O ₂	4×10^{-6}
Ar	4×10^{-6}
CO ₂	4×10^{-6}
CO	5×10^{-6}

ORIGINAL PAGE IS
OF POOR QUALITY

Calibration Station
Molecular Test Procedure
for the Aging UAMS

PAGE

15

DATE

ALAN C. BROWN
Systems Division

DATA SHEET

LEAK CHECK (400 Torr)

Run No.	2	(400 Torr)
Gas Used	Nitrogen	
Clock Time	2:20 p.m. 1-29-82	
Temperature, °F	76.8°F	
Pressure, Torr	439 Torr	
Small micrometer, reading 1	10.0 mm	
Small micrometer, reading 2	0.0 mm	
Small micrometer, difference	10.0 mm	
Multiply by 0.9855×10^{-3} liters		
Time, seconds	26.0	
Divide by Time	3.79×10^{-8} liters/sec	
(If available)		
Chamber 1 gauge, Torr	1.5×10^{-5} Torr	
Pump 1 gauge, Torr	Chamber Pressure	

Maximum Permissible	
H ₂	4×10^{-7}
He	2×10^{-7}
N ₂	1×10^{-7}
O ₂	9×10^{-8}
Ar	8×10^{-8}
CO ₂	8×10^{-8}
CO	1×10^{-7}

ORIGINAL PAGE IS
OF POOR QUALITY

Minimum Permissible	
H ₂	2×10^{-5}
He	1×10^{-5}
N ₂	5×10^{-6}
O ₂	4×10^{-6}
Ar	4×10^{-6}
CO ₂	4×10^{-6}
CO	5×10^{-6}

LEAK CALIBRATION

Run No. 2 (400 Torr)

Gas Used	Nitrogen	
Clock Time	3:00 p.m. 1-29-82	
Temperature, °F	76.4°F	
Pressure, Torr	435 Torr	
Large micrometer, reading 1	15.0 mm	
Large micrometer, reading 2	5.0 mm	
Large micrometer, difference	10.0 mm	
Multiply by 1.0079×10^{-3} liters		
Time, seconds	178 seconds	
Divide by time	5.66×10^{-6} liters/sec	
(If available)		
Chamber 1 gauge, Torr		
Pump 1 gauge, Torr		

As-Run
started 2-23-82

6.2 DYNAMIC CALIBRATION

The dynamic calibration procedure admits nitrogen to the SUMS inlet in a controlled pressure rise from a pressure of approximately 10^{-4} to approximately 25 Torr. During the pressure rise the nitrogen 28 and 14 peaks, as measured by the SUMS instrument, are recorded on tape. Two pressure profiles are run. The admission of the gas, the data taking and recording are controlled by the test configuration. The response of the instrument from this test will be compared to the static calibration to determine the time response of the instrument.

In addition to the nitrogen peaks data, the following is also recorded once every five seconds: one SUMS housekeeping word; the twelve UAMS housekeeping words; the inlet pressure as measured by the baratron heads; the inlet pressure as measured by the SUMS inlet pressure transducer; and the time.

Only six consecutive data points (single scan mode) are stored for each of the two nitrogen peaks. These points are selected by finding the largest value for the peak and recording that value, the two values immediately before it, and the three values immediately following it.

This test is run using filament number 1 only.

6.2.1 Vacuum System Set-Up

6.2.1.1 Verify or implement the following vacuum conditions:

Calibration Station Ion Pump in Protect Mode.

Valve V-15 Closed.

Calibration Station Ion Pump On.

Liquid Helium Pump Valved Off.

Calibration Station Butterfly Valve Open.

Orifice Open.

Cryopump Cold.

Throttling Valve fully Open.

MKS Servo Valve Closed.

6.2.1.2 Verify nitrogen tank is connected to valve V30.

6.2.1.3 Close valve V30 and open V31. Verify pressure on servo valve is less than 50 microns.

6.2.1.4 Verify chamber pressure is less than 1.0×10^{-7} Torr.

1.0 X 10⁻⁸ T.

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
A

SCALE

WEIGHT

SHEET 41

ORIGINAL PAGE IS
OF POOR QUALITY

6.2.2.4 HP1610A Logic State Analyzer

6.2.2.4.1 Connect pods 1 and 2 to the 16 bit parallel SUMS digital data lines. These lines are available inside the GSE Interface Unit. ✓

6.2.2.4.2 Connect the clock pod to the SUMS data strobe inside the GSE Interface Unit. ✓

6.2.2.4.3 Set analyzer power to ON. ✓

6.2.2.5 Fluke 8520A Digital Multimeter

6.2.2.5.1 Verify multimeter is connected to MKS electronics. ✓

6.2.2.5.2 Set power switch to ON. ✓

6.2.2.6 HP6942A Multiprogrammer

6.2.2.6.1 Verify multiprogrammer is connected to MKS electronics (D/A and digital output) and the inlet transducer 0-5V output inside the GSE Interface Unit (A/D). ✓

6.2.2.6.2 Set power switch to ON. ✓

6.2.2.7 HP 85 Computer

6.2.2.7.1 Verify the HP 85 is connected to the Logic State Analyzer, the Multiprogrammer and the Digital Multimeter via the IEEE-488 bus. ✓

6.2.2.7.2 Set power switch to ON. ✓

6.2.2.7.3 Insert SUMS programs tape. ✓

6.2.2.8 MKS Type 244A Valve Controller

6.2.2.8.1 Set power switch to ON. ✓

6.2.2.8.2 Set Phase Lead control to 5.0. ✓

6.2.2.8.3 Set Gain control to 100%. ✓

6.2.2.8.4 Set function rotary switch to CLOSED. ✓

6.2.2.9 MKS 170M-27D Digital Display

6.2.2.9.1 Set display units to TORR. ✓

6.2.2.9.2 Set Head Range to MPLX. ✓

6.2.2.9.3 Set sampling switch to AUTO. ✓

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP3290648	REV A
SCALE	WEIGHT	SHEET 43	

6.2.2.10 MKS 170M-6C Range Multiplier

6.2.2.10.1 Set power switch to ON.

6.2.2.10.2 Set heater switch to OFF.

6.2.2.10.3 Set response switch to FAST.

6.2.2.10.4 Set range switch to .01.

6.2.2.11 MKS 170M-34C Head Selector

6.2.2.11.1 Verify CH.1 and CH.2 heaters have been on for a minimum of 4 hours.

6.2.2.11.2 Set selector switch to CH.1.

6.2.2.11.3 Set CH.1 head range switch to 1 Torr.

6.2.2.11.4 Adjust CH.1 coarse/fine zero for 0.000 nominal.

6.2.2.11.5 Set selector switch to CH.2.

6.2.2.11.6 Set CH.2 head range switch to 100 Torr.

6.2.2.11.7 Adjust CH.2 coarse fine zero for 0.000 nominal.

6.2.2.12 Chart Recorder

6.2.2.12.1 Connect chart recorder across input to Fluke digital multimeter.

6.2.2.12.2 Set power switch to ON.

ORIGINAL PAGE 18
OF POOR QUALITY

NOTE

The Chart Recorder is to be used during the running of this test to indicate to the operator how smoothly the pressure is changing between five second steps. The recorder sensitivity should be changed as necessary to maximize the deflection of the pen.

6.2.3 Inst. Turn-On and Warm-Up

6.2.3.1 Turn on the SUMS Ion Pump Power with the switch on the GSE I/F Unit.

6.2.3.2 Wait one minute for UAMS ion pump to come on.

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP3290648	REV A
SCALE	WEIGHT	SHEET	44

ORIGINAL PAGE IS
OF POOR QUALITY

- 6.2.3.3 From the ion pump current monitor, verify that the instrument internal pressure is less than 1×10^{-5} Torr. ✓
- 6.2.3.4 Using the switches on the GSE I/F Unit, open the Protection, Range and Inlet valves. ✓
- 6.2.3.5 Turn on the SUMS Instrument Power with the switch on the GSE I/F Unit. ✓
- 6.2.3.6 Wait two hours minimum for the instrument ion source to warm-up. ✓
- 6.2.3.7 Using the 1610 logic analyser, verify the ion source temperature as recorded in the UAMS Housekeeping is at least 87 decimal. (Record value.) 90.10
- 6.2.3.8 Record thermocouple temperatures from Data Logger.
- | | |
|-----|----------------|
| T11 | <u>74.4</u> °F |
| T12 | <u>73.7</u> °F |
| T15 | <u>80.9</u> °F |
- 6.2.4 SUMS Background Spectra (Before Run)
- 6.2.4.1 Turn on the HP9830 calculator, printer, cassette memory and plotter. ✓
- 6.2.4.2 Place a marked data tape in the cassette memory and rewind it. ✓
- 6.2.4.3 Place the SUMS Functional test cassette tape in the calculator. ✓
- 6.2.4.4 Verify that the cryopump is still cold and that its pressure is less than 50 microns. ✓
- 6.2.4.5 Load and run file ϕ on the calculator. The program is interactive from this point. Continue with paragraph 6.2.4.5 when the calculator has finished. Record data tape information below.
- SUMS Data Tape I.D. # 8
- Bulk File # (1,2,3, or 4) 1 ✓
- 6.2.5 Final Preparations
- 6.2.5.1 Set GSE I/F valve control switch to SUMS position. ✓

4E BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP329064R	REV A
SCALE	WEIGHT	SHEET 45	

- 6.2.5.2 Open the two nitrogen tank valves and set regulator to 3 PSI.
- 6.2.5.3 Purge the gas supply line with nitrogen.
- 6.2.5.4 Close valve V31 and open valve V30.
- 6.2.5.5 Close calibration station throttling valve and then reopen one full turn.
- 6.2.5.6 On the HP 85 computer load the "DYNAM" program file.
- 6.2.5.7 Verify calibration station Ion Pump START/PROTECT switches is in the PROTECT position.
- Variation* 6.2.5.8 Verify instrument is running on filament # 1.
 6.2.5.9 Set orifice to 10 liter/sec.
 6.2.6 Data Collection (Nominal)

✓
 ✓
 ✓
 ✓
 ✓
 ✓
 ✓
 ✓

NOTE

During the simulation of the re-entry pressure profile the gain and phase controls are to be manually adjusted to obtain as "smooth" a curve as possible. "Smooth" is defined as a linear change in pressure from one point to the next point five seconds later. The chart recorder shall be used by the test conductor throughout the run to determine how smoothly the pressure is rising.

ORIGINAL PAGE IS
 OF POOR QUALITY

Multiple runs of the pressure profile may be made, as determined necessary by the test conductor, in order to fully cover the pressure profile.

- 6.2.6.1 Start the paper in the chart recorder. (Slow)
- 6.2.6.2 Type RUN on the HP 85 computer. The program is interactive from this point, through the collection of all data. Continue with paragraph 6.2.6.3 when the program has finished.
- 6.2.6.3 Close the MKS valve and stop chart recorder.

✓
 ✓
 ✓

THE BENDIX COMMUNICATIONS DIVISION
 AEROSPACE SYSTEMS OPERATIONS
 ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP3290648	REV A
SCALE	WEIGHT	SHEET 46	

ORIGINAL PAGE IS
OF POOR QUALITY

- 6.2.6.4 Load the "30XFER" program on the HP 85. Transfer all data to the HP 9830. Record data tape information below:

NOMINAL

Run #	Tape # (200 Series)	Bulk File #
1	201	1
2	201	2
3	201	3
4		

- 6.2.6.5 Pump down calibration station using the cryo and ion pumps. Open the throttling valve.
- 6.2.6.6 Repeat paragraphs 6.2.5 and 6.2.6 as required in order to adequately cover the complete pressure profile with the desired amount of smoothness.
- 6.2.7 Data Collection (+ 25% P/P)
- 6.2.7.1 Close calibration station throttling valve and then reopen one full turn.
- 6.2.7.2 Verify calibration station ion pump START/PROTECT switch is in the PROTECT position.
- 6.2.7.3 On the HP 85 computer, load the "DYNAM" program file.
- 6.2.7.4 Start the paper in the chart recorder.
- 6.2.7.5 Type RUN on the HP 85. (and run calibration test)
- 6.2.7.6 Close MKS valve and stop chart recorder.
- 6.2.7.7 Load the "30XFER" program on the HP 85. Transfer all data to the HP 9830. Record data type information below:

✓
✓
✓
✓
✓
✓
✓
✓

AE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP3290648	REV A
SCALE	WEIGHT	SHEET 47	

ORIGINAL PAGE IS
OF POOR QUALITY

+ 25% P/P

Run #	Tape # (200 Series)	Bulk File #
1	201	4
2	202	1
3		
4		

- 6.2.7.8 Pump down calibration station using the cryo and ion pumps.
Open the throttling valve. ✓
- 6.2.7.9 Repeat paragraph 6.2.7 as required. ✓
- 6.2.8 SUMS Background Spectra (After Run)
- 6.2.8.1 Close valve V30 and open V31. ✓
- 6.2.8.2 Place a marked data tape in the cassette memory and rewind. ✓
- 6.2.8.3 Place the SUMS Functional Test cassette tape in the calculator. ✓
- 6.2.8.4 Verify that the cryo pump is cold and that its pressure
is less than 50 microns. ✓
- 6.2.8.5 Verify chamber pressure is less than 1.0×10^{-7} Torr.
Record. *orifice open.* 3×10^{-8} Torr ✓
- 6.2.8.6 Load and run file ϕ . Record data tape information below:

SUMS Data Tape I.D. # 008
Bulk File # (1,2,3
or 4) 2

- 6.2.8.7 Record Thermocouple temperatures. ✓

*temperature extremes
during test (both days)*

T11 74.1 °F
T12 73.4 °F
T15 80.9 °F

- 6.2.9 Instrument Turn-Off

	max	min
T11	75.63	72.6
T12	74.4	71.7
T15	80.9	78.4

- 6.2.9.1 Turn off SUMS ion pump and instrument power. ✓

THE BENDIX CORPORATION
Aerospace Systems Operations
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648

REV
A

SCALE

WEIGHT

SHEET 48

6.2.9.2 Turn on SUMS Vacuum Maintenance Power.

6.2.9.3 Attach all data to this procedure, including chart recorder output tapes.

END OF SUMS DYNAMIC CALIBRATION

test completed 2-24-82

ORIGINAL PAGE IS
OF POOR QUALITY

THE BENDIX CORPORATION
Aerospace Systems Operations
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP3290648


REV
A

SCALE

WEIGHT

SHEET 49

tape # 008
file # 1



ION PUMP ANALOG	0.0020
28 VOLT POWER SUP	28.360

ORIGINAL PAGE IS
OF POOR QUALITY

2 22 1982 1104 HPS

SUMC S H C
FUNCTIONAL TEST

PAGE 2 OF 6


75 ELECTRON VOLTS IONIZATION ENERGY

SCAN STEP	-----HIGH MASS COLLECTOR-----				-----LOW MASS COLLECTOR-----			
NO	SCAN 1	SCAN 2	SCAN 3	SCAN 4	SCAN 1	SCAN 2	SCAN 3	SCAN 4
1			200	0	4			
2			200	0		4		
3			200	0			4	
4			200	0				4
5			200	0				
6			200	0	4			
7			200	0		4		
8			200	0			4	
9			200	0				4
10			200	0	4			
11			200	0		4		
12			200	0			4	
13			200	0				4
14			200	0				
15			200	0	4			
16			200	0		4		
17			200	0			4	
18			200	0				4
19			200	0	4			
20			200	0		4		
21			200	0			4	
22			200	0				4
23			200	0	4			
24			200	0		4		
25			200	0			4	
26			200	0				4
27			200	0	4			
28			200	0		4		
29			200	0			4	
30			200	0				4
31			200	0	4			
32			200	0		4		
33			200	0			4	
34			200	0				4
35			200	0	4			
36			200	0		4		
37			200	0			4	
38			200	0				4
39			200	0	4			
40			200	0		4		
41			200	0			4	
42			200	0				4
43			200	0	4			
44			200	0		4		
45			200	0			4	
46			200	0				4
47			200	0	4			
48			200	0		4		
49			200	0			4	
50			200	0				4

ORIGINAL PAGE 13
OF POOR QUALITY

20 23 1902 1104 6

PAGE 3 OF 8



01	23				4			
02	00					4		
03	00						4	
04	00							4
05	00							
06	00				4			
07	00					4		
08	00						4	
09	00							4
10	00				4			
11	00					4		
12	00						4	
13	00							12
14	00				4			
15	00					4		
16	00						4	
17	00				4			
18	00					4		
19	00						4	
20	00							4
21	00				4			
22	00					4		
23	00						4	
24	00				4			
25	00					4		
26	00						4	
27	00				4			
28	00					4		
29	00						4	
30	00				4			
31	00					4		
32	00						4	
33	00				4			
34	00					4		
35	00						4	
36	00				4			
37	00					4		
38	00						4	
39	00				4			
40	00					4		
41	00						4	
42	00				4			
43	00					4		
44	00						4	
45	00				4			
46	00					4		
47	00						4	
48	00				4			
49	00					4		
50	00						4	
51	00				4			
52	00					4		
53	00						4	
54	00				4			
55	00					4		
56	00						4	
57	00				4			
58	00					4		
59	00						4	
60	00				4			
61	00					4		
62	00						4	
63	00				4			
64	00					4		
65	00						4	
66	00				4			
67	00					4		
68	00						4	
69	00				4			
70	00					4		
71	00						4	
72	00				4			
73	00					4		
74	00						4	
75	00				4			
76	00					4		
77	00						4	
78	00				4			
79	00					4		
80	00						4	
81	00				4			
82	00					4		
83	00						4	
84	00				4			
85	00					4		
86	00						4	
87	00				4			
88	00					4		
89	00						4	
90	00				4			
91	00					4		
92	00						4	
93	00				4			
94	00					4		
95	00						4	
96	00				4			
97	00					4		
98	00						4	
99	00				4			
100	00					4		
101	00						4	
102	00				4			
103	00					4		
104	00						4	
105	00				4			
106	00					4		
107	00						4	
108	00							4
109	00							
110	00							

ORIGINAL PAGE IS
OF POOR QUALITY

7-23-1962 1104 E

PAGE 4 OF 6

111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170

$\frac{1}{\sqrt{2}}$

$\frac{1}{\sqrt{\pi}} \int_{-\infty}^{\infty} f(x) e^{-x^2} dx = \frac{1}{\sqrt{\pi}}$

\mathbb{P}_1 \mathbb{P}_2 \mathbb{P}_3 \mathbb{P}_4 \mathbb{P}_5 \mathbb{P}_6 \mathbb{P}_7 \mathbb{P}_8 \mathbb{P}_9 \mathbb{P}_{10} \mathbb{P}_{11} \mathbb{P}_{12} \mathbb{P}_{13} \mathbb{P}_{14} \mathbb{P}_{15} \mathbb{P}_{16} \mathbb{P}_{17} \mathbb{P}_{18} \mathbb{P}_{19} \mathbb{P}_{20} \mathbb{P}_{21} \mathbb{P}_{22} \mathbb{P}_{23} \mathbb{P}_{24} \mathbb{P}_{25} \mathbb{P}_{26} \mathbb{P}_{27} \mathbb{P}_{28} \mathbb{P}_{29} \mathbb{P}_{30} \mathbb{P}_{31} \mathbb{P}_{32} \mathbb{P}_{33} \mathbb{P}_{34} \mathbb{P}_{35} \mathbb{P}_{36} \mathbb{P}_{37} \mathbb{P}_{38} \mathbb{P}_{39} \mathbb{P}_{40} \mathbb{P}_{41} \mathbb{P}_{42} \mathbb{P}_{43} \mathbb{P}_{44} \mathbb{P}_{45} \mathbb{P}_{46} \mathbb{P}_{47} \mathbb{P}_{48} \mathbb{P}_{49} \mathbb{P}_{50} \mathbb{P}_{51} \mathbb{P}_{52} \mathbb{P}_{53} \mathbb{P}_{54} \mathbb{P}_{55} \mathbb{P}_{56} \mathbb{P}_{57} \mathbb{P}_{58} \mathbb{P}_{59} \mathbb{P}_{60} \mathbb{P}_{61} \mathbb{P}_{62} \mathbb{P}_{63} \mathbb{P}_{64} \mathbb{P}_{65} \mathbb{P}_{66} \mathbb{P}_{67} \mathbb{P}_{68} \mathbb{P}_{69} \mathbb{P}_{70} \mathbb{P}_{71} \mathbb{P}_{72} \mathbb{P}_{73} \mathbb{P}_{74} \mathbb{P}_{75} \mathbb{P}_{76} \mathbb{P}_{77} \mathbb{P}_{78} \mathbb{P}_{79} \mathbb{P}_{80} \mathbb{P}_{81} \mathbb{P}_{82} \mathbb{P}_{83} \mathbb{P}_{84} \mathbb{P}_{85} \mathbb{P}_{86} \mathbb{P}_{87} \mathbb{P}_{88} \mathbb{P}_{89} \mathbb{P}_{90} \mathbb{P}_{91} \mathbb{P}_{92} \mathbb{P}_{93} \mathbb{P}_{94} \mathbb{P}_{95} \mathbb{P}_{96} \mathbb{P}_{97} \mathbb{P}_{98} \mathbb{P}_{99} \mathbb{P}_{100}

Table 1

4
4
4
4
4
4
4
4
4
4
4
4

4
4
4
4
4
4
4
4
4
4
4

4
4
4
4
4
4
4
4
4
4
4

12
12
4
4
4
4
4
4
4
4
4

12

12

4

4

4

4

4

4

4

4

1

ORIGINAL PAGE IS
OF POOR QUALITY

1 1981 1104

PAGE 5 OF 8

171	0	0	0	4			
172	0	0	0		4		
173	0	0	0			4	
174	0	0	0				4
175	0	0	0				
176	0	0	0	4			
177	0	0	0		4		
178	0	0	0			4	
179	0	0	0				4
180	0	0	0				
181	0	0	0	4			
182	0	0	0		4		
183	114	0	0			4	
184	0	0	0				4
185	0	0	0				
186	0	0	0	4			
187	0	0	0		4		
188	0	0	0			4	
189	0	0	0				4
190	0	0	0				
191	0	0	0	4			
192	0	0	0		4		
193	0	0	0			4	
194	0	0	0				4
195	114	0	0				
196	0	0	0	4			
197	0	0	0		4		
198	0	0	0			4	
199	0	0	0				4
200	0	0	0				
201	0	0	0	4			
202	0	0	0		4		
203	0	0	0			4	
204	0	0	0				4
205	0	0	0				
206	0	0	0	4			
207	0	0	0		4		
208	0	0	0			119	
209	0	0	0				1450
210	0	0	0				
211	0	0	0	2960			
212	0	0	0		3630		
213	0	0	0			3815	
214	0	0	0				3875
215	0	0	0				
216	0	0	0	3875			
217	0	0	0		3875		
218	0	0	0			3875	
219	0	0	0				4090
220	0	0	0	4090			
221	0	0	0		4090		
222	0	0	0			4090	
223	0	0	0				4090
224	0	0	0				
225	0	0	0	4090			
226	0	0	0		4210		
227	0	0	0			4210	
228	0	0	0				4090
229	0	0	0				
230	0	0	0				

ORIGINAL PAGE IS
OF POOR QUALITY


1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159 160 161 162 163 164 165 166 167 168 169 170 171 172 173 174 175 176 177 178 179 180 181 182 183 184 185 186 187 188 189 190 191 192 193 194 195 196 197 198 199 200 201 202 203 204 205 206 207 208 209 210 211 212 213 214 215 216 217 218 219 220 221 222 223 224 225 226 227 228 229 230 231 232 233 234 235 236 237 238 239 240 241 242 243 244 245 246 247 248 249 250 251 252 253 254 255 256 257 258 259 260 261 262 263 264 265 266 267 268 269 270 271 272 273 274 275 276 277 278 279 280 281 282 283 284 285 286 287 288 289 290 291 292 293 294 295 296 297 298 299 300 301 302 303 304 305 306 307 308 309 310 311 312 313 314 315 316 317 318 319 320 321 322 323 324 325 326 327 328 329 330 331 332 333 334 335 336 337 338 339 340 341 342 343 344 345 346 347 348 349 350 351 352 353 354 355 356 357 358 359 360 361 362 363 364 365 366 367 368 369 370 371 372 373 374 375 376 377 378 379 380 381 382 383 384 385 386 387 388 389 390 391 392 393 394 395 396 397 398 399 400 401 402 403 404 405 406 407 408 409 410 411 412 413 414 415 416 417 418 419 420 421 422 423 424 425 426 427 428 429 430 431 432 433 434 435 436 437 438 439 440 441 442 443 444 445 446 447 448 449 450 451 452 453 454 455 456 457 458 459 460 461 462 463 464 465 466 467 468 469 470 471 472 473 474 475 476 477 478 479 480 481 482 483 484 485 486 487 488 489 490 491 492 493 494 495 496 497 498 499 500 501 502 503 504 505 506 507 508 509 510 511 512 513 514 515 516 517 518 519 520 521 522 523 524 525 526 527 528 529 530 531 532 533 534 535 536 537 538 539 540 541 542 543 544 545 546 547 548 549 550 551 552 553 554 555 556 557 558 559 560 561 562 563 564 565 566 567 568 569 570 571 572 573 574 575 576 577 578 579 580 581 582 583 584 585 586 587 588 589 590 591 592 593 594 595 596 597 598 599 600 601 602 603 604 605 606 607 608 609 610 611 612 613 614 615 616 617 618 619 620 621 622 623 624 625 626 627 628 629 630 631 632 633 634 635 636 637 638 639 640 641 642 643 644 645 646 647 648 649 650 651 652 653 654 655 656 657 658 659 660 661 662 663 664 665 666 667 668 669 670 671 672 673 674 675 676 677 678 679 680 681 682 683 684 685 686 687 688 689 690 691 692 693 694 695 696 697 698 699 700 701 702 703 704 705 706 707 708 709 710 711 712 713 714 715 716 717 718 719 720 721 722 723 724 725 726 727 728 729 730 731 732 733 734 735 736 737 738 739 740 741 742 743 744 745 746 747 748 749 750 751 752 753 754 755 756 757 758 759 760 761 762 763 764 765 766 767 768 769 770 771 772 773 774 775 776 777 778 779 780 781 782 783 784 785 786 787 788 789 790 791 792 793 794 795 796 797 798 799 800 801 802 803 804 805 806 807 808 809 810 811 812 813 814 815 816 817 818 819 820 821 822 823 824 825 826 827 828 829 830 831 832 833 834 835 836 837 838 839 840 841 842 843 844 845 846 847 848 849 850 851 852 853 854 855 856 857 858 859 860 861 862 863 864 865 866 867 868 869 870 871 872 873 874 875 876 877 878 879 880 881 882 883 884 885 886 887 888 889 890 891 892 893 894 895 896 897 898 899 900 901 902 903 904 905 906 907 908 909 910 911 912 913 914 915 916 917 918 919 920 921 922 923 924 925 926 927 928 929 930 931 932 933 934 935 936 937 938 939 940 941 942 943 944 945 946 947 948 949 950 951 952 953 954 955 956 957 958 959 960 961 962 963 964 965 966 967 968 969 970 971 972 973 974 975 976 977 978 979 980 981 982 983 984 985 986 987 988 989 990 991 992 993 994 995 996 997 998 999 1000 1001 1002 1003 1004 1005 1006 1007 1008 1009 1010 1011 1012 1013 1014 1015 1016 1017 1018 1019 1020 1021 1022 1023 1024 1025 1026 1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1038 1039 1040 1

[illegible]

ORIGINAL PAGE 13
OF 2002 QUALITY

20 20 1982 1104 6

PAGE 7 OF 8



0000
0001
0002
0003
0004
0005
0006
0007
0008
0009
0010
0011
0012
0013
0014
0015
0016
0017
0018
0019
0020
0021
0022
0023
0024
0025
0026
0027
0028
0029
0030
0031
0032
0033
0034
0035
0036
0037
0038
0039
0040
0041
0042
0043
0044
0045
0046
0047
0048
0049
0050

0000
0001
0002
0003
0004
0005
0006
0007
0008
0009
0010
0011
0012
0013
0014
0015
0016
0017
0018
0019
0020
0021
0022
0023
0024
0025
0026
0027
0028
0029
0030
0031
0032
0033
0034
0035
0036
0037
0038
0039
0040
0041
0042
0043
0044
0045
0046
0047
0048
0049
0050

0000
0001
0002
0003
0004
0005
0006
0007
0008
0009
0010
0011
0012
0013
0014
0015
0016
0017
0018
0019
0020
0021
0022
0023
0024
0025
0026
0027
0028
0029
0030
0031
0032
0033
0034
0035
0036
0037
0038
0039
0040
0041
0042
0043
0044
0045
0046
0047
0048
0049
0050

0000
0001
0002
0003
0004
0005
0006
0007
0008
0009
0010
0011
0012
0013
0014
0015
0016
0017
0018
0019
0020
0021
0022
0023
0024
0025
0026
0027
0028
0029
0030
0031
0032
0033
0034
0035
0036
0037
0038
0039
0040
0041
0042
0043
0044
0045
0046
0047
0048
0049
0050

0000
0001
0002
0003
0004
0005
0006
0007
0008
0009
0010
0011
0012
0013
0014
0015
0016
0017
0018
0019
0020
0021
0022
0023
0024
0025
0026
0027
0028
0029
0030
0031
0032
0033
0034
0035
0036
0037
0038
0039
0040
0041
0042
0043
0044
0045
0046
0047
0048
0049
0050

4

4

4

4

4

4

4

73

80

65

80

4

4

4

4

12

4

4

42

96

88

68

96

4

4

4

4

4

4

4

50

80

73

73

4

4

4

4

4

4

4

96

96

80

80

50



4

ORIGINAL PAGE 17
OF POOR QUALITY

2/ 23/ 1982 1104 6

PAGE 8 OF 8

*
**
0001 0 0 0 0 4
0002 0 0 0 0 4
0003 0 0 0 0 4
0004 0 0 0 0 4
0005 0 0 0 0 4
0006 0 0 0 0 4
0007 0 0 0 0 4
0008 0 0 0 0 4
0009 0 0 0 0 4
0010 0 0 0 0 4



ORIGINAL PAGE IS
OF POOR QUALITY

2 23 1982 1104 HPS SUMC S H E PAGE 1 OF 8
FUNCTIONAL TEST

DATA TAPE 10 P BULI DATA FILE # 1

SUMC FUNCTIONAL TEST

2 23 1982 1104 C PAGE 8 OF 8

351	0	0	0	0	4			
352	0	0	0	0		4		
353	0	0	0	0			4	
354	0	0	0	0				4
355	0	0	0	0				
356	0	0	0	0	4			
357	0	0	0	0		4		
358	0	0	0	0			4	
359	0	0	0	0				4
360	0	0	0	0				

INTERLACE STEP	1	2	3	4	1	2	3	4	
IONIZATION ENERGY	75	75	75	75	75	75	75	75	
FILAMENT NUMBER	2	2	2	2	2	2	2	2	
CRP ON=1, OFF=2	1	1	1	1	1	1	1	1	
PLUS 15 VOLT	193	193	193	193	193	193	193	193	42.170
MINUS 15 VOLT	129	130	129	129	129	129	130	130	-14.180
ION PUMP VOLT	181	181	181	181	181	181	181	181	7.196
ION SOURCE TEMP	90	91	91	90	90	90	91	90	3.584
PRE-AMP TEMP	169	169	169	169	169	169	169	169	6.797
PLUS 5 VOLT	120	120	120	120	120	120	120	120	4.763
A/D REFERENCE VOLT	163	163	163	163	163	163	163	163	
EMISSION CURRENT	124	124	124	124	124	124	124	124	4.920
COLLECTOR CURRENT	102	102	102	102	102	102	102	102	4.047
ELECTRON ACC VOLT	190	189	189	189	190	189	189	189	7.571
ION ACC VOLT	39	39	39	39	39	39	39	39	1.488

ION PUMP ANALOG	0.0021
28 VOLT POWER SUP	28.360

ORIGINAL PAGE 13
OF POOR QUALITY

2 23 1982 1109 HRS

SUMS
FUNCTIONAL TEST

PAGE 2 OF 8

75 ELECTRON VOLTS IONIZATION ENERGY

SCAN STEP NO	-----HIGH MASS COLLECTOR-----				-----LOW MASS COLLECTOR-----			
	SCAN 1	SCAN 2	SCAN 3	SCAN 4	SCAN 1	SCAN 2	SCAN 3	SCAN 4
1	0	23	0	38	12			
2	0	0	23	0		4		
3	0	0	23	23			4	
4	0	0	0	0				19
5	38	23	0	53				
6	0	0	0	23	4			
7	0	0	0	0		4		
8	0	0	0	23			4	
9	0	0	0	0				4
10	0	0	0	0				
11	0	0	0	0	4			
12	0	0	0	0		4		
13	0	0	0	0			4	
14	0	0	0	0				12
15	0	0	0	0				
16	0	0	0	0	4			
17	0	0	23	0		4		
18	0	0	0	0			12	
19	0	0	0	0				12
20	0	0	0	0				
21	0	0	0	0	4			
22	0	38	23	0		4	12	
23	0	0	0	23				4
24	0	0	0	0				
25	0	0	0	0				
26	53	160	130	160	4			
27	160	191	160	221		4		
28	130	173	173	221			4	
29	130	130	191	191				4
30	23	0	0	23				
31	0	23	0	23	4			
32	0	0	0	23		12		
33	0	0	0	0			4	
34	0	0	38	0				4
35	0	0	0	0				
36	0	0	0	53	4			
37	0	0	0	0		4		
38	0	0	0	0			4	
39	0	53	0	0				4
40	0	0	0	0				
41	0	0	0	0	12			
42	114	173	145	191		4		
43	145	99	145	231			4	
44	160	145	130	173				4
45	145	145	114	53				
46	23	0	0	0	4			
47	0	0	0	0		4		
48	0	0	23	23			4	
49	0	0	0	0				4
50	0	0	0	38				

ORIGINAL PAGE 19
OF POOR QUALITY

20 23 1982 1109 6

PAGE 3 OF 8



100	221	1210	1420	19	12	4	4	12
101	2110	23350	2410	23530	4	4	4	4
102	2470	23530	2470	23530	4	4	4	4
103	2370	23530	2410	2470	12	4	4	12
104	1960	23530	786	2370	4	4	4	4
105	221	23530	23530	23530	4	4	4	4
106	0	23530	23530	23530	4	4	4	4
107	0	23530	23530	23530	4	4	4	4
108	0	23530	23530	23530	4	4	4	4
109	0	23530	23530	23530	4	4	4	4
110	0	23530	23530	23530	4	4	4	4

ORIGINAL PAGE IS
OF POOR QUALITY

2 23 1982 1109 6

PAGE 4 OF 5

111					12			
112						4		
113							4	
114								4
115								
116					4			
117						4		
118							4	
119								4
120								
121					12			
122						4		
123							4	
124								4
125								
126					16			
127						4		
128							12	
129								4
130								
131					4			
132						4		
133							4	
134								4
135								
136					12			
137						12		
138							4	
139								4
140								
141					4		12	
142								4
143							4	
144								4
145								
146					12			
147						12		
148							4	
149								4
150								
151					4			
152						4		
153							12	
154								4
155								
156					4		12	
157								19
158								
159								4
160								
161					12			
162						4		
163							12	
164								27
165								
166					12			
167						4		
168							12	
169								
170								12

ORIGINAL PAGE 13
OF POOR QUALITY

2 23 1982 1109 6

PAGE 5 OF 8





171	8	8	8	88	4			
172	8	8	208	259		12		
173	465	648	694	725			4	
174	694	710	756	755				12
175	694	725	725	740				
176	710	693	542	465	4			
177	145	8	8	52		12		
178	8	8	8	53			4	
179	8	8	8	38				4
180	8	8	8	53				
181	23	8	8	8	4			
182	84	130	114	208		4		
183	160	160	145	175			4	
184	191	145	191	205				19
185	191	208	175	175				
186	69	8	23	23	27			
187	23	8	8	26		4		
188	8	8	23	53			4	
189	8	8	8	8				35
190	8	8	8	8				
191	8	8	8	8	4			
192	114	175	191	237		4		
193	208	175	175	282			4	
194	160	175	191	221				35
195	181	191	160	160				
196	69	8	23	8	12			
197	8	8	8	8		4		
198	8	8	8	33			4	
199	8	8	8	38				35
200	8	8	8	8				
201	8	8	8	38	19			
202	8	84	99	145		4		
203	69	69	69	114			12	
204	99	114	114	114				35
205	69	114	84	145				
206	8	8	8	8	19			
207	8	23	8	23		4		
208	23	38	8	8			65	
209	8	8	8	8				800
210	8	38	8	23				
211	8	8	8	8	1600			
212	8	8	8	8		1940		
213	8	8	8	53			2105	
214	114	130	130	175				2230
215	130	114	99	145				
216	114	145	114	130	2165		2165	
217	130	130	114	69		2165		
218	8	8	23	8			2165	
219	8	8	8	8				2165
220	8	8	8	23				
221	8	8	8	8	2165			
222	8	8	8	8		2165		
223	8	8	8	38			2165	
224	8	8	8	8				2230
225	8	8	8	53				
226	8	8	8	23	2165			
227	8	23	8	38		2165		
228	8	8	8	23			2165	
229	8	8	8	38				2230
230	8	38	8	8				

	2105	1635	785	294
231				
232				
233				
234				
235				
236				
237				
238				
239				
240				
241				
242				
243				
244				
245				
246				
247				
248				
249				
250				
251				
252				
253				
254				
255				
256				
257				
258				
259				
260				
261				
262				
263				
264				
265				
266				
267				
268				
269				
270				
271				
272				
273				
274				
275				
276				
277				
278				
279				
280				
281				
282				
283				
284				
285				
286				
287				
288				
289				
290				

ORIGINAL PAGE IS
OF POOR QUALITY

21 23 1982 1109 6

PAGE 7 OF 9



001
002
003
004
005
006
007
008
009
010
011
012
013
014
015
016
017
018
019
020
021
022
023
024
025
026
027
028
029
030
031
032
033
034
035
036
037
038
039
040
041
042
043
044
045
046
047
048
049
050

001
002
003
004
005
006
007
008
009
010
011
012
013
014
015
016
017
018
019
020
021
022
023
024
025
026
027
028
029
030
031
032
033
034
035
036
037
038
039
040
041
042
043
044
045
046
047
048
049
050

001
002
003
004
005
006
007
008
009
010
011
012
013
014
015
016
017
018
019
020
021
022
023
024
025
026
027
028
029
030
031
032
033
034
035
036
037
038
039
040
041
042
043
044
045
046
047
048
049
050

001
002
003
004
005
006
007
008
009
010
011
012
013
014
015
016
017
018
019
020
021
022
023
024
025
026
027
028
029
030
031
032
033
034
035
036
037
038
039
040
041
042
043
044
045
046
047
048
049
050

001
002
003
004
005
006
007
008
009
010
011
012
013
014
015
016
017
018
019
020
021
022
023
024
025
026
027
028
029
030
031
032
033
034
035
036
037
038
039
040
041
042
043
044
045
046
047
048
049
050

001
002
003
004
005
006
007
008
009
010
011
012
013
014
015
016
017
018
019
020
021
022
023
024
025
026
027
028
029
030
031
032
033
034
035
036
037
038
039
040
041
042
043
044
045
046
047
048
049
050

001
002
003
004
005
006
007
008
009
010
011
012
013
014
015
016
017
018
019
020
021
022
023
024
025
026
027
028
029
030
031
032
033
034
035
036
037
038
039
040
041
042
043
044
045
046
047
048
049
050

001
002
003
004
005
006
007
008
009
010
011
012
013
014
015
016
017
018
019
020
021
022
023
024
025
026
027
028
029
030
031
032
033
034
035
036
037
038
039
040
041
042
043
044
045
046
047
048
049
050

001
002
003
004
005
006
007
008
009
010
011
012
013
014
015
016
017
018
019
020
021
022
023
024
025
026
027
028
029
030
031
032
033
034
035
036
037
038
039
040
041
042
043
044
045
046
047
048
049
050

001
002
003
004
005
006
007
008
009
010
011
012
013
014
015
016
017
018
019
020
021
022
023
024
025
026
027
028
029
030
031
032
033
034
035
036
037
038
039
040
041
042
043
044
045
046
047
048
049
050

ORIGINAL PAGE IS
OF POOR QUALITY

2/ 23/ 1982 1109 6

PAGE 8 OF 8

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159 160 161 162 163 164 165 166 167 168 169 170 171 172 173 174 175 176 177 178 179 180 181 182 183 184 185 186 187 188 189 190 191 192 193 194 195 196 197 198 199 200 201 202 203 204 205 206 207 208 209 210 211 212 213 214 215 216 217 218 219 220 221 222 223 224 225 226 227 228 229 230 231 232 233 234 235 236 237 238 239 240 241 242 243 244 245 246 247 248 249 250 251 252 253 254 255 256 257 258 259 260 261 262 263 264 265 266 267 268 269 270 271 272 273 274 275 276 277 278 279 280 281 282 283 284 285 286 287 288 289 290 291 292 293 294 295 296 297 298 299 300 301 302 303 304 305 306 307 308 309 310 311 312 313 314 315 316 317 318 319 320 321 322 323 324 325 326 327 328 329 330 331 332 333 334 335 336 337 338 339 340 341 342 343 344 345 346 347 348 349 350 351 352 353 354 355 356 357 358 359 360 361 362 363 364 365 366 367 368 369 370 371 372 373 374 375 376 377 378 379 380 381 382 383 384 385 386 387 388 389 390 391 392 393 394 395 396 397 398 399 400 401 402 403 404 405 406 407 408 409 410 411 412 413 414 415 416 417 418 419 420 421 422 423 424 425 426 427 428 429 430 431 432 433 434 435 436 437 438 439 440 441 442 443 444 445 446 447 448 449 450 451 452 453 454 455 456 457 458 459 460 461 462 463 464 465 466 467 468 469 470 471 472 473 474 475 476 477 478 479 480 481 482 483 484 485 486 487 488 489 490 491 492 493 494 495 496 497 498 499 500 501 502 503 504 505 506 507 508 509 510 511 512 513 514 515 516 517 518 519 520 521 522 523 524 525 526 527 528 529 530 531 532 533 534 535 536 537 538 539 540 541 542 543 544 545 546 547 548 549 550 551 552 553 554 555 556 557 558 559 560 561 562 563 564 565 566 567 568 569 570 571 572 573 574 575 576 577 578 579 580 581 582 583 584 585 586 587 588 589 590 591 592 593 594 595 596 597 598 599 600 601 602 603 604 605 606 607 608 609 610 611 612 613 614 615 616 617 618 619 620 621 622 623 624 625 626 627 628 629 630 631 632 633 634 635 636 637 638 639 640 641 642 643 644 645 646 647 648 649 650 651 652 653 654 655 656 657 658 659 660 661 662 663 664 665 666 667 668 669 670 671 672 673 674 675 676 677 678 679 680 681 682 683 684 685 686 687 688 689 690 691 692 693 694 695 696 697 698 699 700 701 702 703 704 705 706 707 708 709 710 711 712 713 714 715 716 717 718 719 720 721 722 723 724 725 726 727 728 729 730 731 732 733 734 735 736 737 738 739 740 741 742 743 744 745 746 747 748 749 750 751 752 753 754 755 756 757 758 759 760 761 762 763 764 765 766 767 768 769 770 771 772 773 774 775 776 777 778 779 780 781 782 783 784 785 786 787 788 789 790 791 792 793 794 795 796 797 798 799 800 801 802 803 804 805 806 807 808 809 810 811 812 813 814 815 816 817 818 819 820 821 822 823 824 825 826 827 828 829 830 831 832 833 834 835 836 837 838 839 840 841 842 843 844 845 846 847 848 849 850 851 852 853 854 855 856 857 858 859 860 861 862 863 864 865 866 867 868 869 870 871 872 873 874 875 876 877 878 879 880 881 882 883 884 885 886 887 888 889 890 891 892 893 894 895 896 897 898 899 900 901 902 903 904 905 906 907 908 909 910 911 912 913 914 915 916 917 918 919 920 921 922 923 924 925 926 927 928 929 930 931 932 933 934 935 936 937 938 939 940 941 942 943 944 945 946 947 948 949 950 951 952 953 954 955 956 957 958 959 960 961 962 963 964 965 966 967 968 969 970 971 972 973 974 975 976 977 978 979 980 981 982 983 984 985 986 987 988 989 990 991 992 993 994 995 996 997 998 999 1000 1001 1002 1003 1004 1005 1006 1007 1008 1009 1010 1011 1012 1013 1014 1015 1016 1017 1018 1019 1020 1021 1022 1023 1024 1025 1026 1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1038 1039 1040 1

[illegible]

2000

2000

ယမာဘူမိ၊ ဘီဟိတံ၊ မေတ္တာလောကံ၊

12

4

4

12

12

4

4

12


ORIGINAL PAGE IS
OF POOR QUALITY

75 REM
80 REM
90 REM
100 REM
110 REM
120 REM
130 REM
140 REM
150 REM
160 REM
170 REM
180 REM
190 REM

SUMS DYNAMIC CALIBRATION
DATA TAPE FORMAT


0	COMMENTS	(72 CHARACTERS)	50
1	TIME	(SECONDS)	480
2	INLET P. INDUCER	(VOLTS)	480
3	BARATRON PRESS.	(TCRR)	480
4	SUMS HSK WORD	(16 BIT DECIMAL)	480
5	UAMS HSK WORDS	(8 BIT DECIMAL)	2880
6	AMU 28 (6 SAMPLES)	(9 BIT DECIMAL)	1440
7	AMU 14 (6 SAMPLES)	(9 BIT DECIMAL)	1440
8	AMU 28 (2ND HIGHEST)	(9 BIT DECIMAL)	240
9	AMU 14 (2ND HIGHEST)	(9 BIT DECIMAL)	240

ORIGINAL PAGE IS
OF POOR QUALITY





TP3290648 NOMINAL PRESSURE PROFILE. 2-20-82, RUN #1, TAPE #201, FILE#1.
TP3290648 NOMINAL PRESSURE PROFILE. 2-23-82, RUN #2, TAPE #201, FILE#2.
TP3290648 NOMINAL PRESSURE PROFILE. 2-23-82, RUN #3, TAPE #201, FILE#3.
TP3290648 +25% P/P PRESSURE PROFILE. 2-24-82, RUN #1, TAPE #201, FILE#4.

TP3290648 +25% P/P PRESSURE PROFILE. 2-24-82, RUN #2, TAPE #202, FILE #1



ORIGINAL PAGE IS
OF POOR QUALITY

TIME	PHANTOM FREQUENCY	RUN 20	RUN 14
0.0	0.000160	237	115
5.0	0.000161	237	115
10.0	0.000170	237	116
20.0	0.000177	237	116
30.0	0.000186	237	119
40.0	0.000189	237	119
50.0	0.000194	237	121
60.0	0.000198	237	122
70.0	0.000207	237	123
80.0	0.000211	240	124
90.0	0.000215	241	126
100.0	0.000224	241	128
110.0	0.000233	243	129
120.0	0.000235	243	129
130.0	0.000243	246	130
140.0	0.000254	247	131
150.0	0.000261	248	132
160.0	0.000266	248	132
170.0	0.000269	250	133
180.0	0.000279	251	134
190.0	0.000281	253	134
200.0	0.000289	253	135
210.0	0.000302	253	136
220.0	0.000316	253	137
230.0	0.000322	255	138
240.0	0.000331	260	139
250.0	0.000340	260	140
260.0	0.000350	262	141
270.0	0.000357	261	142
280.0	0.000362	263	143
290.0	0.000367	264	145
300.0	0.000365	266	146
310.0	0.000396	266	147
320.0	0.000418	267	148
330.0	0.000435	269	150
340.0	0.000459	270	152
350.0	0.000479	271	153
360.0	0.000493	272	155
370.0	0.000547	273	156
380.0	0.000553	276	161
390.0	0.000559	281	162
400.0	0.000579	282	163
410.0	0.000608	284	165
420.0	0.000656	286	166
430.0	0.000691	288	168
440.0	0.000727	290	169
450.0	0.000807	292	171
460.0	0.000838	293	173
470.0	0.000867	296	176
480.0	0.000910	298	179
490.0	0.000966	300	181
500.0	0.001065	303	184
510.0	0.001127	306	188
520.0	0.001221	305	191
530.0	0.001320	313	195
540.0	0.001407	316	197
550.0	0.001539	321	199
560.0	0.001684	322	202
570.0	0.001836	326	206
580.0	0.001944	326	210
590.0	0.002121	330	214
600.0	0.002342	336	218
610.0	0.002552	340	223
620.0	0.002930	344	226
630.0	0.003100	345	230
640.0	0.003384	354	233
650.0	0.003667	357	236
660.0	0.004104	360	240
670.0	0.004556	364	244
680.0	0.005006	366	249
690.0	0.005642	373	255
700.0	0.006315	380	260
710.0	0.007068	386	244
720.0	0.007945	390	140
730.0	0.008612	395	72



ORIGINAL PAGE 19
OF POOR QUALITY

360.1	0.009510	172	44
369.2	0.011935	152	37
394.4	0.012956	150	38
399.9	0.015049	148	39
404.9	0.018742	146	39
409.4	0.020440	145	34
414.4	0.024987	144	33
419.4	0.026634	143	32
424.4	0.030937	142	31
429.8	0.034428	140	30
434.4	0.041898	140	29
439.4	0.044212	141	28
444.4	0.047456	140	27
449.4	0.055151	140	26
454.4	0.062281	142	25
459.4	0.074392	144	24
464.4	0.079929	142	23
469.8	0.083083	147	22
475.0	0.097780	149	21
484.4	0.110400	157	20
489.4	0.126520	156	19
494.4	0.202230	159	18
499.4	0.187180	164	17
504.4	0.228300	167	16
509.4	0.235460	170	15
514.4	0.234500	174	14
519.4	0.238010	176	13
524.4	0.324490	179	12
529.4	0.422220	184	11
534.4	0.456330	190	10
539.4	0.523820	193	9
544.4	0.607890	199	8
549.4	0.659230	204	7
554.4	0.759240	209	6
559.4	0.875520	214	5
564.4	0.897500	219	4
569.4	1.025100	225	3
574.4	1.331600	227	2
579.4	1.382400	232	1
584.4	1.483500	236	
589.4	1.632800	242	
594.4	1.842200	246	
599.4	2.151700	251	
604.4	2.402700	260	
609.4	2.601900	263	
614.4	2.906000	266	
619.4	3.092000	271	
624.4	3.415790	275	
629.4	3.623400	280	
634.4	3.897500	283	
639.4	4.106400	286	
644.4	4.351900	290	
649.4	4.578400	292	
654.4	4.724200	293	
659.4	4.953900	295	
664.4	5.062800	297	
669.4	5.224200	298	
674.4	5.298100	299	
679.4	5.435700	300	
684.4	5.496200	302	
689.4	5.573800	301	
694.4	5.651500	304	
699.4	5.727900	302	
704.4	5.786100	305	
709.4	5.929600	305	
714.4	5.964300	305	
719.4	6.064100	306	
724.4	6.121800	307	
729.4	6.249700	307	
734.4	6.290100	306	
739.4	6.480400	306	
744.4	6.500000	310	
749.4	6.591000	312	
754.4	6.674400	311	
759.4	6.746000	311	
764.4	6.904500	312	
769.4	6.945600	313	
774.4	7.061800	314	
779.4	7.159400	314	
784.4	7.261100	316	
789.4	7.348700	316	
794.4	7.481000	317	
799.4	7.556000	318	

804.4	7.648200	320	197
809.5	7.804200	320	198
814.6	7.884500	321	198
819.5	7.990100	321	199
824.4	8.100900	321	199
829.6	8.289000	322	201
834.6	8.242000	322	205
839.5	8.032000	322	205
844.5	8.784000	322	206
849.6	8.769000	322	204
854.5	8.853000	322	203
859.5	8.963000	324	203
864.4	8.976000	325	204
869.4	9.033000	325	204
874.4	9.074000	326	204
879.5	9.155000	326	204
884.4	9.505000	326	205
889.4	9.577000	327	206
894.3	9.683000	326	207
899.4	9.799000	326	207
904.4	9.942000	326	208
909.5	10.072000	326	208
914.5	10.216000	330	209
919.4	10.446000	330	210
924.3	10.645000	331	211
929.3	10.802000	332	212
934.4	11.003000	332	212
939.3	11.147000	332	214
944.4	11.306000	334	214
949.3	11.469000	335	215
954.4	11.634000	335	215
959.3	11.800000	336	216
964.4	11.978000	336	217
969.3	12.121000	337	217
974.4	12.338000	337	216
979.3	12.480000	338	219
984.4	12.674000	338	220
989.3	12.817000	340	221
994.3	13.010000	340	222
999.3	13.165000	341	223
1004.3	13.387000	342	223
1009.3	13.558000	342	224
1014.3	13.776000	343	225
1019.3	13.968000	344	225
1024.3	14.126000	345	226
1029.3	14.382000	345	226
1034.4	14.568000	346	227
1039.4	14.756000	347	227
1044.4	14.958000	348	228
1049.3	15.194000	348	228
1054.3	15.355000	349	228
1059.4	15.653000	350	229
1064.4	15.793000	351	230
1069.4	16.066000	351	230
1074.3	16.257000	352	230
1079.3	16.580000	353	231
1084.3	16.736000	353	231
1089.2	16.944000	354	232
1094.2	17.226000	354	232
1099.3	17.456000	354	233
1104.2	17.683000	355	233
1109.3	17.924000	355	233
1114.2	18.207000	356	234
1119.2	18.398000	356	235
1124.3	18.731000	356	235
1129.2	18.953000	357	236
1134.1	19.181000	357	236
1139.2	19.486000	358	237
1144.2	19.784000	358	237
1149.1	20.009000	359	238
1154.2	20.323000	359	238
1159.2	20.622000	360	239
1164.2	20.865000	360	240
1169.3	21.212000	361	240
1174.2	21.475000	361	241
1179.1	21.789000	362	241
1184.2	22.074000	362	242
1189.1	22.369000	362	242

ORIGINAL PAGE 17
OF P002 QUALITY

Summit Dynamic Test TP2240483 Calibration

7/29/82 Run 4

2007.4

500mV F.S.

Pressure Profile

$t = 0$

Summit Pressure Transducer

$t = 0.5$

$t = 1.0$

$t = 1.5$

$t = 2.0$

$t = 2.5$

$t = 3.0$

$t = 3.5$

$t = 4.0$

$t = 4.5$

$t = 5.0$

$t = 5.5$

$t = 6.0$

$t = 6.5$

$t = 7.0$

$t = 7.5$

$t = 8.0$

$t = 8.5$

$t = 9.0$

$t = 9.5$

$t = 10.0$

$t = 10.5$

$t = 11.0$

$t = 11.5$

$t = 12.0$

$t = 12.5$

$t = 13.0$

$t = 13.5$

$t = 14.0$

$t = 14.5$

$t = 15.0$

$t = 15.5$

$t = 16.0$

$t = 16.5$

$t = 17.0$

$t = 17.5$

$t = 18.0$

$t = 18.5$

$t = 19.0$

ORIGINAL PAGE 11
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

10/2/20


2017年12月15日


Transaktion *Accounting / Controlling*

2024

ORIGINAL PAGE 13
OF POOR QUALITY

TIME	EXHAUSTION PRESSURE	AMU 28	AMU 14
0.0	0.000149	231	113
4.0	0.000155	231	113
10.0	0.000157	231	114
15.0	0.000163	231	114
19.0	0.000169	232	116
24.0	0.000175	233	116
28.0	0.000179	234	119
33.0	0.000183	235	119
40.0	0.000190	236	119
44.0	0.000193	237	121
49.0	0.000201	237	121
55.0	0.000209	238	124
59.0	0.000214	240	126
64.0	0.000221	241	126
69.0	0.000226	242	127
74.0	0.000236	243	129
79.0	0.000242	245	130
84.0	0.000245	246	130
89.0	0.000257	246	131
94.0	0.000263	246	132
99.0	0.000270	250	133
104.0	0.000282	251	134
109.0	0.000285	252	134
114.0	0.000296	254	135
119.0	0.000297	255	136
124.0	0.000316	256	137
129.0	0.000321	259	138
134.0	0.000325	260	139
139.0	0.000339	261	140
144.0	0.000351	264	142
149.0	0.000360	263	143
154.0	0.000372	264	144
159.0	0.000387	265	146
164.0	0.000402	266	147
169.0	0.000417	267	149
174.0	0.000432	268	151
179.0	0.000452	271	152
184.0	0.000474	273	154
189.0	0.000487	274	156
194.0	0.000522	276	158
199.0	0.000538	276	161
204.0	0.000571	279	162
209.0	0.000597	282	164
214.0	0.000636	283	165
219.0	0.000656	286	167
224.0	0.000735	289	169
229.0	0.000737	291	171
234.0	0.000763	292	173
239.0	0.000805	294	175
244.0	0.000862	296	177
249.0	0.000939	296	179
254.0	0.001000	300	183
259.0	0.001085	304	187
264.0	0.001153	307	190
269.0	0.001254	311	193
274.0	0.001328	314	196
279.0	0.001523	316	198
284.0	0.001564	322	201
289.0	0.001677	324	204
294.0	0.001814	327	208
299.0	0.001983	336	212
304.0	0.002162	333	215
309.0	0.002445	336	220
314.0	0.002577	341	225
319.0	0.002692	346	228
324.0	0.003078	351	231
329.0	0.003513	355	234
334.0	0.003755	356	238
339.0	0.004152	361	242
344.0	0.004645	363	246
349.0	0.005094	370	251
354.0	0.005950	373	255
359.0	0.006305	382	261
364.0	0.006997	387	263
369.0	0.008105	391	268
374.0	0.008325	396	276






379.6	0.011036	209	77
384.5	0.011436	174	50
389.5	0.011592	164	49
394.6	0.012269	156	40
399.5	0.014146	154	35
404.6	0.019617	151	35
409.5	0.020092	148	30
414.5	0.022748	147	31
419.6	0.026664	146	36
424.7	0.031849	145	26
429.6	0.033364	144	29
434.6	0.039255	144	29
439.6	0.042899	144	29
444.5	0.052896	143	29
449.6	0.055568	144	26
454.6	0.065364	145	29
459.6	0.072978	145	29
464.6	0.085136	147	31
469.6	0.093410	148	34
479.5	0.106079	153	35
484.5	0.118740	155	38
489.6	0.152920	156	39
494.6	0.163210	160	40
499.6	0.186600	163	46
504.6	0.228640	165	47
509.6	0.244690	166	51
514.6	0.277760	172	54
519.6	0.329830	176	62
524.6	0.358670	180	65
529.6	0.418610	186	69
534.4	0.465670	193	74
539.5	0.539660	196	78
544.4	0.582680	200	84
549.4	0.696030	204	89
554.6	0.749790	205	96
559.6	0.872980	215	100
564.7	0.877100	220	104
574.4	1.163800	226	111
579.5	1.345100	233	117
584.4	1.525800	236	120
589.4	1.352400	240	127
594.6	1.925700	246	134
599.4	2.096600	255	137
604.6	2.407100	260	140
609.6	2.649300	263	145
614.4	2.898300	266	150
619.4	3.158600	272	155
624.6	3.379200	276	160
629.6	3.685200	282	163
634.4	3.760200	286	166
639.6	3.980500	286	167
644.4	4.267900	296	169
649.4	4.492700	292	171
654.6	4.678600	293	173
659.6	4.859300	295	175
664.6	5.022600	296	177
669.6	5.171900	296	179
674.4	5.272600	299	180
679.6	5.364000	301	191
684.6	5.452900	301	182
689.6	5.543100	303	184
694.4	5.621500	303	185
699.4	5.671000	304	185
704.4	5.784400	304	186
709.5	5.849800	305	186
714.6	5.930100	306	187
719.6	6.026300	306	188
724.6	6.115700	307	189
729.6	6.186100	308	189
734.6	6.274600	308	190
739.4	6.365500	309	191
744.4	6.446300	310	192
749.4	6.543100	311	193
754.4	6.650800	312	193
759.4	6.753100	312	194
764.6	6.807100	312	194
769.6	6.904900	313	194
774.6	7.009200	314	195
779.6	7.119600	315	195
784.6	7.236600	315	196
789.6	7.357500	317	196
794.6	7.416800	318	197
799.6	7.524300	320	197

ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

804.4	7.638800	310	198
805.0	7.746100	321	199
814.0	7.861000	320	199
819.0	7.966300	321	199
824.1	8.087200	321	200
829.0	8.428000	323	201
834.0	8.286000	323	202
839.0	8.372000	323	202
844.0	8.478000	323	202
849.0	8.589000	324	202
854.0	8.634000	324	203
859.1	8.695000	324	203
864.1	8.768000	324	203
869.0	8.877000	324	203
874.0	9.015000	325	204
879.0	9.135000	325	205
884.0	9.256000	326	205
889.0	9.403000	327	206
894.0	9.544000	327	207
899.0	9.686000	328	208
904.0	9.847000	328	208
909.0	9.983000	329	209
914.1	10.145000	329	210
919.0	10.320000	330	210
924.0	10.482000	331	211
929.0	10.658000	331	212
934.0	10.816000	332	213
939.0	10.964000	333	213
944.1	11.142000	333	214
949.1	11.328000	334	215
954.0	11.477800	335	215
959.1	11.637000	335	216
964.1	11.813000	335	217
969.1	11.981000	336	218
974.0	12.154000	337	219
979.1	12.324000	338	220
984.0	12.494000	338	221
989.0	12.660000	339	221
994.0	12.829000	340	222
999.1	12.999000	341	223
1004.0	13.175000	341	223
1009.0	13.362000	342	224
1014.1	13.563000	343	225
1019.0	13.807000	343	225
1024.1	13.987000	344	226
1029.1	14.184000	345	226
1034.0	14.376000	346	227
1039.1	14.575000	346	227
1044.2	14.780000	347	228
1049.1	14.985000	348	228
1054.1	15.191000	348	228
1059.1	15.399000	349	229
1064.0	15.606000	352	229
1069.1	15.859000	351	230
1074.1	16.102000	351	230
1079.1	16.317000	352	231
1084.1	16.553000	353	231
1089.1	16.778000	353	232
1094.1	17.003000	354	232
1099.1	17.228000	354	232
1104.1	17.456000	355	233
1109.1	17.764000	355	234
1114.1	18.003000	356	234
1119.0	18.243000	356	235
1124.1	18.489000	356	235
1129.1	18.727000	357	236
1134.1	18.966000	357	236
1139.0	19.303000	358	237
1144.0	19.559000	358	237
1149.1	19.822000	359	238
1154.1	20.061000	359	238
1159.0	20.413000	360	239
1163.9	20.684000	360	240
1169.0	20.959000	361	240
1174.0	21.297200	362	241
1178.0	21.586000	362	241
1184.0	21.874000	363	242
1188.9	22.154000	363	206
119.5	22.075000	363	199



ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

Section Headings / Columns

Section Headings / Columns

Section 1/2

ORIGINAL PAGE IS
OF POOR QUALITY






TIME	BARTON PRESSURE	AND 28	AND 14
0.0	0.000149	231	113
4.7	0.000153	232	114
10.0	0.000156	233	115
15.0	0.000167	234	116
19.8	0.000168	235	117
24.8	0.000175	236	118
29.0	0.000177	237	119
33.0	0.000184	238	120
38.0	0.000184	239	121
44.0	0.000191	240	122
49.0	0.000197	241	123
54.0	0.000203	242	124
59.0	0.000214	243	125
64.0	0.000220	244	126
69.0	0.000225	245	127
74.0	0.000234	246	128
79.0	0.000240	247	129
84.0	0.000248	248	130
89.0	0.000254	249	131
94.0	0.000261	250	132
99.0	0.000266	251	133
104.0	0.000274	252	134
109.0	0.000288	253	135
114.0	0.000295	254	136
119.0	0.000300	255	137
124.0	0.000315	256	138
129.0	0.000316	257	139
134.0	0.000326	258	140
139.0	0.000337	259	141
144.0	0.000351	260	142
149.0	0.000356	261	143
154.0	0.000372	262	144
159.0	0.000381	263	145
164.0	0.000410	264	146
169.0	0.000415	265	147
174.0	0.000427	266	148
179.0	0.000445	267	149
184.0	0.000480	268	150
189.0	0.000488	269	151
194.0	0.000517	270	152
199.0	0.000538	271	153
204.0	0.000565	272	154
209.0	0.000595	273	155
214.0	0.000635	274	156
219.0	0.000667	275	157
224.0	0.000716	276	158
229.0	0.000744	277	159
234.0	0.000795	278	160
239.0	0.000829	279	161
244.0	0.000908	280	162
249.0	0.000943	281	163
254.0	0.001019	282	164
259.0	0.001103	283	165
264.0	0.001168	284	166
269.0	0.001279	285	167
274.0	0.001334	286	168
279.0	0.001524	287	169
284.0	0.001568	288	170
289.0	0.001722	289	171
294.0	0.001889	290	172
299.0	0.002046	291	173
304.0	0.002159	292	174
309.0	0.002483	293	175
314.0	0.002541	294	176
319.0	0.002760	295	177
324.0	0.003156	296	178
329.0	0.003461	297	179
334.0	0.003787	298	180
339.0	0.004336	299	181
344.0	0.004635	300	182
349.0	0.005258	301	183
354.0	0.005754	302	184
359.0	0.006596	303	185
364.0	0.007077	304	186
369.0	0.008053	305	187
374.0	0.019183	306	188

ORIGINAL PAGE IS
OF POOR QUALITY

383.7	0.004037	111	77
384.7	0.001150	177	78
389.7	0.000471	162	45
394.5	0.006752	161	24
399.7	0.016256	150	35
404.7	0.017622	152	38
409.7	0.019567	140	29
414.6	0.022225	149	36
419.5	0.025195	141	21
424.4	0.030401	140	24
429.4	0.034529	147	27
434.0	0.038615	141	25
439.5	0.044082	145	24
444.7	0.052556	145	28
449.5	0.055840	140	28
454.5	0.062090	146	31
459.5	0.076164	146	30
464.6	0.081252	145	34
469.6	0.084120	150	34
479.4	0.104290	154	37
484.4	0.124950	150	41
489.4	0.154400	150	44
494.5	0.170330	162	46
499.4	0.197320	162	50
504.5	0.222600	167	53
509.6	0.253290	170	56
514.6	0.287800	174	64
519.6	0.311000	176	66
524.6	0.325170	182	70
529.5	0.406670	187	75
534.4	0.444700	194	79
539.4	0.523020	197	85
544.5	0.584190	201	88
549.5	0.675500	202	86
554.4	0.758110	210	89
559.5	0.871410	212	104
564.5	0.900900	222	115
569.4	1.272800	220	121
574.4	1.281600	227	124
584.5	1.242500	246	127
589.5	1.512800	242	129
594.5	1.011700	244	137
599.4	2.205700	254	142
604.5	2.260500	261	140
609.5	2.540000	261	149
614.4	2.787900	262	154
619.5	3.164600	272	161
624.4	3.360500	277	163
629.5	3.638000	281	166
634.4	3.867800	286	168
639.5	4.136600	289	171
644.5	4.274500	291	172
649.5	4.552200	292	174
654.4	4.711600	294	176
659.4	4.922100	296	178
664.5	5.041000	297	180
669.4	5.192900	300	181
674.4	5.301900	301	182
679.4	5.390300	302	183
684.5	5.475900	303	184
689.5	5.564400	304	185
694.5	5.643700	305	186
699.4	5.695600	305	187
704.5	5.810600	306	188
709.5	5.875500	307	189
714.5	5.953000	307	190
719.5	6.040600	307	190
724.5	6.099900	308	191
729.4	6.242700	309	192
734.4	6.298000	310	193
739.5	6.370500	310	193
744.5	6.482300	311	194
749.5	6.547300	312	194
754.5	6.671100	312	195
759.1	6.750900	313	195
764.5	6.847600	313	196
769.5	6.941000	315	196
774.4	7.041800	316	197
779.4	7.146000	316	197
784.4	7.243500	316	197
789.5	7.329200	316	197
794.5	7.462300	320	190
799.5	7.547500		


ORIGINAL PAGE 19
OF POOR QUALITY

804.2	7.550000	201	186
807.2	7.750000	201	186
814.2	7.800000	201	186
819.2	7.900000	201	200
824.2	8.000000	202	200
829.4	8.110000	202	204
834.2	8.250000	202	200
839.2	8.350000	202	205
844.2	8.440000	202	200
849.4	8.510000	202	200
854.2	8.720000	202	200
859.2	8.720000	202	204
864.2	8.721000	202	204
869.2	8.850000	202	204
874.2	9.001000	202	205
879.2	9.190000	202	205
884.2	9.314000	202	200
889.2	9.420000	202	200
894.2	9.504000	202	200
899.2	9.710000	202	200
904.2	9.851000	202	200
909.2	10.000000	202	200
914.1	10.137000	202	210
919.2	10.300000	202	211
924.1	10.440000	202	211
929.2	10.550000	202	210
934.2	10.770000	202	210
939.2	10.832000	202	214
944.2	11.000000	202	214
949.1	11.220000	202	210
954.1	11.390000	202	210
959.1	11.561000	202	217
964.2	11.742000	202	217
969.1	11.920000	202	210
974.2	12.100000	202	210
979.2	12.281000	202	220
984.1	12.432000	202	221
989.0	12.581000	202	221
994.1	12.780000	240	222
999.2	12.980000	241	223
1004.2	13.170000	242	223
1009.1	13.350000	242	225
1014.2	13.540000	243	225
1019.2	13.720000	244	227
1024.2	13.940000	244	226
1029.1	14.140000	245	226
1034.1	14.357000	246	227
1039.0	14.521000	247	227
1044.1	14.760000	247	228
1049.1	14.981000	248	228
1054.0	15.150000	248	229
1059.1	15.410000	250	229
1064.0	15.639000	250	229
1069.0	15.824000	252	230
1074.0	16.082000	252	230
1079.0	16.266000	252	231
1083.9	16.539000	252	231
1088.9	16.730000	254	232
1093.9	17.007000	254	232
1098.9	17.281000	255	233
1103.9	17.481000	255	233
1109.0	17.766000	255	234
1114.0	17.980000	256	234
1119.0	18.180000	256	235
1124.1	18.496000	257	235
1129.0	18.790000	257	236
1133.9	19.025000	258	237
1138.9	19.264000	258	237
1144.0	19.588000	259	238
1149.0	19.830000	259	238
1153.9	20.145000	260	239
1158.9	20.417000	260	240
1164.0	20.674000	261	240
1168.9	21.021000	261	241
1174.0	21.295000	262	241
1179.0	21.625000	262	242
1183.9	21.854000	262	242




ORIGINAL PAGE 13
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY



ORIGINAL PAGE IS
OF POOR QUALITY





TIME	BREATHING PRESSURE	AMU 2	AMU 14
0.0	0.000010	137	120
5.0	0.000009	137	120
10.0	0.000011	137	120
20.0	0.000013	137	120
25.0	0.000014	137	120
30.1	0.000014	137	120
35.0	0.000014	137	120
40.2	0.000014	140	120
45.1	0.000022	140	120
50.1	0.000013	140	120
55.1	0.000014	141	120
60.2	0.000018	142	120
65.1	0.000017	143	120
70.0	0.000021	143	120
75.0	0.000017	146	120
80.0	0.000027	147	120
85.0	0.000024	149	120
90.1	0.000024	152	120
95.0	0.000022	154	120
100.0	0.000025	156	120
104.9	0.000028	157	120
110.2	0.000030	159	120
115.1	0.000025	159	120
119.9	0.000030	161	120
124.9	0.000029	162	120
130.2	0.000033	164	120
135.1	0.000033	166	120
139.9	0.000034	167	120
144.9	0.000037	168	120
149.9	0.000040	170	120
155.1	0.000043	172	120
160.1	0.000045	174	120
165.0	0.000047	176	120
170.0	0.000052	177	120
174.9	0.000050	181	120
180.0	0.000056	183	120
185.1	0.000062	185	120
190.1	0.000068	188	120
195.0	0.000066	191	120
199.9	0.000073	194	120
204.9	0.000080	196	120
209.9	0.000083	197	120
215.1	0.000093	199	120
220.1	0.000096	202	120
225.1	0.000107	204	120
230.1	0.000115	206	120
235.0	0.000130	208	120
239.9	0.000139	210	120
245.0	0.000153	216	120
249.6	0.000163	220	120
254.8	0.000183	223	120
260.1	0.000196	227	120
265.0	0.000236	229	120
269.9	0.000240	232	120
274.9	0.000265	236	120
280.0	0.000298	240	120
284.9	0.000324	244	120
289.9	0.000340	247	120
294.9	0.000423	252	120
299.8	0.000441	256	120
304.9	0.000503	262	120
309.8	0.000562	266	120
314.8	0.000609	270	120
320.0	0.000735	274	120
324.9	0.000781	281	120
329.6	0.000896	286	120
334.9	0.000963	291	120
339.6	0.001177	295	120
344.9	0.001250	300	120
349.6	0.001409	306	120
354.6	0.001711	312	120
359.6	0.001890	316	120
364.7	0.002222	324	120
370.0	0.002595	330	120
374.9	0.002958	335	120

ORIGINAL PAGE IS
OF POOR QUALITY

379.6	0.003500	341	203
384.9	0.003572	353	204
389.6	0.004507	356	204
394.9	0.005360	360	206
399.9	0.006218	372	208
404.6	0.007344	381	200
409.9	0.008568	388	247
415.1	0.009818	394	140
424.7	0.012687	171	51
429.9	0.013054	162	42
434.9	0.018402	153	37
439.6	0.021295	148	34
444.7	0.023737	146	34
449.7	0.030386	144	30
454.7	0.033987	142	29
459.6	0.042930	140	28
464.7	0.046459	141	29
469.6	0.056725	142	28
474.9	0.062595	143	29
479.6	0.075865	140	31
484.7	0.085033	143	32
489.9	0.086700	145	30
494.6	0.123260	147	36
499.6	0.136070	150	36
504.6	0.161830	152	37
509.6	0.201250	157	39
514.6	0.218460	162	45
519.6	0.237210	165	50
524.7	0.273200	166	52
529.6	0.331550	172	56
534.6	0.394490	177	65
539.7	0.492790	183	70
544.6	0.543240	191	75
549.7	0.555020	197	83
554.6	0.767420	203	92
559.7	0.895340	209	96
564.9	0.882700	216	100
569.6	1.157600	223	106
574.6	1.566200	227	112
579.6	1.613200	235	124
584.6	1.701600	243	131
589.7	1.795400	247	133
594.6	2.037700	251	135
599.6	2.789400	254	137
604.7	3.338800	264	149
609.6	3.579200	273	161
614.7	4.136000	281	165
619.6	4.515100	288	169
624.7	4.957200	291	173
629.6	5.376900	294	177
634.6	5.784500	296	181
639.6	6.266100	301	186
644.6	6.603400	305	191
649.6	6.998200	308	194
654.7	7.329500	312	196
659.6	7.556100	314	197
664.6	7.782400	316	199
669.7	8.007800	320	199
674.9	8.333000	326	201
684.6	8.224000	321	202
689.7	8.243000	321	202
694.7	8.277000	321	202
699.7	8.331000	321	202
704.7	8.435000	321	202
709.6	8.547000	322	202
714.6	8.717000	322	203
719.7	8.896000	323	204
724.7	9.054000	323	205
729.7	9.250000	324	206
734.7	9.436000	325	207
739.7	9.589000	326	208
744.7	9.751000	327	209
749.6	9.883000	327	210
754.6	10.033000	328	210
759.6	10.144000	329	211
764.6	10.324000	329	211
769.6	10.464000	330	212
774.6	10.611000	330	213
779.6	10.752000	331	214
784.6	10.891000	331	214
789.6	11.041000	333	215
794.6	11.183000	333	216
799.6	11.337000	333	217

ORIGINAL PAGE IS
OF POOR QUALITY



804.4	11.252000	344	210
814.4	11.829000	345	214
819.4	11.844000	346	216
824.4	12.150000	347	220
829.4	12.367000	348	221
834.4	12.407000	349	222
839.4	12.670000	350	223
844.4	12.858000	351	225
849.4	12.958000	352	228
854.4	13.176000	353	230
859.4	13.345000	354	231
864.4	13.594000	355	232
869.4	13.735000	356	233
874.4	13.912000	357	234
879.4	14.138000	358	235
884.4	14.300000	359	236
889.4	14.531000	360	237
894.4	14.723000	361	238
899.4	14.899000	362	239
904.4	15.101000	363	240
909.4	15.326000	364	241
914.4	15.503000	365	242
919.4	15.733000	366	243
924.4	15.951000	367	244
929.4	16.175000	368	245
934.4	16.410000	369	246
939.4	16.616000	370	247
944.4	16.849000	371	248
949.4	17.079000	372	249
954.4	17.307000	373	250
959.4	17.540000	374	251
964.4	17.787000	375	252
969.4	18.040000	376	253
974.4	18.284000	377	254
979.4	18.530000	378	255
984.4	18.791000	379	256
989.4	19.038000	380	257
994.4	19.286000	381	258
999.4	19.571000	382	259
1004.4	19.841000	383	260
1009.4	20.103000	384	260
1014.4	20.386000	385	261
1019.4	20.634000	386	262
1024.4	20.950000	387	263
1029.4	21.245000	388	264
1034.4	21.531000	389	265
1039.4	21.819000	390	266
1044.4	22.108000	391	267
1049.4	22.435000	392	268
1054.4	22.717000	393	269
1059.4	23.022000	394	270
1064.4	23.957000	395	271
1069.4	23.661000	396	272
1074.4	24.910000	397	273
1079.4	24.319000	398	274
1084.4	24.655000	399	275
1089.4	24.960000	400	276
1094.4	25.293000	401	277
1099.4	25.685000	402	278
1104.4	26.019000	403	279
1109.4	26.366000	404	280
1114.4	26.727000	405	281
1119.4	27.105000	406	282
1124.4	27.460000	407	283
1129.4	27.857000	408	284
1134.4	28.221000	409	285
1139.4	28.613000	410	286
1144.4	29.005000	411	287
1149.4	29.403000	412	288
1154.4	29.812000	413	289
1159.4	30.216000	414	290
1164.4	30.620000	415	291
1169.4	31.042000	416	292
1174.4	31.477000	417	293
1179.4	31.892000	418	294
1184.4	32.344000	419	295
1189.4	32.749000	420	296
1194.4	32.154000	421	297
1199.4	32.075000	422	298

100

3000 μ sec. 2000 μ sec. 5000 μ sec. 5000 μ sec. full scale
425% μ sec. 1000 μ sec. 1000 μ sec. 1000 μ sec.
Run in
2/10/72
40

00177

86-32

ORIGINAL. PAGE 19
OF POOR QUALITY

12.0000

12.0000

12.0000

25V F3

20V F3


20V F3

20V F3

20V F3

20V F3

11701015




ORIGINAL PAGE 13
OF POOR QUALITY

TIME	BATH TON PRESSURE	RUN 20	RUN 14
0.0	0.000020	140	34
5.1	0.000010	140	34
10.4	0.000011	146	31
15.7	0.000012	147	31
20.0	0.000010	146	34
25.3	0.000014	146	31
30.6	0.000015	140	34
35.9	0.000016	147	32
41.2	0.000016	146	34
46.5	0.000018	150	35
51.8	0.000019	151	36
57.1	0.000019	151	36
62.4	0.000020	154	38
67.7	0.000021	155	38
73.0	0.000021	157	41
78.3	0.000021	159	41
83.6	0.000022	160	41
88.9	0.000022	161	41
94.2	0.000024	163	45
99.5	0.000026	165	47
104.8	0.000025	166	50
110.1	0.000028	166	49
115.4	0.000027	167	51
120.7	0.000029	166	54
126.0	0.000032	169	52
131.3	0.000031	170	54
136.6	0.000032	171	57
141.9	0.000036	173	58
147.2	0.000037	173	61
152.5	0.000041	175	63
157.8	0.000043	177	64
163.1	0.000043	179	66
168.4	0.000046	181	66
173.7	0.000050	183	68
179.0	0.000053	186	71
184.3	0.000054	186	74
189.6	0.000060	191	74
194.9	0.000066	193	75
200.2	0.000072	196	79
205.5	0.000078	197	81
210.8	0.000085	199	84
216.1	0.000082	201	87
221.4	0.000098	203	90
226.7	0.000099	206	93
232.0	0.000105	206	96
237.3	0.000110	211	97
242.6	0.000122	213	100
247.9	0.000137	216	102
253.2	0.000151	219	104
258.5	0.000162	223	107
263.8	0.000179	226	109
269.1	0.000203	229	113
274.4	0.000221	231	117
279.7	0.000235	234	121
285.0	0.000279	236	126
290.3	0.000278	242	130
295.6	0.000297	246	132
300.9	0.000344	246	135
306.2	0.000399	252	137
311.5	0.000436	260	142
316.8	0.000528	263	146
322.1	0.000551	267	153
327.4	0.000627	273	159
332.7	0.000723	277	163
338.0	0.000744	287	168
343.3	0.000815	289	171
348.6	0.000971	292	174
353.9	0.001111	295	179
359.2	0.001328	300	186
364.5	0.001408	307	194
369.8	0.001476	314	198
375.1	0.001628	320	203
380.4	0.001939	323	205
385.7	0.002291	327	211
391.0	0.002745	332	218
396.3	0.002484	336	226


ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY



384.6	0.003900	384	123
385.7	0.004728	385	124
386.7	0.005222	386	125
387.7	0.006462	387	126
388.6	0.007182	388	127
389.6	0.008922	389	128
390.6	0.008624	390	129
391.6	0.012774	391	130
392.7	0.013432	392	131
393.6	0.014162	393	132
394.7	0.017002	394	133
395.6	0.023532	395	134
396.6	0.023892	396	135
397.7	0.027482	397	136
398.6	0.035082	398	137
399.7	0.041102	399	138
400.6	0.046614	400	139
401.6	0.062292	401	140
402.6	0.064132	402	141
403.6	0.072224	403	142
404.6	0.082562	404	143
405.6	0.084672	405	144
406.6	0.109400	406	145
407.6	0.144650	407	146
408.6	0.151680	408	147
409.6	0.169700	409	148
410.6	0.215360	410	149
411.7	0.267200	411	150
412.6	0.280820	412	151
413.6	0.324290	413	152
414.6	0.381300	414	153
415.6	0.492170	415	154
416.6	0.537480	416	155
417.6	0.644140	417	156
418.6	0.768090	418	157
419.6	0.878410	419	158
420.6	0.870200	420	159
421.6	1.445500	421	160
422.6	1.455000	422	161
423.6	1.865600	423	162
424.7	1.850700	424	163
425.6	2.074700	425	164
426.6	2.460800	426	165
427.6	2.821200	427	166
428.6	3.218400	428	167
429.6	3.720800	429	168
430.6	4.038400	430	169
431.6	4.435600	431	170
432.6	4.969800	432	171
433.6	5.341900	433	172
434.4	5.767800	434	173
435.6	6.182100	435	174
436.6	6.586900	436	175
437.6	6.975900	437	176
438.6	7.281200	438	177
439.6	7.536100	439	178
440.6	7.777400	440	179
441.6	7.997200	441	180
442.6	8.116000	442	181
443.6	8.205000	443	182
444.6	8.254000	444	183
445.6	8.365000	445	184
446.6	8.512000	446	185
447.4	8.655000	447	186
448.6	8.810000	448	187
449.6	8.931000	449	188
450.6	9.055000	450	189
451.6	9.196000	451	190
452.6	9.354000	452	191
453.6	9.474000	453	192
454.6	9.592000	454	193
455.6	9.796000	455	194
456.6	9.868000	456	195
457.6	10.065000	457	196
458.6	10.143000	458	197
459.6	10.267000	459	198
460.6	10.491000	460	199
461.6	10.581000	461	200
462.6	10.713000	462	201
463.6	10.932000	463	202
464.6	11.025000	464	203
465.6	11.159000	465	204
466.6	11.303000	466	205

ORIGINAL PAGE IS
OF POOR QUALITY



804.0	11.548000	314	217
809.4	11.620000	315	218
814.0	11.784000	316	219
819.0	12.028000	317	220
824.0	12.135000	318	221
829.4	12.285000	319	222
834.0	12.445000	320	223
839.4	12.707000	321	224
844.4	12.785000	322	225
849.0	12.880000	323	226
854.0	13.160000	324	227
859.0	13.336000	325	228
864.0	13.590000	326	229
869.0	13.721000	327	230
874.4	13.896000	328	231
879.4	14.156000	329	232
884.4	14.293000	330	233
889.4	14.487000	331	234
894.4	14.736000	332	235
899.4	14.866000	333	236
904.0	15.119000	334	237
909.0	15.313000	335	238
914.0	15.528000	336	239
919.0	15.727000	337	240
924.0	15.950000	338	241
929.0	16.130000	339	242
934.0	16.435000	340	243
939.0	16.592000	341	244
944.0	16.845000	342	245
949.0	17.086000	343	246
954.0	17.302000	344	247
959.0	17.525000	345	248
964.0	17.740000	346	249
969.0	18.069000	347	250
974.0	18.236000	348	251
979.0	18.544000	349	252
984.0	18.782000	350	253
989.0	19.019000	351	254
994.0	19.254000	352	255
999.0	19.601000	353	256
1004.0	19.847000	354	257
1009.0	20.110000	355	258
1014.0	20.370000	356	259
1019.0	20.620000	357	260
1024.0	20.861000	358	261
1029.0	21.240000	359	262
1034.0	21.519000	360	263
1039.0	21.788000	361	264
1044.0	22.144000	362	265
1049.0	22.369000	363	266
1054.0	22.720000	364	267
1059.0	22.995000	365	268
1064.1	23.372000	366	269
1069.0	23.668000	367	270
1074.0	23.974000	368	271
1079.1	24.332000	369	272
1084.0	24.658000	370	273
1089.1	24.955000	371	274
1094.0	25.267000	372	275
1099.0	25.675000	373	276
1104.0	26.059000	374	277
1109.0	26.354000	375	278
1114.1	26.738000	376	279
1119.1	27.062000	377	280
1124.0	27.490000	378	281
1129.1	27.851000	379	282
1134.0	28.224000	380	283
1139.0	28.638000	381	284
1144.0	29.009000	382	285
1149.0	29.368000	383	286
1154.1	29.827000	384	287
1159.1	30.206000	385	288
1164.0	30.611000	386	289
1169.1	31.065000	387	290
1174.1	31.470000	388	291
1179.0	31.871000	389	292
1184.0	32.252000	390	293
1189.0	32.773000	391	294
119.5	22.075000	392	295

ORIGINAL PAGE 17
OF POOR QUALITY

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100

SUMS Dynamic Calibration 500 mV F.S.
#252 P/P Profile
R04 2
2/24/82

Continued from Page 16

27.00

Continued from Page 15

0.00

Continued from Page 14

1.00 F.S.

2.00

Continued from Page 13

1.00 F.S.

5.0 F.S.

2.57 F.S.

0.00


Page 17

0.00

0.00

ORIGINAL PAGE IS
OF POOR QUALITY

Tape # 008
File # 2



ORIGINAL PAGE IS
OF POOR QUALITY

24 24 1982 1930 HRS SUMS FUNCTIONAL TEST S/N 6 PAGE 1 OF 6

DATA TAPE ID 8 BULK DATA FILE # 2

SUMS FUNCTIONAL TEST

TF3290648 BACKGROUND SPECTRA (AFTER PUMP) ALL VALVES OPEN. 3E-8 TORR EXT.

HOUSEKEEPING DATA FILAMENT NUMBER 1

SCAN NUMBER	1	2	3	4	5	6	7	8	ANAL MUX
INTERLACE STEP	1	2	3	4	1	2	3	4	
IONIZATION ENERGY	75	75	75	75	75	75	75	75	
FILAMENT NUMBER	1	1	1	1	1	1	1	1	
CAP ON=1, OFF=2	1	1	1	1	1	1	1	1	
PLUS 15 VOLT	193	193	193	193	193	193	193	193	15.000
MINUS 15 VOLT	129	130	129	129	130	129	130	130	15.000
ION PUMP VOLT	181	180	180	180	181	181	180	181	15.000
ION SOURCE TEMP	91	90	90	90	91	90	90	91	15.000
PRE-AMP TEMP	168	169	169	169	168	169	169	168	15.000
PLUS 5 VOLT	120	120	120	120	121	120	121	120	15.000
A/D REFERENCE VOLT	163	163	163	163	163	163	163	163	15.000
EMISSION CURRENT	126	126	125	126	126	125	126	125	15.000
COLLECTOR CURRENT	111	111	111	111	111	112	111	111	15.000
ELECTRON ACC VOLT	190	189	189	190	190	189	190	189	15.000
ION ACC VOLT	39	39	39	39	39	39	39	39	15.000
ION PUMP ANALOG									15.000
28 VOLT POWER SUP									15.000

ORIGINAL PAGE IS
OF POOR QUALITY

14 1980 1800 HPS

SOME
FUNCTIONAL TEST

PAGE 2 OF 8

75 ELECTRON VOLTS IONIZATION ENERGY

SCAN STEP NO	-----HIGH MASS COLLECTOR-----				-----LOW MASS COLLECTOR-----			
	SCAN 1	SCAN 2	SCAN 3	SCAN 4	SCAN 1	SCAN 2	SCAN 3	SCAN 4
1	23	0	0	0	4	19	4	4
2	0	0	0	0				
3	0	0	0	0				
4	0	0	0	0				
5	23	0	0	0	4	12	12	4
6	0	0	0	0				
7	0	0	0	0				
8	23	0	0	0				
9	0	0	0	0				
10	0	0	0	0	4	19	4	4
11	23	0	0	0				
12	0	0	0	0				
13	0	0	0	0				
14	0	0	0	0				
15	0	0	0	0	4	19	4	4
16	23	0	0	0				
17	0	0	0	0				
18	0	0	0	0				
19	0	0	0	0	4	19	4	4
20	0	0	0	0				
21	0	0	0	0	4	19	4	4
22	0	0	0	0				
23	0	0	0	0				
24	0	0	0	0				
25	0	0	0	0	4	4	4	4
26	0	160	175	145				
27	175	191	206	160				
28	0	0	0	0				
29	175	191	206	175				
30	114	0	0	0	4	19	4	4
31	0	0	0	0				
32	0	0	0	0				
33	0	0	0	0				
34	0	0	0	0				
35	0	0	0	0	4	12	4	4
36	0	0	0	0				
37	0	0	0	0				
38	23	0	0	0				
39	0	0	0	0				
40	0	0	0	0	4	4	4	4
41	0	0	0	0				
42	0	0	0	0				
43	0	0	0	0				
44	0	0	0	0				
45	0	0	0	0	4	27	4	4
46	0	0	0	0				
47	0	0	0	0				
48	0	0	0	0				
49	0	0	0	0				
50	0	0	0	0				

ORIGINAL PAGE IS
OF POOR QUALITY

1 2 24 1962 1970 7 DATE 2 01 2

91		20		4	19	4	4
92		30					
93							
94							
95							
96				12	12	4	4
97							
98							
99				4	4	4	4
100							
101							
102							
103							
104							
105							
106							
107							
108							
109							
110							

ORIGINAL PAGE IS
OF POOR QUALITY

1

PAGE 180 1900


PAGE 180 1900

171	8	8	8	8	4			
172	8	8	8	8		19		
173	1300	1370	1630	1690			4	
174	1690	1690	1690	1790				4
175	1690	1750	1750	1750				
176	1660	1480	1300	992	4			
177	420	63	38	53		19		
178	8	8	23	8			4	
179	8	8	8	8				4
180	8	8	23	8				
181	8	8	23	69	4			
182	221	359	435	450		4		
183	526	511	496	511			12	
184	481	511	481	511				4
185	511	526	542	420				
186	237	84	69	8	4			
187	8	23	8	8		19		
188	23	23	8	8			4	
189	8	8	8	8				4
190	8	8	53	8				
191	8	8	8	8	4			
192	84	114	173	191		19		
193	221	191	206	221			4	
194	191	221	206	206				4
195	206	191	206	114				
196	53	23	23	8	4			
197	8	8	8	8		4		
198	8	8	8	8			4	
199	8	8	8	8				4
200	8	8	8	8				
201	8	8	23	8	4			
202	8	8	8	8		12		
203	8	8	5	8			4	
204	8	8	8	84				4
205	8	8	8	8				
206	23	8	5	8	4			
207	8	8	8	8		4		
208	8	8	8	8			180	
209	8	8	8	23				2470
210	8	8	8	8	5200			
211	8	8	8	8		6400		
212	8	23	8	8			6750	
213	8	8	23	8				6900
214	8	84	130	160				
215	84	99	99	99				
216	99	84	145	99	6900			
217	99	84	130	8		7000		
218	8	8	8	8			7000	
219	8	8	8	8				7000
220	23	8	8	8				
221	8	8	53	8	7000			
222	8	8	8	8		7150		
223	8	8	8	8			7150	
224	8	8	23	8				7150
225	8	8	8	8				
226	23	8	23	8	7150			
227	8	8	8	8		7150		
228	8	8	8	8			7250	
229	8	8	8	8				7250
230	23	8	23	8				

ORIGINAL PAGE 19
OF POOR QUALITY

24 1962 1960 6

PAGE 2 OF 3



			7250	5450	2525	990
231						
232						
233						
234						
235						
236						
237						
238						
239						
240						
241						
242						
243						
244						
245						
246						
247						
248						
249						
250						
251						
252						
253						
254						
255						
256						
257						
258						
259						
260						
261						
262						
263						
264						
265						
266						
267						
268						
269						
270						
271						
272						
273						
274						
275						
276						
277						
278						
279						
280						
281						
282						
283						
284						
285						
286						
287						
288						
289						
290						

ORIGINAL PAGE IS
OF POOR QUALITY

2 24 1900 1900

PAGE 7 OF 8

291	30	6	6	4	27	4	4
292	30	6	6	4	12	4	4
293	30	6	6	4	12	4	4
294	30	6	6	4	12	4	4
295	30	6	6	4	12	4	4
296	30	6	6	4	12	4	4
297	30	6	6	4	12	4	4
298	30	6	6	4	12	4	4
299	30	6	6	4	12	4	4
300	30	6	6	4	12	4	4
301	30	6	6	4	12	4	4
302	30	6	6	4	12	4	4
303	30	6	6	4	12	4	4
304	30	6	6	4	12	4	4
305	30	6	6	4	12	4	4
306	30	6	6	4	12	4	4
307	30	6	6	4	12	4	4
308	30	6	6	4	12	4	4
309	30	6	6	4	12	4	4
310	30	6	6	4	12	4	4
311	30	6	6	4	12	4	4
312	30	6	6	4	12	4	4
313	30	6	6	4	12	4	4
314	30	6	6	4	12	4	4
315	30	6	6	4	12	4	4
316	30	6	6	4	12	4	4
317	30	6	6	4	12	4	4
318	30	6	6	4	12	4	4
319	30	6	6	4	12	4	4
320	30	6	6	4	12	4	4
321	30	6	6	4	12	4	4
322	30	6	6	4	12	4	4
323	30	6	6	4	12	4	4
324	30	6	6	4	12	4	4
325	30	6	6	4	12	4	4
326	30	6	6	4	12	4	4
327	30	6	6	4	12	4	4
328	30	6	6	4	12	4	4
329	30	6	6	4	12	4	4
330	30	6	6	4	12	4	4
331	30	6	6	4	12	4	4
332	30	6	6	4	12	4	4
333	30	6	6	4	12	4	4
334	30	6	6	4	12	4	4
335	30	6	6	4	12	4	4
336	30	6	6	4	12	4	4
337	30	6	6	4	12	4	4
338	30	6	6	4	12	4	4
339	30	6	6	4	12	4	4
340	30	6	6	4	12	4	4
341	30	6	6	4	12	4	4
342	30	6	6	4	12	4	4
343	30	6	6	4	12	4	4
344	30	6	6	4	12	4	4
345	30	6	6	4	12	4	4
346	30	6	6	4	12	4	4
347	30	6	6	4	12	4	4
348	30	6	6	4	12	4	4
349	30	6	6	4	12	4	4
350	30	6	6	4	12	4	4

ORIGINAL PAGE IS
OF POOR QUALITY

24 1982 1990

PAGE 001 0

001	000	000	000	000	4	12	4	4
002	000	000	000	000				
003	000	000	000	000				
004	000	000	000	000				
005	000	000	000	000				
006	000	000	000	000	4	4	12	4
007	000	000	000	000				
008	000	000	000	000				
009	000	000	000	000				
010	000	000	000	000				

ORIGINAL PAGE IS
OF POOR QUALITY

9-24 1987 1987 HPS

SUPPLEMENTAL TEST

5. H. E.

PAGE 1 OF 6

DATA TAPE IN 0 BULK DATA FILE # 2

SAMPLE FUNGUS INOCULUM TEST

TP03290640. LARGE CRACK OPEN. AFTER APPROX 2 HOURS OF PUMPING.

HOUSEKEEPING DATA FILAMENT NUMBER 2

[illegible]

ORIGINAL PAGE IS
OF POOR QUALITY

7-24-1962

1500 HRS

SUN

5.11.6

PAGE 2 OF 8


END OF TEST

75 ELECTRON VOLTS IONIZATION ENERGY

SCAN STEP	HIGH MASS COLLECTOR				LOW MASS COLLECTOR			
NO	SCAN 1	SCAN 2	SCAN 3	SCAN 4	SCAN 1	SCAN 2	SCAN 3	SCAN 4
1					4			
2						4		
3							4	
4								4
5					4			
6						4		
7							4	
8								4
9					12			
10						4		
11							4	
12								4
13								
14								4
15					4			
16						4		
17							4	
18								4
19								
20					4			
21						4		
22							4	
23								4
24								
25								4
26					4			
27						4		
28							4	
29								4
30					4			
31						4		
32							4	
33								4
34								
35								4
36					4			
37						4		
38							4	
39								4
40					4			
41						4		
42							4	
43								4
44								
45								4
46					4			
47						4		
48							4	
49								4
50								

2 24 1982 1982 6

PAGE 1 OF 2



100	170	664	771	1080	4	4	4	4
101	1240	1480	1450	1510	4	12	4	4
102	1480	1480	1450	1540	4	4	4	4
103	1510	1540	1480	1510	4	4	4	4
104	1300	600	526	289	4	4	4	4
105	151	30	8	8	4	4	4	4
106	8	23	8	8	4	4	4	4
107	8	8	8	8	4	4	4	4
108	23	13	8	8	4	4	4	4
109	8	8	8	8	4	4	4	4
110	8	8	8	8	4	4	4	4

ORIGINAL PAGE IS
OF POOR QUALITY

24 1982 1986

PAGE 5 OF 8

171	0	0	0	4			
172	0	221	404	4			
173	1480	1980	2040			12	
174	2110	2170	2110				4
175	2170	2170	2170				
176	2110	1980	1680	4			
177	420	84	99		4		
178	38	0	0			4	
179	0	0	0				4
180	0	0	0				
181	0	0	0	4			
182	0	0	0		4		
183	0	420	481			4	
184	0	0	0				4
185	0	0	0				
186	0	0	0	4			
187	0	0	0		4		
188	0	0	0			4	
189	0	0	0				4
190	0	0	0				
191	0	0	0	4			
192	0	0	0		4		
193	0	0	0			4	
194	0	0	0				4
195	0	0	0	4			
196	0	0	0		4		
197	0	0	0			4	
198	0	0	0				4
199	0	0	0				
200	0	0	0	4			
201	0	0	0		4		
202	0	0	0			4	
203	0	0	0				4
204	0	0	0				
205	0	0	0	4			
206	0	0	0		4		
207	0	0	0			65	
208	0	0	0				955
209	0	0	0				
210	0	0	0	2105			
211	0	0	0		2595		
212	0	0	0			2715	
213	0	0	0				2840
214	0	0	0				
215	100	0	0	2840			
216	0	114	0		2840		
217	100	0	0			2840	
218	0	0	0				2840
219	0	0	0				
220	0	0	0	2840			
221	0	0	0		2840		
222	0	0	0			2840	
223	0	0	0				2840
224	0	0	0				
225	0	0	0	2840			
226	0	0	0		2840		
227	0	0	0			2840	
228	0	0	0				2840
229	0	0	0				
230	0	0	0				

2

PAGE 6 OF 8

363

4
4
4
4
4
4
4
4
4
4

ORIGINAL PAGE IS
OF POOR QUALITY

20 24 1982 1986 5

PAGE 7 OF 8

[illegible]

6.3

COMPOSITION CHANGE CALIBRATIONORIGINAL PAGE 13
OF POOR QUALITY

As-Run

3/2/82

The composition change calibration admits a gas to the SUMS inlet in a controlled pressure rise. At a given pressure point the gas is switched to another gas. The SUMS instrument and test configuration measures and records the time, pressure and a portion of the spectra so that the time response to the gas composition change can be determined.

Two sets of gasses are used during this procedure; oxygen switching to nitrogen and nitrogen switching to a nitrogen/oxygen mixture. For each set of gasses there are two pressure switch points; 1 Torr and 10 Torr. For each switch point there are two pressure profiles which are followed; the dynamic nominal profile and the dynamic +25% P/P profile. All these various combinations yield a total of 8 different pressure runs.

The data collected during this procedure consists of the time, the inlet pressure (as measured by the MRS baratron), the inlet pressure (as measured by the sums inlet pressure transducer), two of the twelve UAMS housekeeping words (status and ion source temperature), and peak data (ion currents) for the AMV 32, 28, 16 and 14 peaks.

Only six consecutive data points (single scan mode) are stored for each of the four peaks. These points are selected by finding the largest value for the peak and recording that value, the two values immediately before it and the three values immediately following it. (Note: by definition if the largest value occurs more than once, the later occurrence is assumed to be "larger".

This procedure is run using filament number 1 only.

**COMPOSITION CHANGE CALIBRATION
PRESSURE RUN SUMMARY**

RUN TYPE	SWITCH POINT (approx.)	PROFILE	TIME (seconds)	
			RANGE	SWITCH
#1	1 Torr	nominal	425-905	565
#2	1 Torr	+25%	440-755	565
#3	10 Torr	nominal	520-1100	900
#4	10 Torr	+25%	515-950	750

6.3.1 **VACUUM SYSTEM SET UP**

- 6.3.1.1 Verify or implement the following vacuum conditions:
- Calibration Station Ion Pump in Protect Mode.
- Valve V-15 Closed.

✓
✓
✓

JE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP 3290648

REV
B

SCALE

WEIGHT

SHEET 50

- 6.0x10⁻⁸ Torr

SEA 241B-2

ORIGINAL PAGE IS
OF POOR QUALITY

6.3.2.1.10 Press START/DECODE.

6.3.2.2 SUMS GSE Interface Unit

6.3.2.2.1 Inlet, Range, and Protection valve switches set to CLOSED.

6.3.2.2.2 Control select switch set to GSE.

6.3.2.2.3 Delay select switch set to SHORT.

6.3.2.2.4 Set analog monitor rotary switch to position #9. (This provides a 2M Ω PCM type load.)

6.3.2.2.5 Set interface power switches to ON.

6.3.2.2.6 Set TEST SET/INTERNAL switch to TEST SET.

6.3.2.2.7 Set VAC MAIN/ION PUMP switch to ION PUMP.

6.3.2.2.8 Set sweep inhibit switch to NORMAL.

6.3.2.3 Fluke Data Logger

6.3.2.3.1 Turn power on.

6.3.2.3.1 Program data logger to scan channels T11, T12, and T15. (See figure 1 for thermocouple locations.)

6.3.2.4 HP1610A Logic State Analyzer

6.3.2.4.1 Connect pods 1 and 2 to the 16 bit parallel SUMS digital data lines. These lines are available inside the GSE Interface Unit.

6.3.2.4.2 Connect the clock pod to the SUMS data strobe inside the GSE Interface Unit.

6.3.2.4.3 Set analyzer power to ON.

6.3.2.5 Fluke 8520A Digital Multimeter

6.3.2.5.1 Verify multimeter is connected to MKS electronics.

6.3.2.5.2 Set power switch to ON.

6.3.2.6 HP6942A Multiprogrammer

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP 3290648	REV B
SCALE	WEIGHT	SHEET 52	

ORIGINAL PAGE 18
OF POOR QUALITY

- 6.3.2.6.1 Verify multiprogrammer is connected to MKS electronics (D/A and digital output) and the inlet transducer 0-5V output inside the GSE Interface Unit (A/D).
- 6.3.2.6.2 Set power switch to ON.
- 6.3.2.7 HP 85 Computer
- 6.3.2.7.1 Verify the HP 85 is connected to the Logic State Analyzer, the Multiprogrammer and the Digital Multimeter via the IEEE-488 bus.
- 6.3.2.7.2 Set power switch to ON.
- 6.3.2.7.3 Insert SUMS programs tape.
- 6.3.2.8 MKS Type 244A Valve Controller
- 6.3.2.8.1 Set power switch to ON.
- 6.3.2.8.2 Set Phase Lead control to 5.0.
- 6.3.2.8.3 Set Gain control to 100%.
- 6.3.2.8.4 Set function rotary switch to CLOSED.
- 6.3.2.8.5 Set INT/EXT switch to EXT.
- 6.3.2.8.6 Set setpoint control to 10.00.
- 6.3.2.8.7 Set input switch to 100%.
- 6.3.2.9 MKS 170M-27D Digital Display
- 6.3.2.9.1 Set display units to TORR.
- 6.3.2.9.2 Set Head Range to MPLX.
- 6.3.2.9.3 Set sampling switch to AUTO.
- 6.3.2.10 MKS 170M-6C Range Multiplier
- 6.3.2.10.1 Set power switch to ON.
- 6.3.2.10.2 Set heater switch to OFF.
- 6.3.2.10.3 Set response switch to FAST.

B BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP 3290648

REV
B

SCALE

WEIGHT

SHEET 53

ORIGINAL PAGE IS
OF POOR QUALITY

6.3.2.10.4 Set range switch to .01.

6.3.2.11 MKS 170M-34C Head Selector

6.3.2.11.1 Verify CH.1 and CH.2 heaters have been on for a minimum of 4 hours.

6.3.2.11.2 Set selector switch to CH.1.

6.3.2.11.3 Set CH.1 head range switch to 1 Torr.

6.3.2.11.4 Adjust CH.1 coarse/fine zero for 0.000 nominal.

6.3.2.11.5 Set selector switch to CH.2.

6.3.2.11.6 Set CH.2 head range switch to 100 Torr.

6.3.2.11.7 Adjust CH.2 coarse fine zero for 0.000 nominal.

6.3.2.12 Chart Recorder

6.3.2.12.1 Connect chart recorder across input to Fluke digital multimeter.

6.3.2.12.2 Set power switch to ON.

NOTE

The Chart Recorder is to be used during the running of this test to indicate to the operator how smoothly the pressure is changing between five second steps. The recorder sensitivity should be changed as necessary to maximize the deflection of the pen.

6.3.3 Instrument Turn-On and Warm-Up

6.3.3.1 Turn on the SUMS Ion Pump Power with the switch on the GSE I/F Unit.

6.3.3.2 Wait one minute for UAMS ion pump to come on.

6.3.3.3 From the ion pump current monitor, verify that the instrument internal pressure is less than 1×10^{-5} Torr.

E BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP 3290648

REV
B

SCALE

WEIGHT

SHEET 54

ORIGINAL PAGE 13
OF POOR QUALITY

- 6.3.3.4 Using the switches on the GSE I/F Unit, open the protection Inlet valves. Close the Range valve. ✓
- 6.3.3.5 Turn on the SUMS Instrument Power with the switch on the GSE I/F Unit. ✓
- 6.3.3.6 Wait two hours minimum for the instrument ion source to warm-up. *on for 6 hours* ✓
- 6.3.3.7 Using the 1610 logic analyser, verify the ion source temperature as recorded in the UAMS Housekeeping is at least 87 decimal. (Record value.) 90.10
- 6.3.3.8 Record thermocouple temperatures from Data Logger. T11 72.7 °F
T12 72.5 °F
T15 77.0 °F

6.3.4 SUMS Background Spectra (Before Run)

- 6.3.4.1 Turn on the HP9830 calculator, printer, cassette memory and plotter. ✓
- 6.3.4.2 Place a marked data tape in the cassette memory and rewind it. ✓
- 6.3.4.3 Place the SUMS Functional test cassette tape in the calculator. ✓
- 6.3.4.4 Verify that the cryopump is still cold and that its pressure is less than 50 microns. ✓
- 6.3.4.5 Load and run file ϕ on the calculator. The program is interactive from this point. Continue with paragraph 6.3.5 when the calculator has finished. Record data tape information below.

SUMS Data Tape I.D.# 9

Bulk File #(1,2,3,or4) 1

6.3.5 Conductance Setting

The calibration station throttling valve is set to a known conductance in the following steps. In this way there will always be a flow of gas out of the upper volume of the calibration station. (The part that

E BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP 3290648

REV
B

SCALE

WEIGHT

SHEET 55

ORIGINAL PAGE 19
OF POOR QUALITY

the SUMS inlet is connected to.) This flow will insure that when the 4-way valve is switched to change gas composition, the gas in the upper volume will rapidly be replaced with the new gas.

- | | | |
|----------|---|---------------------------|
| 6.3.5.1 | Set in the 10 liter/sec orifice. | ✓ |
| 6.3.5.2 | Verify that the cryo pump is still cold. | ✓ |
| 6.3.5.3 | Close the SUMS inlet valve. | ✓ |
| 6.3.5.4 | Set the MKS baratron readout for 10 mili Torr full scale. | ✓ |
| 6.3.5.5 | Verify that oxygen is flowing through the Varian leak. | ✓ |
| 6.3.5.6 | Verify that the throttling valve is fully open. | ✓ |
| 6.3.5.7 | Using the Varian leak and watching the baratron readout, raise the pressure to $.30 \pm .02 \times 10^{-3}$ Torr. | ✓ |
| 6.3.5.8 | Wait one minute, then record pressure. | $.31 \times 10^{-3}$ Torr |
| 6.3.5.9 | Leaving the Varian leak as it is, immediately close the throttling valve until the pressure increases to $6.0 \pm 0.5 \times 10^{-3}$ Torr. | ✓ |
| 6.3.5.10 | Wait one minute and verify that the pressure is stable. Record pressure. | 6.0×10^{-3} Torr |
| 6.3.5.11 | Remove the handle from the throttling valve. Do not move valve throughout the test. Conductance is now set to approximately 0.5 liters/sec. | ✓ |
| 6.3.5.12 | Close Varian leak valve. $\frac{10}{6.0/.31} = .52 \text{ l/sec}$ | ✓ |
| 6.3.6 | <u>Final Preparations</u> | |
| 6.3.6.1 | Use the HP 85 to manually switch the 4-way valve to nitrogen. | ✓ |
| 6.3.6.2 | Verify MKS baratron pressure is less than 0.1×10^{-3} Torr. | ✓ |
| 6.3.6.3 | Open all three SUMS valves. | ✓ |
| 6.3.6.4 | Set valve control select switch on GSE I/F to "SUMS". | ✓ |

IE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP 3290648	REV B
SCALE	WEIGHT	SHEET 56	

ORIGINAL PAGE 13
OF POOR QUALITY

- 6.3.6.5 Slowly open Varian leak to raise pressure high enough to cause SUMS to automatically close the range valve. (approx. 5×10^{-3} Torr) *closed at $P \sim 10 \times 10^{-3}$ Torr* ✓
- 6.3.6.6 Close Varian leak and again verify that pressure is less than 0.1×10^{-3} Torr. *ion pump current ~ 30 mA.* ✓
- 6.3.6.7 On the HP 85 load "COMPOS" program. ✓
- 6.3.6.8 Verify SUMS is running on filament #1. ✓
- 6.3.7 Data Collection (O_2 switching to N_2)

NOTE

For this test the pressure ramp is manually controlled by the operator using the Varian leak valve. The valve is used to obtain as smooth a curve as possible while staying close to the desired curve. The HP 85 display is used to indicate how close to the desired curve the pressure ramp is and the chart recorder shows how smooth it is.

- 6.3.7.1 Start the paper in the chart recorder. (Slow) ✓
- 6.3.7.2 Type run on the HP 85. The program is interactive through the collection of all data.
- The HP 85 gives you a choice of four run types. Run each of the four until a good run is obtained for all. The data for the four runs will be stored on tape in files "COMP1", "COMP2", "COMP3" and "COMP4". ✓
- 6.3.7.3 Load the "30XFER" program on the HP 85. Transfer the data from the four runs to the HP 9830. Record data tape information below:

E BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A
SCALE

CODE IDENT NO.
07038

DRAWING NUMBER
TP 3290648

REV
B

WEIGHT

SHEET 57

ORIGINAL PAGE 13
OF POOR QUALITY

O₂ SWITCHING TO N₂

RUN TYPE	TAPE # (300 series)	BULK FILE #
#1	301	1
#2	301	2
#3	301	3
#4	301	4

ion currents before runs

#	background P.	32 peak	2.8 peak
#1	—	—	—
#2	1.5×10^{-5} Torr	6.0×10^{-13} A	2.6×10^{-12} A
#3	$< 10^{-6}$ Torr	6.0×10^{-13} A	4.8×10^{-12} A
#4	$< 10^{-6}$ Torr	7.9×10^{-13} A	5.1×10^{-12} A

6.3.8 Data Collection (N₂ Switching to N₂/O₂)

- 6.3.8.1 Remove the oxygen tank from the "gas #1" fitting on the 4-way valve. Replace this with the nitrogen tank, again via the flow meter. ✓
- 6.3.8.2 Connect the N₂/O₂ mixture to the "gas #2" fitting on the 4-way valve, via the flow meter. ✓
- 6.3.8.3 Open the valves on both tanks and set the regulators to 5 psi. ✓
- 6.3.8.4 Checking first to make sure the flow meters are level, set each so that the black ball is centered at 15. ✓
- 6.3.8.5 Load "COMPOS" program on the HP 85. ✓
- 6.3.8.6 Start the paper in the chart recorder. (Slow) ✓
- 6.3.8.7 Type run on the HP 85. Again run each of the four run types until four good ones are obtained. ✓

1E BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP 3290648	REV B
SCALE	WEIGHT	SHEET 58	

- 6.3.8.8 Load the "30 XFER" program on the HP 85. Transfer the data from the four runs to the HP 9830. Record data tape information below:

N₂ SWITCHING TO N₂/O₂

RUN	TYPE	TAPE # (300 series)	BULK FILE #
#1		301	5
#2		301	6
#3		302	1
#4		302	2

ion currents before runs

	baratron P.	32 peak	2 B peak
#1	$< 10^{-6} T$	$6.0 \times 10^{-12} A$	$3.5 \times 10^{-12} A$
#2	$< 10^{-6} T$	$5.6 \times 10^{-12} A$	$3.3 \times 10^{-12} A$
#3	$< 10^{-6} T$	$6.5 \times 10^{-12} A$	$4.9 \times 10^{-12} A$
#4	$< 10^{-6} T$	$5.4 \times 10^{-12} A$	$3.3 \times 10^{-12} A$

- 6.3.9 SUMS Background Spectra (After Run)

- 6.3.9.1 Record the time (as read from the UAMS test set) at which the calibration station was pumped down following the last run. Pressure was 10 Torr.

20:40 Hrs.

- 6.3.9.2 Fully open the calibration station throttling valve.

- 6.3.9.3 Verify that the chamber pressure is less than 1×10^{-6} Torr.

5×10^{-8} Torr

- 6.3.9.4 Load and run file 0 of the SUMS functional test tape on the HP 9830. Record data tape information below.

range valve was
still closed.

SUMS Data Tape I.D.#

9

Bulk File #(1,2,3 or 4)

2

- 6.3.10 Instrument Turn-Off

- 6.3.10.1 Turn off SUMS ion pump and instrument power.

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE	CODE IDENT NO.	DRAWING NUMBER	REV
A	07038	TP 3290648	B
SCALE	WEIGHT	SHEET	
		59	

ORIGINAL PAGE 13
OF POOR QUALITY

- 6.3.10.2 Turn on SUMS Vacuum Maintenance Power. ✓
- 6.3.10.3 Attach all data to this procedure, including chart recorder output tapes. ✓

END OF SUMS COMPOSITION CHANGE CALIBRATION

E BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP 3290648	REV B
SCALE	WEIGHT	SHEET 60	

7.0

Procedure Variation Sheet

ORIGINAL PAGE 13
OF POOR QUALITY

E BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP 3290648

REV
B

SCALE

WEIGHT

SHEET 61

8.0

Hardware Discrepancy Sheet

ORIGINAL PAGE IS
OF POOR QUALITY

E BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE A	CODE IDENT NO. 07038	DRAWING NUMBER TP 3290648	REV B
SCALE	WEIGHT	SHEET 62	

ORIGINAL PAGE 13
OF POOR QUALITY

9.0

Sign-Off Sheet

The SUMS instrument has been successfully calibrated per
this procedure.

SUMS SN# 1

UAMS SN# 6

Greg Robertson 3-48-82
Test Conductor Date

THE BENDIX COMMUNICATIONS DIVISION
AEROSPACE SYSTEMS OPERATIONS
ANN ARBOR, MICHIGAN

SIZE
A

CODE IDENT NO.
07038

DRAWING NUMBER
TP 3290648

REV
B

SCALE

WEIGHT


SHEET 63

ORIGINAL PAGE IS
OF POOR QUALITY

10 6110 31

Tape #009

File #1



ORIGINAL PAGE IS
OF POOR QUALITY

3 24 1982 1437 HPS

SUMS
FUNCTIONAL TEST

S/N 6

PAGE 1 OF 8

DATA TAPE ID 9 BULK DATA FILE # 1

SUMS FUNCTIONAL TEST

TP3290648: COMP CHANGE: BKG SCAN (BEFORE RUN) INLET OPEN: RANGE CLOSED.

ext. press (chamber 6×10^{-8} Torr)

HOUSEKEEPING DATA FILAMENT NUMBER 1

SCAN NUMBER	1	2	3	4	5	6	7	8	ANAL MUX
INTERLACE STEP	1	2	3	4	1	2	3	4	
IONIZATION ENERGY	75	75	75	75	75	75	75	75	
FILAMENT NUMBER	1	1	1	1	1	1	1	1	
CAF ON=1, OFF=2	1	1	1	1	1	1	1	1	
PLUS 15 VOLT	193	193	193	193	193	193	193	193	0.000
MINUS 15 VOLT	130	130	130	130	130	130	130	130	-15.090
ION PUMP VOLT	181	181	181	180	181	180	181	181	0.000
ION SOURCE TEMP	90	90	90	90	90	90	90	90	0.000
PRE-AMP TEMP	167	167	167	167	167	167	167	167	0.000
PLUS 5 VOLT	120	121	121	120	121	121	120	120	0.000
A/D REFERENCE VOLT	163	163	163	163	163	163	163	163	
EMISSION CURRENT	126	125	125	126	125	125	126	126	0.000
COLLECTOR CURRENT	113	113	113	112	112	112	113	112	0.000
ELECTRON ACC VOLT	190	190	190	189	189	190	190	189	0.000
ION ACC VOLT	39	39	39	39	39	39	39	39	0.000
ION PUMP ANALOG									2.0mV 0.0020
28 VOLT POWER SUP									0.000

ORIGINAL PAGE 19
OF POOR QUALITY

2/ 2/ 1982 1437 HRS

SUMS
FUNCTIONAL TEST

S/N 6

PAGE 2 OF 8

75 ELECTRON VOLTS IONIZATION ENERGY


SCAN STEP NO	-----HIGH MASS COLLECTOR-----				-----LOW MASS COLLECTOR-----			
	SCAN 1	SCAN 2	SCAN 3	SCAN 4	SCAN 1	SCAN 2	SCAN 3	SCAN 4
1	0	0	0	0	4	12	4	4
2	0	0	0	0	0	0	0	0
3	0	0	0	0	0	0	0	0
4	0	0	0	0	0	0	0	0
5	0	0	0	0	0	0	0	0
6	0	0	0	0	0	0	0	0
7	0	0	0	0	0	0	0	0
8	0	0	0	0	0	0	0	0
9	0	0	0	0	0	0	0	0
10	0	0	0	0	0	0	0	0
11	0	0	0	0	0	0	0	0
12	0	0	0	0	0	0	0	0
13	0	0	0	0	0	0	0	0
14	0	0	0	0	0	0	0	0
15	0	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0	0
17	0	0	0	0	0	0	0	0
18	0	0	0	0	0	0	0	0
19	0	0	0	0	0	0	0	0
20	0	0	0	0	0	0	0	0
21	0	0	0	0	0	0	0	0
22	0	0	0	0	0	0	0	0
23	0	0	0	0	0	0	0	0
24	0	0	0	0	0	0	0	0
25	0	0	0	0	0	0	0	0
26	0	0	0	0	0	0	0	0
27	0	0	0	0	0	0	0	0
28	0	0	0	0	0	0	0	0
29	0	0	0	0	0	0	0	0
30	0	0	0	0	0	0	0	0
31	0	0	0	0	0	0	0	0
32	0	0	0	0	0	0	0	0
33	0	0	0	0	0	0	0	0
34	0	0	0	0	0	0	0	0
35	0	0	0	0	0	0	0	0
36	0	0	0	0	0	0	0	0
37	0	0	0	0	0	0	0	0
38	0	0	0	0	0	0	0	0
39	0	0	0	0	0	0	0	0
40	0	0	0	0	0	0	0	0
41	0	0	0	0	0	0	0	0
42	0	0	0	0	0	0	0	0
43	0	0	0	0	0	0	0	0
44	0	0	0	0	0	0	0	0
45	0	0	0	0	0	0	0	0
46	0	0	0	0	0	0	0	0
47	0	0	0	0	0	0	0	0
48	0	0	0	0	0	0	0	0
49	0	0	0	0	0	0	0	0
50	0	0	0	0	0	0	0	0

PAGE 4 OF 6

[illegible]

ORIGINAL PAGE 13
OF POOR QUALITY

1 2 2/ 1982 1437 6 PAGE 5 OF 6



171	0	0	0	0	12		
172	0	0	0	0		12	
173	0	0	0	0			12
174	0	0	0	0			4
175	0	0	0	0			
176	0	0	0	0	4		
177	0	0	0	0		12	
178	0	0	0	0			12
179	0	0	0	0			4
180	0	0	0	0			
181	0	0	0	0	4		
182	0	0	0	0		12	
183	0	0	0	0			12
184	0	0	0	0			4
185	0	0	0	0			
186	0	0	0	0	4		
187	0	0	0	0		19	
188	0	0	0	0			4
189	0	0	0	0			4
190	0	0	0	0	4		
191	0	0	0	0		4	
192	0	0	0	0			4
193	0	0	0	0			4
194	0	0	0	0			
195	0	0	0	0	4		
196	0	0	0	0		4	
197	0	0	0	0			4
198	0	0	0	0			4
199	0	0	0	0			
200	0	0	0	0	4		
201	0	0	0	0		4	
202	0	0	0	0			4
203	0	0	0	0			
204	0	0	0	0			4
205	0	0	0	0			
206	0	0	0	0	4		
207	0	0	0	0		19	
208	0	0	0	0			19
209	0	0	0	0			970
210	0	0	0	0			
211	0	0	0	0	2535		
212	0	0	0	0		3325	
213	0	0	0	0			3510
214	0	0	0	0	114		3630
215	114	175	145	114			
216	114	175	130	160	3570		
217	145	130	160	114		3695	
218	0	29	29	0			3695
219	0	0	0	0			3695
220	0	0	0	0			
221	0	0	0	0	3695		
222	0	0	0	0		3755	
223	0	0	0	0			3755
224	0	0	0	0			3755
225	0	0	0	0			
226	0	0	0	0	3755		
227	0	0	0	0		3755	
228	0	0	0	0			3755
229	29	0	0	0			3755
230	0	0	0	0			

ORIGINAL PAGE IS
OF POOR QUALITY

3/ 2/ 1982 1437 6

PAGE 6 OF 8

[illegible]

290 0 8 23 8

ORIGINAL PAGE 19
OF POOR QUALITY

3/ 2/ 1982 1437 6

PAGE 7 OF 8

1

291	23	0	30	30	4	27	4	4
292	0	0	0	0				
293	0	0	0	0				
294	23	0	0	0				
295	0	0	0	0				
296	30	0	0	0	4	19	4	4
297	0	0	0	0				
298	0	0	0	0				
299	0	0	0	0				
300	0	0	0	0				
301	0	0	0	0	4	19	4	4
302	0	0	0	0				
303	30	0	0	0				
304	0	0	0	0				
305	0	0	0	0	4	27	4	4
306	0	0	0	0				
307	23	0	0	0				
308	0	0	0	0				
309	0	0	0	0				
310	0	0	0	0	4	12	4	4
311	0	0	0	0				
312	0	0	0	0				
313	0	0	0	0				
314	0	0	0	0				
315	0	0	0	0	4	19	4	4
316	0	0	0	0				
317	0	0	0	0				
318	0	0	0	0				
319	0	0	0	0				
320	0	0	0	0	4	42	35	42
321	0	0	0	0				
322	23	0	0	0				
323	23	0	0	0				
324	0	0	0	0				
325	0	0	0	0				
326	0	0	0	0	42	80	35	35
327	0	0	0	0				
328	0	0	0	0				
329	23	0	0	0				
330	0	0	0	0				
331	0	0	0	0	57	80	35	35
332	0	0	0	0				
333	0	0	0	0				
334	0	0	0	0				
335	0	0	0	0	50	57	35	35
336	0	0	0	0				
337	0	0	0	0				
338	0	0	0	0				
339	0	0	0	0				
340	30	0	0	0	65	65	42	19
341	0	0	0	0				
342	0	0	0	0				
343	0	0	0	0				
344	0	0	0	0				
345	0	0	0	0	35	27	4	4
346	0	0	0	0				
347	0	0	0	0				
348	0	0	0	0				
349	23	0	0	0				
350	0	0	0	0				

ORIGINAL PAGE IS
OF POOR QUALITY

3/ 2/ 1982 1437 6

PAGE 8 OF 8

351 8 8 8 23 4
352 8 8 8 8 4
353 23 8 8 4
354 23 8 8 4
355 8 8 8 4
356 23 8 8 4
357 8 8 8 4
358 8 8 8 4
359 8 8 8 4
360 8 8 8 4

ORIGINAL PAGE 19
OF POOR QUALITY

3/ 2/ 1982 1447 HRS

SUMS
FUNCTIONAL TEST

S/N 6

PAGE 1 OF 6

DATA TAPE ID 9 BULK DATA FILE # 1

SUMS FUNCTIONAL TEST

CHAMBER PRESSURE GE-8 TORF BOTH FILAMENTS

HOUSEKEEPING DATA FILAMENT NUMBER 2

SCAN NUMBER	1	2	3	4	5	6	7	8	ANAL MUX
INTERLACE STEP	1	2	3	4	1	2	3	4	
IONIZATION ENERGY	75	75	75	75	75	75	75	75	
FILAMENT NUMBER	2	2	2	2	2	2	2	2	
CAP ON=1, OFF=2	1	1	1	1	1	1	1	1	
PLUS 15 VOLT	193	193	193	193	193	193	193	193	43.600
MINUS 15 VOLT	130	130	130	129	130	130	130	130	-15.000
ION PUMP VOLT	181	181	181	180	181	181	181	181	4.901
ION SOURCE TEMP	90	90	89	90	90	89	90	89	4.061
PRE-AMP TEMP	167	167	167	167	167	167	167	167	4.062
PLUS 5 VOLT	120	120	120	120	120	120	120	120	4.061
A/D REFERENCE VOLT	163	163	163	163	163	163	163	163	4.062
EMISSION CURRENT	125	125	125	125	125	125	125	125	4.061
COLLECTOR CURRENT	106	105	106	106	105	105	105	106	4.061
ELECTRON ACC VOLT	189	190	189	189	190	190	190	189	4.062
ION ACC VOLT	39	39	39	39	39	39	39	39	4.062

ION PUMP ANALOG
20 VOLT POWER SUP

2.040.0020
42.070

ORIGINAL PAGE 13
OF POOR QUALITY

3/ 2/ 1962 1447 HPS

SUMS
FUNCTIONAL TEST SIN 6

PAGE 2 OF 8

75 ELECTRON VOLTS IONIZATION ENERGY



SCAN STEP NO	-----HIGH MASS COLLECTOR-----				-----LOW MASS COLLECTOR-----			
	SCAN 1	SCAN 2	SCAN 3	SCAN 4	SCAN 1	SCAN 2	SCAN 3	SCAN 4
1					12			
2						4		
3							4	
4								4
5					12			
6						4		
7							4	
8								12
9					19			
10						4		
11							4	
12								4
13					19			
14						4		
15							4	
16								19
17					4			
18						4		
19							4	
20								12
21					12			
22						4		
23							4	
24								12
25					4			
26						4		
27							4	
28					4			
29						4		
30							4	
31					4			
32						4		
33							4	
34								4
35					4			
36						4		
37							4	
38								4
39							19	
40								4
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

ORIGINAL PAGE 18
OF POOR QUALITY

3/ 2/ 1982 1447 6

PAGE 3 OF 8

2



100 101 102 103 104 105 106 107 108 109 110

100 101 102 103 104 105 106 107 108 109 110

100 101 102 103 104 105 106 107 108 109 110

100 101 102 103 104 105 106 107 108 109 110

100 101 102 103 104 105 106 107 108 109 110

4 4 4 4 4 4 4 4 4 4 4

4 4 4 4 4 4 4 4 4 4 4

12 12 19 4 12 4 19 12 4 4

19 4 12 12 4 12 4 4 27

ORIGINAL PAGE 19
OF POOR QUALITY

2



3/ 2/ 1982 1447 6

PAGE 4 OF 6

111	0	0	20	0	19			
112	0	0	0	0		4		
113	0	0	0	0			4	19
114	0	0	0	0				
115	0	0	0	0				
116	0	0	0	0	4			
117	0	0	0	0		4		
118	0	0	0	0			4	
119	0	0	0	0				12
120	0	0	0	0				
121	0	0	0	0	12			
122	0	0	0	0		4		
123	0	0	0	0			4	
124	0	0	0	0				35
125	0	0	0	0				
126	0	0	0	0	12			
127	0	0	0	0		4		
128	0	0	0	0			4	
129	0	0	0	0				27
130	0	0	0	0				
131	0	0	0	0	19			
132	0	0	0	0		4		
133	0	0	0	0			4	
134	0	0	0	0				35
135	0	0	0	0				
136	0	0	0	0	12			
137	0	0	0	0		4		
138	0	0	0	0			27	
139	0	0	0	0				19
140	0	0	0	0	12			
141	0	0	0	0		4		
142	0	0	0	0			12	
143	0	0	0	0				19
144	0	0	0	0				
145	0	0	0	0	4			
146	0	0	0	0		4		
147	0	0	0	0			12	
148	0	0	0	0				27
149	0	0	0	0	4			
150	0	0	0	0		4		
151	0	0	0	0			12	
152	0	0	0	0				19
153	0	0	0	0	4			
154	0	0	0	0		4		
155	0	0	0	0			12	
156	0	0	0	0	4			
157	0	0	0	0		4		
158	0	0	0	0			12	
159	0	0	0	0				19
160	0	0	0	0	4			
161	0	0	0	0		4		
162	0	0	0	0			4	
163	0	0	0	0				19
164	0	0	0	0				
165	0	0	0	0	4			
166	0	0	0	0		4		
167	0	0	0	0			12	
168	0	0	0	0				12
169	0	0	0	0				
170	0	0	0	0				

ORIGINAL PAGE IS
OF POOR QUALITY

2 2 2 1982 1447 6 PAGE 5 OF 8



171	0	20	20	0	4			
172		20	20	114		4		
173	17	20	20	313			12	
174	20	20	20	24				19
175	20	20	20	20		4		
176	20	20	20	20				
177	114	20	20	20		4		
178	0	20	20	20			4	
179	0	20	20	20				27
180	0	20	20	20		4		
181	0	20	20	20				
182	0	20	20	20		4		
183	0	20	20	20			12	
184	0	20	20	20				12
185	0	20	20	20		4		
186	0	20	20	20				
187	0	20	20	20		4		
188	0	20	20	20			15	
189	0	20	20	20				19
190	0	20	20	20		4		
191	0	20	20	20				
192	0	20	20	20		4		
193	114	20	20	20			4	
194	0	20	20	20				12
195	0	20	20	20		4		
196	0	20	20	20				
197	0	20	20	20		4		
198	0	20	20	20			15	
199	0	20	20	20				12
200	0	20	20	20		15		
201	0	20	20	20			4	
202	0	20	20	20				35
203	0	20	20	20				4
204	0	20	20	20		4		
205	0	20	20	20				
206	0	20	20	20		4		
207	0	20	20	20			19	
208	0	20	20	20				376
209	0	20	20	20		925		
210	0	20	20	20			1175	
211	0	20	20	20				1295
212	0	20	20	20				1295
213	0	20	20	20				
214	0	114	20	20				
215	100	20	20	20				
216	100	20	20	20		1295		
217	145	20	20	20			1330	
218	0	20	20	20				1360
219	0	20	20	20				1330
220	0	20	20	20				
221	0	20	20	20		1230		
222	0	20	20	20			1295	
223	0	20	20	20				1360
224	0	20	20	20				1330
225	0	20	20	20				
226	0	20	20	20		1230		
227	0	20	20	20			1295	
228	0	20	20	20				1360
229	0	20	20	20				1330
230	0	20	20	20				

ORIGINAL PAGE IS
OF POOR QUALITY

3/ 2/ 1982 1447 6

PAGE 6 OF 8



Year	1990	1995	2000	2005
1990	50	4	12	195
1991	4	4	19	4
1992	4	4	4	12
1993	4	4	4	4
1994	4	4	12	19
1995	4	4	27	19
1996	4	4	19	19
1997	4	4	19	27
1998	4	4	27	4
1999	4	4	19	12
2000	4	4	19	19
2001	12	4	19	12

	P ₁	P ₂	P ₃	P ₄	P ₅	P ₆	P ₇	P ₈	P ₉	P ₁₀	P ₁₁	P ₁₂	P ₁₃	P ₁₄	P ₁₅	P ₁₆	P ₁₇	P ₁₈	P ₁₉	P ₂₀	P ₂₁	P ₂₂	P ₂₃	P ₂₄	P ₂₅	P ₂₆	P ₂₇	P ₂₈	P ₂₉	P ₃₀	P ₃₁	P ₃₂	P ₃₃	P ₃₄	P ₃₅	P ₃₆	P ₃₇	P ₃₈	P ₃₉	P ₄₀	P ₄₁	P ₄₂	P ₄₃	P ₄₄	P ₄₅	P ₄₆	P ₄₇	P ₄₈	P ₄₉	P ₅₀	P ₅₁	P ₅₂	P ₅₃	P ₅₄	P ₅₅	P ₅₆	P ₅₇	P ₅₈	P ₅₉	P ₆₀	P ₆₁	P ₆₂	P ₆₃	P ₆₄	P ₆₅	P ₆₆	P ₆₇	P ₆₈	P ₆₉	P ₇₀	P ₇₁	P ₇₂	P ₇₃	P ₇₄	P ₇₅	P ₇₆	P ₇₇	P ₇₈	P ₇₉	P ₈₀	P ₈₁	P ₈₂	P ₈₃	P ₈₄	P ₈₅	P ₈₆	P ₈₇	P ₈₈	P ₈₉	P ₉₀	P ₉₁	P ₉₂	P ₉₃	P ₉₄	P ₉₅	P ₉₆	P ₉₇	P ₉₈	P ₉₉	P ₁₀₀	P ₁₀₁	P ₁₀₂	P ₁₀₃	P ₁₀₄	P ₁₀₅	P ₁₀₆	P ₁₀₇	P ₁₀₈	P ₁₀₉	P ₁₁₀	P ₁₁₁	P ₁₁₂	P ₁₁₃	P ₁₁₄	P ₁₁₅	P ₁₁₆	P ₁₁₇	P ₁₁₈	P ₁₁₉	P ₁₂₀	P ₁₂₁	P ₁₂₂	P ₁₂₃	P ₁₂₄	P ₁₂₅	P ₁₂₆	P ₁₂₇	P ₁₂₈	P ₁₂₉	P ₁₃₀	P ₁₃₁	P ₁₃₂	P ₁₃₃	P ₁₃₄	P ₁₃₅	P ₁₃₆	P ₁₃₇	P ₁₃₈	P ₁₃₉	P ₁₄₀	P ₁₄₁	P ₁₄₂	P ₁₄₃	P ₁₄₄	P ₁₄₅	P ₁₄₆	P ₁₄₇	P ₁₄₈	P ₁₄₉	P ₁₅₀	P ₁₅₁	P ₁₅₂	P ₁₅₃	P ₁₅₄	P ₁₅₅	P ₁₅₆	P ₁₅₇	P ₁₅₈	P ₁₅₉	P ₁₆₀	P ₁₆₁	P ₁₆₂	P ₁₆₃	P ₁₆₄	P ₁₆₅	P ₁₆₆	P ₁₆₇	P ₁₆₈	P ₁₆₉	P ₁₇₀	P ₁₇₁	P ₁₇₂	P ₁₇₃	P ₁₇₄	P ₁₇₅	P ₁₇₆	P ₁₇₇	P ₁₇₈	P ₁₇₉	P ₁₈₀	P ₁₈₁	P ₁₈₂	P ₁₈₃	P ₁₈₄	P ₁₈₅	P ₁₈₆	P ₁₈₇	P ₁₈₈	P ₁₈₉	P ₁₉₀	P ₁₉₁	P ₁₉₂	P ₁₉₃	P ₁₉₄	P ₁₉₅	P ₁₉₆	P ₁₉₇	P ₁₉₈	P ₁₉₉	P ₂₀₀	P ₂₀₁	P ₂₀₂	P ₂₀₃	P ₂₀₄	P ₂₀₅	P ₂₀₆	P ₂₀₇	P ₂₀₈	P ₂₀₉	P ₂₁₀	P ₂₁₁	P ₂₁₂	P ₂₁₃	P ₂₁₄	P ₂₁₅	P ₂₁₆	P ₂₁₇	P ₂₁₈	P ₂₁₉	P ₂₂₀	P ₂₂₁	P ₂₂₂	P ₂₂₃	P ₂₂₄	P ₂₂₅	P ₂₂₆	P ₂₂₇	P ₂₂₈	P ₂₂₉	P ₂₃₀	P ₂₃₁	P ₂₃₂	P ₂₃₃	P ₂₃₄	P ₂₃₅	P ₂₃₆	P ₂₃₇	P ₂₃₈	P ₂₃₉	P ₂₄₀	P ₂₄₁	P ₂₄₂	P ₂₄₃	P ₂₄₄	P ₂₄₅	P ₂₄₆	P ₂₄₇	P ₂₄₈	P ₂₄₉	P ₂₅₀	P ₂₅₁	P ₂₅₂	P ₂₅₃	P ₂₅₄	P ₂₅₅	P ₂₅₆	P ₂₅₇	P ₂₅₈	P ₂₅₉	P ₂₆₀	P ₂₆₁	P ₂₆₂	P ₂₆₃	P ₂₆₄	P ₂₆₅	P ₂₆₆	P ₂₆₇	P ₂₆₈	P ₂₆₉	P ₂₇₀	P ₂₇₁	P ₂₇₂	P ₂₇₃	P ₂₇₄	P ₂₇₅	P ₂₇₆	P ₂₇₇	P ₂₇₈	P ₂₇₉	P ₂₈₀	P ₂₈₁	P ₂₈₂	P ₂₈₃	P ₂₈₄	P ₂₈₅	P ₂₈₆	P ₂₈₇	P ₂₈₈	P ₂₈₉	P ₂₉₀	P ₂₉₁	P ₂₉₂	P ₂₉₃	P ₂₉₄	P ₂₉₅	P ₂₉₆	P ₂₉₇	P ₂₉₈	P ₂₉₉	P ₃₀₀	P ₃₀₁	P ₃₀₂	P ₃₀₃	P ₃₀₄	P ₃₀₅	P ₃₀₆	P ₃₀₇	P ₃₀₈	P ₃₀₉	P ₃₁₀	P ₃₁₁	P ₃₁₂	P ₃₁₃	P ₃₁₄	P ₃₁₅	P ₃₁₆	P ₃₁₇	P ₃₁₈	P ₃₁₉	P ₃₂₀	P ₃₂₁	P ₃₂₂	P
--	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	------------------	---

ORIGINAL PAGE 13
OF POOR QUALITY

2 3/ 2/ 1982 1447 6 PAGE 8 OF 8

351	0	0	0	10	4			
352	0	20	0	0		4		
353	10	0	10	0			4	
354	0	0	0	10				4
355	0	0	0	0				
356	0	10	10	0	4			
357	0	0	10	0		4		
358	0	0	0	0			4	
359	0	20	0	0				4
360	0	20	0	0				




TIME (SEC)	BARATRON PRESSURE (TORR)	AMU 32	AMU 28	AMU 16	AMU 14
(5 BIT)					
425.0	0.020197	17	103	6	13
430.1	0.021556	16	104	7	12
435.3	0.039504	18	104	4	13
445.0	0.046640	18	103	5	11
449.8	0.043625	21	103	5	10
455.1	0.058579	21	103	7	13
460.1	0.070416	22	103	8	12
465.0	0.066071	24	103	6	11
469.9	0.077958	32	103	12	14
475.0	0.063562	31	103	9	12
480.1	0.103468	35	103	7	12
485.1	0.115640	38	103	8	11
490.1	0.161000	44	102	7	9
495.1	0.169130	51	102	10	10
500.1	0.198870	63	102	8	12
504.9	0.211430	71	102	12	11
509.9	0.262460	76	103	13	14
515.0	0.287340	84	103	13	12
519.9	0.315450	96	103	17	13
525.0	0.381460	100	104	16	11
530.1	0.414870	107	104	20	10
534.9	0.475620	117	105	20	13
539.9	0.537390	124	106	26	12
545.1	0.620760	133	106	28	12
549.9	0.649010	138	107	32	12
555.0	0.858410	147	108	38	14
559.9	0.859400	156	109	48	16
565.0	0.993500	165	110	52	12
*** COMPOSITION SWITCH ***					
569.9	1.075500	169	112	58	15
575.0	1.231900	167	162	50	58
579.9	1.374400	159	197	47	89
585.0	1.574700	147	216	41	104
589.9	1.714300	138	228	37	115
594.0	1.973100	131	236	31	125
599.9	2.202500	122	242	30	131
605.0	2.487000	110	251	27	137
610.0	2.598300	105	259	23	143
615.0	2.863500	98	264	23	147
619.9	3.108400	98	267	24	151
624.0	3.362300	91	270	22	157
629.9	3.662600	88	275	22	162
635.0	3.852700	82	280	22	165
639.9	4.165000	79	287	23	167
644.0	4.389600	76	288	20	169
650.0	4.569300	74	290	23	172
654.0	4.776300	73	291	21	173
659.9	4.853500	74	293	21	175
664.0	5.112700	76	294	20	177
669.9	5.235800	76	296	20	179
674.0	5.377600	76	297	22	180
679.9	5.414800	80	298	23	181
685.0	5.557500	84	299	26	182
689.0	5.534500	90	300	24	184
694.0	5.633100	95	300	25	184
699.0	5.712500	103	301	27	184
705.0	5.859800	106	301	29	185
709.0	5.924600	107	302	27	186
714.0	5.975100	106	302	28	187
719.0	6.035100	111	303	31	187
724.0	6.083200	115	303	32	187
729.0	6.319100	119	304	32	188
734.0	6.324300	119	304	31	189
739.0	6.390100	114	306	31	190
744.0	6.486200	119	306	31	191
749.0	6.557500	121	307	32	191
754.0	6.701300	122	307	33	192
759.0	6.789800	122	308	31	193
764.0	6.874700	119	309	30	193
769.0	6.959900	119	310	31	194
774.0	7.048200	119	310	32	194
779.0	7.142800	120	311	31	195







ORIGINAL PAGE 13
OF POOR QUALITY

764.1	7.249300	121	312	31	195
764.2	7.357500	122	313	32	196
764.3	7.459500	119	314	32	196
764.4	7.557900	119	315	31	197
804.1	7.653000	119	316	31	197
804.2	7.756300	119	317	34	198
814.1	7.860900	119	317	32	198
814.2	7.961900	119	320	31	199
824.1	8.0154000	117	320	30	199
824.2	8.1255000	119	320	31	200
834.1	8.2374000	111	321	31	201
834.2	8.3491000	112	321	31	201
844.1	8.4605000	111	322	30	202
844.2	8.5725000	110	322	32	202
854.1	8.6841000	106	323	27	203
854.2	8.7960000	109	323	31	203
864.1	8.9082000	109	324	30	204
864.2	9.0207000	108	324	30	205
874.1	9.1334000	107	325	30	206
874.2	9.2449000	107	325	31	206
884.1	9.3574000	107	326	32	207
884.2	9.4700000	107	327	32	208
894.1	9.5834000	105	327	32	208
894.2	9.6964000	105	328	30	209
904.1	9.81052000	105	328	31	209

SUMS COMP CHANGE CAL DATA. RUN TYPE 01, D2==N2, TAPE 0301, BULK FILE 01




() ()








ORIGINAL PAGE IS
OF POOR QUALITY

TIME (SEC)	BARATRON PRESSURE (TORR)	AMU 32	AMU 28	AMU 16	AMU 14
				(9 BIT)	
440.0	0.024586	23	116	6	16
445.0	0.025435	24	116	6	14
450.0	0.023356	21	116	6	14
455.0	0.011064	22	116	6	17
460.0	0.064315	23	117	6	16
465.1	0.046336	26	116	6	16
469.9	0.053901	26	120	6	17
473.0	0.064376	27	120	6	16
478.0	0.093642	22	122	6	16
484.0	0.075810	25	123	6	16
489.0	0.086440	29	123	6	19
494.0	0.086000	41	124	10	16
500.1	0.084700	46	123	10	16
504.0	0.243290	51	123	9	16
510.0	0.182520	61	121	12	17
515.0	0.221720	72	120	12	17
520.0	0.252660	61	120	15	16
524.0	0.297720	91	120	15	17
529.0	0.351790	100	120	16	16
533.0	0.410310	107	119	20	17
539.0	0.471430	116	118	24	16
545.0	0.564750	127	118	26	16
550.0	0.659710	135	118	31	19
554.0	0.766690	143	118	38	17
559.0	0.873300	155	118	44	17
563.0	1.173200	164	116	55	15
*** COMPOSITION SWITCH ***					
570.0	1.217200	173	116	65	22
574.0	1.300900	166	180	56	75
579.0	1.627000	165	203	55	94
583.0	1.897000	154	223	40	111
588.0	2.172500	136	237	30	127
593.0	2.431300	127	246	24	134
598.0	2.679300	116	259	24	141
604.0	3.274400	106	264	23	149
609.0	3.782100	100	273	23	158
615.0	4.137600	93	287	23	164
619.0	4.472600	88	288	24	168
624.0	4.959900	88	289	21	171
629.0	5.409700	86	293	24	176
634.0	5.857800	80	297	23	180
639.0	6.366300	78	301	23	185
644.0	6.754600	75	305	23	190
649.0	7.010900	73	308	23	193
654.0	7.264800	74	311	23	194
659.0	7.596900	76	313	24	196
664.0	8.096500	76	316	27	197
669.0	8.007800	76	319	27	199
674.0	8.063000	75	314	27	200
679.0	8.153000	77	320	27	200
684.0	8.232000	61	321	26	200
689.0	8.362000	67	321	27	200
694.0	8.530000	94	321	27	201
699.0	8.625000	97	323	26	202
704.0	8.740000	96	323	26	202
709.0	8.839000	100	323	26	203
714.0	8.920000	102	323	31	203
719.0	9.112000	104	324	32	204
724.0	9.316000	106	324	32	204
729.0	9.514000	105	325	32	205
734.0	9.614000	103	326	32	206
739.0	9.686000	102	327	32	207
744.0	9.779000	104	327	31	207
749.0	9.947000	107	326	32	208
754.0	10.101000	109	326	36	208

SUNA COMP CHANGE CAL DATA. RUN TYPE 02, 02-->N2, TAPE 0301, BULK FILE 02.



10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100



ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE 19
OF POOR QUALITY


TIME (SEC)	BARATRON PRESSURE (TORR)	AMU 32	AMU 28	AMU 16	AMU 14
		(9 BIT)			
520.0	0.320620	123	140	25	19
525.0	0.322240	129	142	27	21
530.0	0.324130	132	143	27	22
535.4	0.326220	135	144	31	23
540.2	0.334600	137	145	31	21
545.2	0.334160	141	145	34	23
550.2	0.370320	151	145	39	23
555.2	0.750030	162	145	47	33
560.1	0.865040	167	146	53	32
565.2	0.896000	175	148	63	25
570.2	1.090100	182	150	60	24
575.2	1.236800	189	152	71	25
580.1	1.374900	196	154	78	23
585.2	1.540900	202	156	85	31
590.1	1.760700	208	162	93	30
595.2	1.955500	216	163	100	31
600.1	2.143400	223	165	104	33
605.2	2.342100	228	168	108	37
610.1	2.535700	233	170	114	37
615.1	2.737200	238	172	120	39
620.2	3.136300	245	173	127	41
625.1	3.496700	249	175	130	40
630.1	3.759900	253	177	135	42
635.2	3.873600	258	179	138	43
640.2	4.105700	263	181	140	46
645.1	4.380000	265	184	143	47
650.1	4.565700	268	185	146	50
655.1	4.738500	271	187	149	50
660.1	4.850000	273	188	151	51
665.1	5.186100	274	190	153	54
670.2	5.191800	277	190	157	54
675.1	5.334100	279	190	158	54
680.2	5.400700	280	190	159	53
685.2	5.479300	282	191	161	55
690.0	5.552700	282	193	162	56
695.1	5.625500	283	193	162	57
700.0	5.718600	287	193	162	58
705.1	5.794300	288	194	163	58
710.0	5.904400	288	195	164	58
715.1	5.991200	288	196	164	60
720.2	6.074600	289	196	165	60
725.2	6.131700	289	197	166	64
730.0	6.181100	290	197	167	64
735.1	6.318100	290	198	167	65
740.0	6.408700	291	198	167	66
745.1	6.510800	291	199	168	66
750.1	6.592400	292	200	169	67
755.0	6.688200	293	200	169	67
760.2	6.776100	293	200	169	68
765.0	6.854800	294	201	170	68
770.1	6.961600	294	202	171	69
775.1	7.061600	295	202	172	69
780.0	7.140400	295	203	172	69
785.1	7.294600	296	203	173	70
790.0	7.349000	296	204	174	70
795.0	7.423100	297	204	175	70
799.9	7.566500	297	205	174	70
805.0	7.657800	298	205	175	72
810.0	7.744800	298	206	176	72
814.9	7.846400	299	206	177	71
820.0	7.911300	300	207	177	71
824.8	8.101300	301	208	178	73
829.9	8.237000	302	209	180	74
835.0	8.337000	302	209	180	74
839.9	8.412000	303	209	180	73
845.0	8.546000	304	210	181	74
849.9	8.634000	304	211	182	75
855.0	8.748000	305	211	182	75
859.9	8.848000	305	211	183	75
865.0	9.023000	306	211	184	76
870.0	9.168000	307	211	185	76
874.9	9.304000	308	211	186	76
879.9	9.448000	308	211	186	75

ORIGINAL PAGE 19
OF POOR QUALITY




883.1	9.583000	310	212	187	77
883.9	9.691000	310	213	189	77
884.0	9.814000	311	213	189	77
889.0	10.228000	311	213	189	76
*** COMPOSITION SWITCH ***					
905.0	10.305000	312	214	191	76
909.0	10.437000	315	215	193	79
914.0	10.554000	315	221	193	88
920.0	10.648000	315	231	191	103
921.0	10.772000	314	241	191	113
923.0	10.895000	313	253	190	125
924.0	11.010000	311	263	188	133
929.0	11.145000	310	273	186	140
930.0	11.283000	309	273	185	146
930.0	11.420000	308	283	184	153
937.0	11.564000	306	283	182	159
937.0	11.697000	305	293	180	163
964.0	11.884000	304	293	180	167
969.0	12.083000	302	298	179	171
974.0	12.278000	301	302	176	173
979.0	12.447000	299	306	174	180
984.0	12.612000	297	311	172	184
989.0	12.790000	296	315	172	188
994.0	12.968000	295	320	170	191
999.0	13.152000	294	321	169	194
1004.0	13.356000	293	322	168	195
1009.0	13.541000	292	324	167	197
1014.0	13.722000	291	325	166	199
1019.0	13.893000	290	327	164	200
1024.0	14.058000	289	329	164	202
1029.0	14.254000	288	330	164	203
1034.0	14.418000	288	330	163	204
1039.0	14.639000	288	332	162	206
1044.0	14.853000	284	334	161	207
1049.0	15.078000	282	335	159	209
1054.0	15.317000	281	336	158	210
1059.0	15.565000	278	338	156	212
1064.0	15.775000	277	340	154	214
1069.0	15.997000	275	341	153	216
1074.0	16.201000	273	342	151	217
1079.0	16.422000	272	343	149	219
1084.0	16.660000	271	345	148	220
1089.0	16.900000	270	346	148	221

ORIGINAL PAGE IS
OF POOR QUALITY

SUNS COMP CHANGE CAL DATA. RUN TYPE 03, 02--02, TAPE 0301, FILE 03.



10 10 10 10 10 10



ORIGINAL PAGE IS
OF POOR QUALITY

— 〇 —

[illegible][illegible]


ORIGINAL PAGE 13
OF POOR QUALITY

TIME (SEC)	BARATRON PRESSURE (TORR)	AMU 32	AMU 28	AMU 16	AMU 14
		(9 BIT)			
515.0	0.223370	122	142	22	19
520.2	0.225020	125	143	23	21
525.4	0.309930	127	143	27	21
530.2	0.336340	130	143	26	21
535.2	0.411820	134	144	29	23
540.1	0.466320	139	145	30	21
545.2	0.541210	145	146	36	22
550.3	0.652170	153	146	41	21
555.1	0.767960	162	149	47	22
560.2	0.896300	170	150	58	25
565.1	1.075800	176	153	66	25
570.2	1.206200	188	154	70	25
575.1	1.370600	197	159	80	28
580.1	1.573800	203	163	86	29
585.2	1.915100	211	165	97	33
590.1	2.106800	222	167	103	36
595.2	2.712100	228	171	108	37
600.2	2.805600	236	173	120	41
605.1	3.071900	245	176	128	41
610.2	3.654400	250	177	131	45
615.1	4.157000	260	180	136	48
620.1	4.456400	267	185	143	50
625.2	4.889300	269	188	147	53
630.1	5.421800	274	190	152	55
635.2	5.860400	280	191	159	56
640.1	6.329100	285	194	163	59
645.2	6.688700	289	195	166	60
650.2	7.011700	292	198	168	62
655.2	7.382600	294	198	171	65
660.1	7.615400	296	200	173	66
665.0	7.827300	298	201	175	68
670.1	8.010900	299	202	176	69
675.1	8.088000	301	204	178	71
680.1	8.219000	302	206	179	71
685.3	8.344000	302	206	179	70
690.1	8.433000	303	206	179	72
695.0	8.604000	304	207	181	72
700.1	8.774000	305	208	182	74
705.0	8.736000	306	209	183	73
710.0	8.752000	306	209	182	73
715.1	8.997000	306	210	183	75
720.1	9.171000	307	211	185	76
725.0	9.241000	308	211	186	75
730.2	9.350000	309	212	186	77
735.0	9.493000	309	212	187	75
740.1	9.548000	310	212	188	76
745.0	9.627000	311	212	188	76
750.0	10.353000	311	212	188	76
	*** COMPOSITION SWITCH ***				
755.1	10.396000	313	213	191	77
760.0	10.424000	316	223	193	90
765.0	10.528000	315	227	192	93
770.0	10.630000	315	230	191	100
775.0	10.737000	315	237	191	108
780.2	10.844000	314	247	191	117
785.0	10.950000	313	257	190	127
790.0	11.064000	312	263	188	133
795.1	11.235000	311	268	187	138
800.0	11.400000	310	274	186	145
805.0	11.574000	309	283	184	155
810.1	11.748000	306	291	181	163
815.1	11.909000	304	295	180	167
820.1	12.076000	303	299	176	172
825.0	12.251000	301	303	176	175
830.0	12.463000	300	307	174	179
835.1	12.624000	299	311	173	184
840.1	12.792000	297	315	172	187
845.0	12.935000	296	320	170	190
849.2	13.126000	294	321	169	193
855.0	13.334000	294	323	169	194
859.9	13.445000	293	324	168	196
865.0	13.617000	292	325	167	197
869.9	13.813000	291	326	166	198
875.0	13.999000	291	327	165	200

ORIGINAL PAGE 19
OF POOR QUALITY

879.9	14.178000	290	328	164	202
884.9	14.363000	289	320	164	203
890.1	14.556000	288	321	162	205
895.0	14.741000	288	323	162	206
899.9	14.927000	285	324	162	207
904.9	15.116000	283	325	160	209
910.0	15.299000	283	326	158	210
914.9	15.493000	281	326	157	211
919.0	15.688000	279	329	157	213
924.9	15.900000	279	340	155	214
929.9	16.110000	277	341	154	215
934.8	16.330000	277	342	153	217
939.9	16.536000	274	344	152	218

SUMS COMP CHANGE CAL DATA. RUN TYPE 04, 02-->N2, TAPE 0301, FILE 04.



ORIGINAL PAGE 15
OF POOR QUALITY

10 11 12 13 14

SUM3 Composition Clay Chemical
O1 to W2, switch at 750
Run Type #4
34W BZ
Tape #301
Bulk File #4

005F5

515F4

20V.F.S

Summit Recording Equipment

MRS
range

505F4

505F4

Summit Recording Equipment

MRS
range

505F4

505F4

Summit Recording Equipment

25V.F.S

505F4

505F4

Summit Recording Equipment

505F4

505F4

505F4

505F4

505F4

505F4

505F4


ORIGINAL PAGE 15
OF POOR QUALITY



TIME (SEC)	BARATRON PRESSURE (TORR)	AMU 32	AMU 28	AMU 16	AMU 14
			(9 BIT)		
425.0	0.029590	35	130	10	18
430.4	0.028755	33	131	9	17
435.6	0.046585	37	132	7	18
445.3	0.043030	35	134	7	18
450.3	0.058622	35	135	8	18
455.1	0.061732	38	137	6	21
460.2	0.069210	38	138	8	20
465.3	0.078212	36	141	8	22
470.3	0.081831	35	144	8	24
475.2	0.083890	36	146	8	24
480.2	0.107810	37	149	7	28
485.4	0.137650	34	151	6	28
490.2	0.144100	33	156	7	31
495.1	0.169530	35	161	5	35
500.2	0.192730	33	164	7	37
505.3	0.219760	33	167	6	40
510.3	0.248690	32	171	7	43
515.3	0.273560	32	175	6	50
520.1	0.322780	35	180	7	56
525.2	0.369480	35	186	9	63
530.1	0.409660	34	193	10	67
535.1	0.460470	32	196	10	70
540.3	0.500640	32	200	5	74
545.1	0.608180	36	205	9	80
550.1	0.675780	32	211	7	87
555.1	0.774730	34	216	10	93
560.1	0.850850	34	223	7	98
565.1	0.970300	35	237	7	101
	*** COMPOSITION SWITCH ***				
570.2	1.085200	33	231	10	106
575.1	1.203300	58	234	13	109
580.1	1.381300	81	236	14	112
585.1	1.565200	101	240	18	116
590.1	1.723100	118	245	23	121
595.1	1.980800	137	249	24	125
600.3	2.146300	135	254	30	130
605.1	2.366100	142	259	34	133
610.1	2.696100	149	262	36	136
615.1	2.870400	158	266	43	140
620.1	3.192300	164	269	45	144
625.2	3.432700	167	274	52	148
630.1	3.635000	172	278	58	153
635.0	3.827400	176	281	63	156
640.1	4.145300	179	288	67	159
645.0	4.343300	183	289	68	162
650.0	4.561600	188	290	69	164
655.1	4.759400	191	292	71	165
660.0	4.963000	194	293	74	167
665.1	5.082500	195	294	77	168
670.1	5.135600	197	296	77	170
675.1	5.253700	198	297	78	170
680.1	5.378900	200	298	80	172
685.0	5.506700	200	299	80	173
690.1	5.661800	201	300	82	173
695.0	5.660700	203	300	82	174
700.0	5.738400	203	302	83	175
705.0	5.813000	203	302	84	176
710.0	5.870300	204	302	84	176
715.2	5.966200	205	303	85	176
720.0	6.014400	206	304	86	177
725.0	6.133300	206	304	86	178
730.1	6.221900	207	305	88	179
735.0	6.304600	208	306	88	180
739.9	6.393200	209	306	89	180
745.0	6.451300	209	308	91	181
749.9	6.573600	210	308	91	181
754.9	6.663000	211	308	91	182
760.0	6.714400	212	310	93	183
765.0	6.790500	213	310	94	184
770.1	6.967200	214	310	94	184
775.0	7.094500	215	311	96	185
779.9	7.152600	217	313	96	186
785.0	7.257800	217	313	97	187
790.0	7.331600	218	314	96	187

ORIGINAL PAGE IS
OF POOR QUALITY

795.0	7.451100	220	314	98	188
795.0	7.500000	220	315	98	189
805.0	7.646500	221	316	99	190
805.0	7.781700	222	317	100	190
815.0	7.883400	223	320	101	191
815.0	7.972500	225	320	101	191
824.0	8.070000	225	320	101	193
820.0	8.167000	226	320	102	193
834.0	8.297000	226	320	102	193
839.0	8.391000	227	321	103	194
844.0	8.486000	227	321	104	194
849.0	8.581000	228	322	104	195
854.0	8.698000	228	322	105	195
859.0	8.946000	229	323	105	195
864.0	9.066000	230	323	107	196
869.0	9.176000	231	324	107	197
875.0	9.285000	231	324	108	197
877.0	9.344000	232	325	108	197
884.0	9.446000	232	325	109	198
889.0	9.750000	233	325	109	198
894.0	9.881000	234	326	110	199
899.0	10.006000	235	327	111	200

SUMS COMP CHANGE CAL DATA. RUN TYPE 01, N2 00, N2/02, TAPE 0301, FILE 05.






ORIGINAL PAGE IS
OF POOR QUALITY



ORIGINAL PAGE IS
OF POOR QUALITY






TIME (SEC)	BARATRON PRESSURE (TORR)	AMU 32	AMU 28	AMU 16	AMU 14
				(9 BIT)	
440.0	0.021460	32	123	5	13
445.1	0.021820	31	125	5	15
450.0	0.034950	32	126	5	14
455.0	0.035330	31	126	5	16
460.1	0.046780	32	129	4	15
465.0	0.046200	30	130	6	16
470.0	0.057230	32	132	5	19
475.0	0.064160	37	135	5	21
480.0	0.067120	33	136	7	20
485.1	0.067100	33	136	6	19
490.0	0.074780	36	141	8	23
495.1	0.074540	35	144	8	24
499.9	0.072610	35	147	7	27
505.0	0.090270	36	149	7	30
509.9	0.181970	34	151	7	30
514.9	0.217940	34	155	6	28
520.0	0.268070	35	163	6	28
524.9	0.299640	35	169	6	43
530.0	0.349350	35	176	6	51
535.0	0.404670	35	184	6	61
539.9	0.467800	34	193	6	63
544.9	0.504630	32	197	6	73
550.1	0.612030	31	204	6	80
554.9	0.777890	36	211	6	88
559.9	0.936200	32	219	6	96
565.1	1.029800	32	226	10	101
	*** COMPOSITION SWITCH ***				
570.0	1.201100	31	231	7	106
574.9	1.425400	32	236	10	111
580.1	1.516800	37	239	16	115
584.9	1.908200	112	244	22	120
589.9	2.184400	129	250	24	127
594.9	2.561700	140	259	31	132
600.0	2.923300	150	262	37	137
604.9	3.025500	162	268	46	143
610.0	3.623900	166	271	46	147
614.9	4.388200	176	281	63	157
620.1	4.536400	182	288	68	162
624.9	5.080700	190	291	71	165
629.9	5.473200	194	294	74	168
635.0	5.870600	197	296	78	171
639.9	6.215100	202	300	83	175
644.9	6.672800	205	303	87	177
649.9	7.022200	210	307	90	182
654.9	7.341600	212	309	93	184
659.9	7.579300	216	312	97	187
664.9	7.859900	219	314	98	189
669.9	8.041300	222	316	100	191
674.9	8.108000	223	320	100	193
679.9	8.232000	225	319	102	193
684.9	8.346000	225	320	101	193
689.9	8.509000	226	321	103	194
694.9	8.607000	226	321	104	194
699.9	8.799000	227	322	104	195
704.9	8.886000	228	322	105	195
709.9	8.907000	228	323	105	196
714.9	8.922000	229	323	106	196
719.9	9.199000	229	323	106	196
724.9	9.344000	230	324	106	197
729.9	9.422000	231	324	108	198
734.9	9.531000	231	325	109	198
739.9	9.616000	232	325	109	198
744.9	9.763000	233	325	109	199

SUMS COMP CHANGE CAL DATA. RUN TYPE 02, N2 ==> N2/D2, TAPE 0301, FILE08.



ORIGINAL PAGE 18
OF POOR QUALITY

100 110 120



ORIGINAL PAGE IS
OF POOR QUALITY


TIME (SEC)	BARATRON PRESSURE (TORR)	AMU 32	AMU 28	AMU 16	AMU 14
			(9 BIT)		
520.0	0.322600	70	197	10	69
525.1	0.324320	71	198	11	70
530.2	0.457740	72	199	10	71
540.2	0.467760	67	200	13	78
545.0	0.543540	67	208	14	81
550.0	0.710890	66	211	10	82
554.9	0.740330	57	219	11	92
560.0	0.897770	60	225	11	98
565.0	0.988800	58	228	11	101
570.0	1.074200	55	230	12	106
575.0	1.197600	51	237	10	111
580.0	1.343400	54	241	10	115
585.1	1.550900	50	246	11	120
590.0	1.678800	47	251	10	126
595.0	1.973000	45	259	9	130
600.0	2.175200	44	263	12	134
605.1	2.427700	42	268	10	138
610.1	2.672700	44	272	12	144
614.9	2.901300	44	276	10	148
620.0	3.190100	42	279	11	152
625.0	3.455600	45	288	11	158
629.9	3.690600	43	289	11	162
634.9	3.878000	44	292	13	164
640.0	4.085400	43	299	11	165
644.1	4.382000	45	295	13	168
649.9	4.585000	45	290	12	170
654.9	4.738100	43	300	11	173
660.0	4.935900	44	303	14	175
664.1	5.079400	47	304	13	176
669.1	5.217200	45	306	12	178
675.0	5.339800	43	307	14	180
680.0	5.405800	45	308	13	180
684.1	5.476200	46	309	12	181
690.0	5.562300	50	310	13	182
695.0	5.658300	47	311	15	183
700.0	5.719200	49	312	16	183
704.0	5.798800	50	312	11	184
709.9	5.881200	51	313	12	185
714.9	5.972100	51	314	14	186
719.9	6.045800	50	314	13	186
725.0	6.146600	52	315	13	188
729.9	6.220200	52	316	13	188
734.9	6.321200	53	317	13	189
739.9	6.447700	53	320	14	190
744.9	6.496300	53	320	10	191
749.9	6.608900	54	320	13	191
754.9	6.619100	55	320	14	192
759.9	6.783800	54	321	15	193
765.0	6.854900	55	321	14	193
769.9	6.941700	55	322	15	194
774.9	7.035300	51	322	13	194
779.9	7.144300	56	323	13	194
784.9	7.237200	55	323	13	195
789.9	7.335200	55	323	15	195
794.9	7.463500	54	324	14	196
799.9	7.586100	55	324	14	196
804.9	7.693000	54	325	14	197
809.9	7.723600	54	326	13	198
814.9	7.877700	53	326	14	198
819.9	7.981400	53	327	14	198
824.9	8.087000	53	327	14	199
829.9	8.190000	53	328	14	200
834.9	8.281000	53	328	15	200
839.9	8.391000	53	329	15	200
844.9	8.504000	53	329	14	201
849.9	8.601000	53	330	16	202
854.9	8.806000	55	330	15	202
859.9	8.966000	52	331	15	203
864.9	9.056000	53	332	14	204
869.9	9.150000	54	333	16	204
874.9	9.289000	53	333	17	205
879.9	9.400000	54	333	15	205
884.9	9.589000	54	334	16	206

ORIGINAL PAGE IS
OF POOR QUALITY

889.0	9.591000	53	335	16	207
894.0	9.647000	52	335	17	207
899.0	9.780000	53	335	17	207
	*** COMPOSITION SWITCH ***				
904.0	10.028000	53	336	14	208
909.0	10.247000	53	337	17	209
914.0	10.389000	90	338	24	210
919.0	10.540000	126	338	32	210
924.0	10.674000	142	338	35	210
929.0	10.819000	155	339	43	211
934.0	10.967000	164	339	51	211
939.0	11.118000	170	339	56	211
944.0	11.279000	176	340	63	211
949.0	11.435000	182	340	66	212
954.0	11.609000	189	340	70	212
959.0	11.792000	194	341	73	213
964.0	11.997000	197	342	77	213
969.0	12.151000	201	342	81	214
974.0	12.300000	204	343	85	215
979.0	12.448000	207	343	88	215
984.0	12.613000	210	343	90	216
989.0	12.795000	213	344	93	216
994.0	12.948000	215	344	96	217
1000.0	13.066000	218	345	97	217
1004.0	13.248000	220	345	98	218
1009.0	13.382000	222	346	99	218
1014.0	13.609000	223	346	101	219
1019.0	13.828000	225	346	102	219
1024.0	14.011000	227	347	103	220
1029.0	14.213000	229	348	106	221
1034.0	14.406000	230	348	108	221
1039.0	14.618000	232	348	109	222
1044.0	14.845000	233	349	110	222
1049.0	15.072000	234	350	112	223
1054.0	15.326000	236	350	114	223
1059.0	15.581000	238	352	116	223
1064.0	15.800000	240	352	117	225
1069.0	16.050000	241	351	120	225
1074.0	16.246000	243	353	122	226
1079.0	16.466000	244	353	122	226
1084.0	16.663000	245	353	125	226
1089.0	16.856000	246	353	126	227
1094.0	17.055000	247	354	127	227

ORIGINAL PAGE IS
OF POOR QUALITY

SUMS COMP CHANGE CAL DATA. RUN TYPE 03, N2 00, N2/02, TAPE 0302, FILE 01.




ORIGINAL PAGE #1
OF POOR QUALITY

TIME (SEC)	BARATRON PRESSURE (TORR)	AMU 32	AMU 26	AMU 16	AMU 14
(9 BIT)					
515.0	0.221110	38	171	7	46
519.0	0.222330	38	175	8	49
525.1	0.358450	39	178	7	51
527.9	0.349060	39	184	10	58
530.0	0.409450	38	190	11	65
540.0	0.479510	37	196	9	70
545.0	0.537940	35	201	8	76
549.9	0.648700	38	207	8	82
550.1	0.772260	38	213	8	88
560.1	0.902730	35	220	11	96
565.0	1.035100	34	227	10	103
569.9	1.176500	36	232	9	108
574.9	1.414200	31	237	9	112
580.0	1.615900	34	243	10	120
585.1	1.855900	34	251	9	127
589.9	2.126300	35	259	10	132
594.9	2.513700	36	266	10	138
600.1	2.856000	33	269	9	144
604.9	3.282500	34	275	10	151
609.9	3.680800	34	280	10	159
615.1	4.118600	32	290	9	164
619.9	4.511000	36	293	10	167
624.9	4.947800	34	297	10	171
629.9	5.365500	37	301	12	176
634.9	5.903200	33	305	13	180
639.9	6.274900	33	310	11	185
644.9	6.647600	37	314	14	189
649.9	7.017700	35	320	12	193
654.9	7.399000	37	321	14	194
660.0	7.624300	37	323	16	196
664.9	7.847500	37	324	13	197
669.9	8.030700	37	325	16	198
674.9	8.189000	38	326	14	199
679.9	8.316000	36	327	15	200
684.9	8.324000	37	327	13	200
689.9	8.345000	37	328	15	201
694.9	8.564000	38	328	15	201
699.9	8.669000	38	329	16	202
704.9	8.720000	38	330	15	203
710.0	8.772000	41	330	17	203
714.9	8.864000	41	330	17	203
719.9	9.131000	39	330	16	204
724.9	9.320000	40	332	16	205
729.9	9.449000	40	333	17	206
734.9	9.622000	40	333	14	206
740.0	9.723000	40	334	16	207
744.9	9.843000	40	334	13	208
749.9	9.963000	39	335	15	208
*** COMPOSITION SWITCH ***					
755.0	10.127000	40	336	16	209
759.9	10.257000	40	336	15	209
764.9	10.365000	35	337	16	210
769.9	10.478000	34	337	19	210
774.9	10.633000	106	338	27	211
779.9	10.832000	121	338	31	211
784.9	10.963000	138	338	37	211
789.9	11.119000	155	339	47	212
794.9	11.244000	165	339	53	212
799.9	11.387000	171	339	60	212
804.9	11.519000	177	340	64	213
809.9	11.682000	181	340	66	213
814.9	11.917000	186	340	78	214
819.9	12.065000	193	341	74	214
824.9	12.213000	197	341	77	215
829.9	12.390000	200	342	81	215
834.9	12.552000	203	342	83	216
839.9	12.726000	208	343	89	216
844.9	12.899000	209	343	89	217
849.9	13.134000	211	344	92	218
854.9	13.331000	215	344	97	218
859.9	13.512000	219	345	98	219
864.9	13.689000	222	345	100	219
869.9	13.862000	224	346	102	220

ORIGINAL PAGE 11
OF POOR QUALITY


874.	14.036000	226	346	103	220
875.	14.219000	227	347	104	221
864.	14.387000	228	347	106	222
865.	14.532000	229	348	107	223
864.	14.762000	231	348	108	223
865.	14.949000	232	349	110	223
904.	15.171000	233	349	111	223
905.	15.364000	234	350	113	223
914.	15.606000	236	350	114	223
915.	15.804000	237	350	117	223
924.	15.968000	239	350	116	223
925.	16.165000	240	351	120	226
934.	16.413000	241	351	120	226
935.	16.641000	242	352	122	226

SUMS COMP CHANGE CAL DATA. RUN TYPE 04, N2 --> N2/02, TAPE 0302, FILE02.



ORIGINAL PAGE IS
OF POOR QUALITY

Tape #009
File # 2



TP3290648. COMP CHANGE. BIG SCAN AFTER RUN. INLET OPEN. PRNGE CLOSED.

[illegible]

ORIGINAL PAGE 19
OF POOR QUALITY

3 4/ 1962 2101 HPS

SUM
FUNCTIONAL TEST

6-11-62

PAGE 2 OF 6



75 ELECTRON VOLTS IONIZATION ENERGY

SCAN STEEL NO	HIGH MASS COLLECTOR				LOW MASS COLLECTOR			
	SCAN 1	SCAN 2	SCAN 3	SCAN 4	SCAN 1	SCAN 2	SCAN 3	SCAN 4
1					4			
2						4		
3							4	
4								27
5								
6								
7								
8								
9								
10								
11								
12								
13								
14								
15								
16								
17								
18								
19								
20								
21								
22								
23								
24								
25								
26								
27								
28								
29								
30								
31								
32								
33								
34								
35								
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

[illegible]

ORIGINAL PAGE 18
OF POOR QUALITY

3/ 4/ 1982 2101 6 PAGE 4 OF 8



111					4			
112						4		
113							4	12
114								
115								
116					4			
117						4		
118							4	16
119								
120								
121					4			
122						4		
123							4	
124								4
125								
126					4			
127						4		
128							4	12
129								
130								
131					4			
132						4		
133							4	
134								4
135								
136					4			
137						4		
138							4	
139								4
140								
141					4			
142						4		
143							4	12
144								
145					4			
146						4		
147							4	
148								4
149								
150					4			
151						4		
152							4	
153								16
154								
155					4			
156						4		
157							4	12
158								
159								
160					4			
161						4		
162							4	
163								4
164								
165								4
166					4			
167						4		
168							4	
169								16
170								

ORIGINAL PAGE IS
OF POOR QUALITY

1 2 4 1982 2101 6

PAGE 5 OF 6

171	53	6	6	6	4			
172	6	99	114	252	4			
173	326	425	481	450				
174	481	481	481	481				4
175	450	465	481	420				
176	420	464	359	298	4			
177	190	23	6	36		4		
178	6	20	6	6			4	
179	6	6	6	6				12
180	6	6	6	23				
181	6	6	6	6	4			
182	69	64	114	130		4		
183	160	175	114	145			4	
184	191	130	130	130				12
185	130	130	145	66				
186	36	6	6	6	4			
187	6	6	6	23		4		
188	6	6	6	6			4	
189	23	6	6	6				4
190	6	6	6	6				
191	36	6	6	6	4			
192	6	6	6	64		4		
193	145	64	64	64			4	
194	64	64	64	64				12
195	64	64	64	64				
196	64	64	64	64	4		4	
197	6	6	6	6				4
198	6	6	6	6				12
199	6	6	6	6				
200	23	6	6	6				
201	6	6	6	6	4		4	
202	23	6	6	6				4
203	6	6	6	6				
204	23	6	6	6				4
205	6	6	6	6				
206	64	6	6	6	4			
207	6	6	6	6		4		
208	6	6	6	5			19	
209	6	6	6	6				570
210	6	6	6	6				
211	6	6	6	23	1235		1570	
212	6	6	6	6				1695
213	23	6	6	23				1755
214	114	145	175	175				
215	145	160	160	145				
216	145	145	191	160	1725		1755	
217	130	160	160	99			1755	
218	6	6	6	6				1765
219	6	23	6	6				
220	6	6	6	6	1785		1785	
221	6	6	6	6				
222	6	6	6	23		1785		
223	6	6	6	6			1785	
224	6	6	6	6				1815
225	6	6	6	6				
226	23	6	6	23	1785		1815	
227	6	6	6	6				1815
228	6	6	6	6				1845
229	6	6	6	6				
230	6	6	6	6				

PAGE 6 OF 8

[illegible]

ORIGINAL PAGE IS
OF POOR QUALITY

3/ 4/ 1962 2181 6

PAGE 7 OF 8




[illegible]

ORIGINAL PAGE IS
OF POOR QUALITY

1 3/ 4 1982 2101 6

PAGE 8 OF 8

001	6	20	6	20	4	4	4	19
002	6	00	00	00				
003	6	00	00	00				
004	6	00	00	00				
005	6	00	00	00				
006	20	00	00	00	4	4	4	
007	6	00	00	00				
008	20	00	00	00				4
009	20	00	00	00				
010	20	00	00	00				



ORIGINAL PAGE 19
OF POOR QUALITY

3/ 4/ 1982

2106 HRS

SUMS
FUNCTIONAL TEST

SN 6

PAGE 2 OF 8

75 ELECTRON VOLTS IONIZATION ENERGY

SCAN STEP NO	-----HIGH MASS COLLECTOR-----				-----LOW MASS COLLECTOR-----			
	SCAN 1	SCAN 2	SCAN 3	SCAN 4	SCAN 1	SCAN 2	SCAN 3	SCAN 4
1					19			
2						12		
3							4	
4								27
5					12			
6						12		
7							4	
8								4
9					12			
10						4		
11							4	
12								4
13								
14								
15								
16					27			
17						4		
18							4	
19								4
20								
21					4	4		
22							4	
23								4
24							4	
25					19			
26						4		
27							4	
28					4			
29						4		
30							4	
31								12
32					4			
33						4		
34							4	
35								4
36					12			
37						4		
38							4	
39								12
40								
41								
42								
43								
44								
45								
46					4			
47						4		
48							4	
49								4
50								

3 4 1982 2106 0 PAGE 3 OF 8

PAGE 2 OF 8

[illegible]

A vertical strip of four black and white photographs showing different views of a mechanical component. The top two images show the component from a perspective where two circular features are visible. The bottom two images show the component from a perspective where two circular features are visible, with the bottom image showing a different arrangement or detail.

PAGE 4 OF 6

Sl. No.	Particulars	1990-91	1991-92	1992-93	1993-94	1994-95	1995-96	1996-97	1997-98	1998-99	1999-00	2000-01	2001-02	2002-03	2003-04	2004-05	2005-06	2006-07	2007-08	2008-09	2009-10	2010-11	2011-12	2012-13	2013-14	2014-15	2015-16	2016-17	2017-18	2018-19	2019-20	2020-21	2021-22	2022-23	2023-24	2024-25	2025-26	2026-27	2027-28	2028-29	2029-30	2030-31	2031-32	2032-33	2033-34	2034-35	2035-36	2036-37	2037-38	2038-39	2039-40	2040-41	2041-42	2042-43	2043-44	2044-45	2045-46	2046-47	2047-48	2048-49	2049-50	2050-51	2051-52	2052-53	2053-54	2054-55	2055-56	2056-57	2057-58	2058-59	2059-60	2060-61	2061-62	2062-63	2063-64	2064-65	2065-66	2066-67	2067-68	2068-69	2069-70	2070-71	2071-72	2072-73	2073-74	2074-75	2075-76	2076-77	2077-78	2078-79	2079-80	2080-81	2081-82	2082-83	2083-84	2084-85	2085-86	2086-87	2087-88	2088-89	2089-90	2090-91	2091-92	2092-93	2093-94	2094-95	2095-96	2096-97	2097-98	2098-99	2099-00	2100-01	2101-02	2102-03	2103-04	2104-05	2105-06	2106-07	2107-08	2108-09	2109-10	2110-11	2111-12	2112-13	2113-14	2114-15	2115-16	2116-17	2117-18	2118-19	2119-20	2120-21	2121-22	2122-23	2123-24	2124-25	2125-26	2126-27	2127-28	2128-29	2129-30	2130-31	2131-32	2132-33	2133-34	2134-35	2135-36	2136-37	2137-38	2138-39	2139-40	2140-41	2141-42	2142-43	2143-44	2144-45	2145-46	2146-47	2147-48	2148-49	2149-50	2150-51	2151-52	2152-53	2153-54	2154-55	2155-56	2156-57	2157-58	2158-59	2159-60	2160-61	2161-62	2162-63	2163-64	2164-65	2165-66	2166-67	2167-68	2168-69	2169-70	2170-71	2171-72	2172-73	2173-74	2174-75	2175-76	2176-77	2177-78	2178-79	2179-80	2180-81	2181-82	2182-83	2183-84	2184-85	2185-86	2186-87	2187-88	2188-89	2189-90	2190-91	2191-92	2192-93	2193-94	2194-95	2195-96	2196-97	2197-98	2198-99	2199-00	2200-01	2201-02	2202-03	2203-04	2204-05	2205-06	2206-07	2207-08	2208-09	2209-10	2210-11	2211-12	2212-13	2213-14	2214-15	2215-16	2216-17	2217-18	2218-19	2219-20	2220-21	2221-22	2222-23	2223-24	2224-25	2225-26	2226-27	2227-28	2228-29	2229-30	2230-31	2231-32	2232-33	2233-34	2234-35	2235-36	2236-37	2237-38	2238-39	2239-40	2240-41	2241-42	2242-43	2243-44	2244-45	2245-46	2246-47	2247-48	2248-49	2249-50	2250-51	2251-52	2252-53	2253-54	2254-55	2255-56	2256-57	2257-58	2258-59	2259-60	2260-61	2261-62	2262-63	2263-64	2264-65	2265-66	2266-67	2267-68	2268-69	2269-70	2270-71	2271-72	2272-73	2273-74	2274-75	2275-76	2276-77	2277-78	2278-79	2279-80	2280-81	2281-82	2282-83	2283-84	2284-85	2285-86	2286-87	2287-88	2288-89	2289-90	2290-91	2291-92	2292-93	2293-94	2294-95	2295-96	2296-97	2297-98	2298-99	2299-00	2300-01	2301-02	2302-03</
---------	-------------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	-----------

1771			19			
1772				4		
1773					4	19
1774			12	27		
1775					4	
1776						4
1777			4	4		
1778					4	
1779						4
1780			19	4		
1781					4	
1782			19	4		
1783						4
1784			12	4		
1785					4	
1786			12	4		
1787						12
1788			12	4		
1789					4	
1790						4
1791			12	4		
1792					4	
1793			4	4		
1794					4	
1795						241
1796			605	740		
1797					785	
1798						830
1799			830	815		
1800					815	
1801						830
1802			845	815		
1803					850	
1804			860	830		
1805					850	
1806						845

[illegible]

SPECIAL TESTS FOLLOWING COMPLETION OF DYNAMIC CALIBRATION

SUMS S/N 1
UAMS S/N 6
T/C G. Robertson
Date 2-25-82

- All tests were run with filament #1.
- Background spectra taken with all SUMS valves open, calibration station orifice open, and station chamber pressure at 6×10^{-9} Torr. SUMS has been pumping on itself with the inlet valve closed and the range valve open for ~ 24 hours prior to this time. Before this the inlet pressure was as high as 33 Torr. Background data stored on tape #008, file #3.

- Temperatures:

UAMS ion source = 90_{10} (i.e. fully warmed up)

T11 73.7°F

T12 73.0°F

T15 78.9°F

- Special Test #1

Nominal Pressure Profile followed up to time = 150 seconds, then pressure was held constant and data was taken for another 50 seconds. Data stored on HP9830 tape #202, bulk file #2.

- Special Test #2

Same as above except pressure was held at $t = 650$ seconds. Data stored on HP9830 tape #202, bulk file #3.

- Special Test #3

Exponential pressure profile was followed starting at $P = .1$ Torr. Curve followed was:

$$P = P_0 e^{at}$$

$$P_0 = .1 \text{ Torr}$$

$$a = 0.0132$$

Range valve closed for entire test. Inlet valve allowed to close automatically. Data stored on HP9830 tape #202, bulk file #4. After pumping down system at the end of the run, AMU28 peak was less than 2.7×10^{-12} Amps.

- Special Test # 1 (Again)

First run was done with filament #2 by mistake. Test was rerun using filament #1. Same profile. Data on tape #202, bulk file #2.

	<u>ext. press.</u>	<u>before</u>	<u>after</u>
AMU 28 peak @	3×10^{-8} Torr	3.51×10^{-12} A	3.73×10^{-12} A

**ORIGINAL PAGE IS
OF POOR QUALITY**

- Special Test #2 (Again)


First run done with filament #2 by mistake. Test rerun using filament #1. Nominal profile from $t = 500$ to $t = 630$, hold at 630. Data on tape #202, bulk file #3.

	<u>ext. press.</u>	<u>before</u>	<u>after</u>
AMU 28 peak @ 2×10^{-8} T		2.59×10^{-12} A	2.47×10^{-12} A
AMU 14 peak @ 2×10^{-8} T		1.75×10^{-13} A	1.91×10^{-13} A
		T11 75.2 °F	
		T12 74.6 °F	
		T15 75.9 °F	

- After running the three special tests a second background spectra was taken. This spectra was taken with all SUMS valves open, the calibration station throttling valve fully open, the orifice open and the chamber pressure at 3×10^{-8} Torr. The background data is stored on HP9830 tape #008, bulk file #4.

tape #008
file # 3

100-117 (1)



PAGE 1 OF 1

DATA TAPE 110 8 BULL. DATA FILE # 3

SUMS FUNCTIONAL TEST

BACKGROUND SPECTRA: 6E-STORE; ALL VALVES OPEN *Before Special Tests*

HOUSEKEEPING DATA	FILAMENT NUMBER	1
SCAN NUMBER	1	2
INTERLACE STEP	75	75
IONIZATION ENERGY	1	1
FILAMENT NUMBER	1	1
CAP ON=1, OFF=2	193	193
PLUS 15 VOLT	129	130
MINUS 15 VOLT	181	181
ION PUMP VOLT	90	90
ION SOURCE TEMP	167	168
PRE-AMP TEMP	120	121
PLUS 5 VOLT	163	163
A/D REFERENCE VOLT	125	126
EMISSION CURRENT	111	111
COLLECTOR CURRENT	190	190
ELECTRON ACC VOLT	39	39
ION ACC VOLT		
ION PUMP ANALOG		
26 VOLT POWER SUP		

ORIGINAL PAGE 13
OF POOR QUALITY

2 25 1962 1653 HRS

SUN
FUNCTIONAL TEST

PAGE 2 OF 6

75 ELECTRON VOLTS IONIZATION ENERGY

SCAN STEP NO	-----HIGH MASS COLLECTOR-----				-----LOW MASS COLLECTOR-----			
	SCAN 1	SCAN 2	SCAN 3	SCAN 4	SCAN 1	SCAN 2	SCAN 3	SCAN 4
1					4			
2						12		
3							4	
4								4
5								
6					4			
7						4		
8							4	
9								4
10					4			
11						4		
12							4	
13								4
14					4			
15						4		
16							4	
17								4
18					4			
19						4		
20							4	
21					4			
22						4		
23							4	
24								4
25					4			
26						12		
27							4	
28								12
29					4			
30						12		
31							4	
32								4
33								
34								
35					4			
36						4		
37							4	
38								4
39					4			
40						4		
41							4	
42								12
43								
44								
45								
46					4			
47						27		
48							4	
49								1
50								

ORIGINAL PAGE IS
OF POOR QUALITY

2 25 1982 1653 6

PAGE 3 OF 10



51	0	20	0	0	4		
52	0	0	0	0		12	
53	0	0	0	0			4
54	0	0	0	0			19
55	0	0	0	0			
56	0	0	0	0	4		
57	0	0	0	0		19	
58	0	0	0	0			4
59	0	0	0	0			27
60	0	0	0	0			
61	0	0	0	0	4		
62	0	0	0	0		4	
63	0	0	0	0			12
64	0	0	0	0			19
65	0	0	0	0			
66	0	0	0	0	4		
67	0	0	0	0		12	
68	0	0	0	0			4
69	0	0	0	0			4
70	0	0	0	0			
71	0	0	0	0	4		
72	0	0	0	0		12	
73	0	0	0	0			4
74	0	0	0	0			4
75	0	0	0	0			
76	0	0	0	0	4		
77	0	0	0	0		4	
78	0	0	0	0			4
79	160	221	221	114			4
80	221	221	191	130			
81	191	175	175	221	4		
82	206	130	0	53		27	
83	23	23	0	0			4
84	0	0	0	0			4
85	0	0	0	0			
86	0	0	0	0	4		
87	0	0	0	0		12	
88	0	0	0	0			4
89	0	0	0	0			4
90	0	0	0	0			
91	0	0	0	0	4		
92	23	0	0	0		12	
93	0	0	0	0			4
94	0	0	0	0			4
95	23	0	0	0			
96	0	0	0	0	4		
97	0	0	0	0		19	
98	0	0	0	0			4
99	0	0	0	0			12
100	130	465	618	664			
101	847	928	928	969	4		
102	954	969	1020	992		12	
103	992	992	992	923			12
104	771	374	282	252			12
105	130	23	0	0			
106	0	0	0	0	4		
107	0	0	23	0		4	
108	0	0	0	0			12
109	0	23	0	0			12
110	0	0	0	0			

1. *Chlorophyll a* (Chl *a*) and *Chlorophyll b* (Chl *b*) were determined by the method of Lichtenthal and Whistler (1973). Total chlorophyll (Chl *a* + Chl *b*) was determined by the method of Lichtenthal and Whistler (1973). Total chlorophyll (Chl *a* + Chl *b*) was determined by the method of Lichtenthal and Whistler (1973).

[illegible]

ORIGINAL PAGE IS
OF POOR QUALITY

1 2 25 1962 1652 6 PAGE 5 OF 6



171	0	0	0	0	4			
172	0	0	175	0		4		
173	004	090	000	000			4	
174	000	004	000	000				19
175	000	000	000	000				
176	004	000	000	000	4			
177	191	000	000	000		4		
178	0	0	0	0			4	
179	0	0	0	0				4
180	0	0	0	0				
181	0	0	0	0	4			
182	0	0	0	0		4		
183	000	000	000	000			4	
184	000	000	000	000				4
185	000	000	000	000				
186	000	004	000	000	4			
187	000	000	000	000		19		
188	0	0	0	0			4	
189	0	0	0	0				4
190	0	0	0	0				
191	0	0	0	0	4			
192	0	0	0	0		19		
193	000	145	000	145			4	
194	004	000	000	114				12
195	000	000	000	000				
196	000	000	000	000	4			
197	0	0	0	0		4		
198	0	0	0	0			4	
199	0	0	0	0				12
200	0	0	0	0				
201	0	0	0	0	4			
202	0	0	0	0		4		
203	0	0	0	0			4	
204	0	0	0	0				4
205	000	000	000	000				
206	000	000	000	000	4			
207	0	0	0	0		4		
208	0	0	0	0			103	
209	0	0	0	0				1785
210	0	0	0	0	3815			
211	0	0	0	0		4945		
212	0	0	0	0			5200	
213	0	0	0	0				5300
214	0	0	0	0				
215	000	000	000	000				
216	000	000	000	000	5300			
217	000	000	000	000		5450		
218	000	000	000	000			5450	
219	0	0	0	0				5450
220	0	0	0	0	5450			
221	0	0	0	0		5550		
222	0	0	0	0			5550	
223	0	0	0	0				5450
224	0	0	0	0				
225	0	0	0	0				
226	0	0	0	0	5550			
227	0	0	0	0		5550		
228	0	0	0	0			5550	
229	0	0	0	0				5550
230	0	0	0	0				

ORIGINAL PAGE IS
OF POOR QUALITY


2 25 1901 1653 6

PAGE 6 OF 68

	5550	4210	1995	725
	210	80	19	4
	4	12	4	4
	4	19	4	4
	4	12	4	4
	4	16	4	19
	4	4	4	12
	4	12	4	4
	4	27	4	4
	4	12	4	4
	4	27	4	4
	4	4	4	4

ORIGINAL PAGE IS
OF POOR QUALITY

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50



3000	4	12	4	4
3001	4	4	4	4
3002	4	27	4	4
3003	4	12	4	4
3004	4	27	4	4
3005	4	12	4	4
3006	4	12	4	4
3007	4	12	4	4
3008	4	12	4	4
3009	4	12	4	4
3010	4	12	4	4
3011	4	12	4	4
3012	4	12	4	4
3013	4	12	4	4
3014	4	12	4	4
3015	4	12	4	4
3016	4	12	4	4
3017	4	12	4	4
3018	4	12	4	4
3019	4	12	4	4
3020	4	12	4	4
3021	4	12	4	4
3022	4	12	4	4
3023	4	12	4	4
3024	4	12	4	4
3025	4	12	4	4
3026	4	12	4	4
3027	4	12	4	4
3028	4	12	4	4
3029	4	12	4	4
3030	4	12	4	4
3031	4	12	4	4
3032	4	12	4	4
3033	4	12	4	4
3034	4	12	4	4
3035	4	12	4	4
3036	4	12	4	4
3037	4	12	4	4
3038	4	12	4	4
3039	4	12	4	4
3040	4	12	4	4
3041	4	12	4	4
3042	4	12	4	4
3043	4	12	4	4
3044	4	12	4	4
3045	4	12	4	4
3046	4	12	4	4
3047	4	12	4	4
3048	4	12	4	4
3049	4	12	4	4
3050	4	12	4	4

ORIGINAL PAGE IS
OF POOR QUALITY

29 1902 1893 6

PAGE 6 OF 9

1-800-976-0000

புதுப்பிப்புப் பணிகள்

မိမိတို့အားလုံးအတွက်

பெரிய நகரம்

የገንዘብ ፋይል

44

44

44

44

SOME FUNCTIONAL TEST

HOUSEKEEPING DATA	FILAMENT NUMBER	2
SCAN NUMBER	1	2
INTERLACE STEP	1	2
IONIZATION ENERGY	75	75
FILAMENT NUMBER	2	2
CAP ON=1, OFF=2	1	1
PLUS 15 VOLT	193	193
MINUS 15 VOLT	129	129
ION PUMP VOLT	180	180
ION SOURCE TEMP	90	90
PRE-AMP TEMP	168	168
PLUS 5 VOLT	120	120
A/D REFERENCE VOLT	163	163
EMISSION CURRENT	125	125
COLLECTOR CURRENT	106	106
ELECTRON ACC VOLT	190	190
ION ACC VOLT	39	39
ION PUMP ANALOG		0.0020
28-VOLT POWER SUP		28.370

ORIGINAL PAGE IS
OF POOR QUALITY

21 05 1960

1000 HRS

0000

FOOT (1) 000 1100

Page 2 of 6



75 ELECTRON VOLTS IONIZATION ENERGY

SCAN STEP NO	HIGH MASS COLLECTOR				LOW MASS COLLECTOR			
	SCAN 1	SCAN 2	SCAN 3	SCAN 4	SCAN 1	SCAN 2	SCAN 3	SCAN 4
1					12	4	4	
2								4
3					12	4	4	
4								4
5								
6								
7								
8								
9								
10					4	4	4	
11								
12								
13								
14								
15								
16					4	4	4	
17								
18								
19								
20					19	4	4	
21								4
22								
23								
24								
25								
26					19	4	4	
27								
28								
29								
30								
31					4	4	4	
32								
33								
34								
35					4	4	4	
36								
37								
38								
39								
40								
41					4	4	4	
42								
43								
44								
45								
46					4	4	4	
47								
48								
49								
50								

ORIGINAL PAGE 13
OF POOR QUALITY

25 1987 1757 6

PAGE 3 OF 6



100 101 102 103 104 105 106 107 108 109 110

111 112 113 114 115 116 117 118 119 120 121

122 123 124 125 126 127 128 129 130 131 132

133 134 135 136 137 138 139 140 141 142 143

144 145 146 147 148 149 150 151 152 153 154

155 156 157 158 159 160 161 162 163 164 165

166 167 168 169 170 171 172 173 174 175 176

177 178 179 180 181 182 183 184 185 186 187

188 189 190 191 192 193 194 195 196 197 198

111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170

THE UNIVERSITY OF CHICAGO

[illegible]

.....

$\frac{P_0}{P_1} = \frac{P_2}{P_3} = \dots = \frac{P_{n-1}}{P_n}$

4
4
4
4
4
4
4
4
4
4
4

4
4
4
4
4
4
4
4
4
4
4
4

4
4
4
4
12
4
4
4
4
4
12
18

이
이
이
이
이
이
이
이
이
이
이
이

ORIGINAL PAGE IS
OF POOR QUALITY



2 25 1982 1657 6 PAGE 5 OF 8

171	8	8	8	4			
172	8	114	206		4		
173	801	1050	1170			18	
174	1140	1210	1240				4
175	1140	1140	1170				
176	1140	1080	954	4			
177	100	100	100		4		
178	8	8	8			4	
179	8	8	8				4
180	8	8	8				
181	8	8	8	4			
182	8	8	8		4		
183	8	8	8			27	
184	8	8	8				4
185	8	8	8				
186	145	8	8	4			
187	8	8	8		4		
188	8	8	8			4	
189	8	8	8				4
190	8	8	8				
191	8	8	8	4			
192	8	8	8		4		
193	8	8	8			4	
194	8	8	8				4
195	8	8	8				
196	8	8	8	4			
197	8	8	8		4		
198	8	8	8			4	
199	8	8	8				4
200	8	8	8				
201	8	8	8	4			
202	8	8	8		4		
203	8	8	8			12	
204	8	8	8				4
205	8	8	8				
206	8	8	8	4			
207	8	8	8		4		
208	8	8	8			35	
209	8	8	8				605
210	8	8	8				
211	8	8	8	1800			
212	8	8	8		1685		
213	8	8	8			1815	
214	8	8	8				1845
215	8	8	8				
216	10	8	8	1815			
217	8	8	8		1815		
218	8	8	8			1845	
219	8	8	8				1875
220	8	8	8	1845			
221	8	8	8		1845		
222	8	8	8			1875	
223	8	8	8				1845
224	8	8	8				
225	8	8	8	1845			
226	8	8	8		1845		
227	8	8	8			1845	
228	8	8	8				1845
229	8	8	8				
230	8	8	8				

ORIGINAL PAGE IS
OF POOR QUALITY

25 1987 1650 6

PAGE 6 OF 8



2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217
2218
2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2300

2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217
2218
2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2300

2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217
2218
2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2300

2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217
2218
2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2300

2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217
2218
2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2300

1815

50

4

4

4

4

4

4

4

4

4

4

4

1420

4

4

4

4

4

4

4

4

4

4

4

4

095

12

19

12

12

12

4

4

4

4

4

4

4

248

4

4

4

4

4

4

4

4

4

4

4


4

4

ORIGINAL PAGE IS
OF POOR QUALITY

25 1982 1657 6

PAGE 7 OF 8



291					4			
292						4		
293							4	
294								4
295					4			
296						4		
297							4	
298								4
299								
300					4			
301						4		
302							4	
303								4
304								
305					4			
306						4		
307							4	
308								4
309								
310					4			
311						4		
312							4	
313								4
314								
315					4			
316						4		
317							4	
318								4
319					4			
320						35		
321							126	
322								157
323								
324								
325					141			
326						134		
327							157	
328								172
329					157			
330						149		
331							172	
332								180
333								
334					157			
335						149		
336							187	
337								180
338								
339					164			
340						134		
341							180	
342								134
343								
344					50			
345								
346						4		
347								
348							4	
349								4
350								

2/ 25/ 1982 1657 6 PAGE 8 OF 8

PAGE 8 OF 8

[illegible]



ORIGINAL PAGE IS
OF POOR QUALITY

1-EMP, 0102-T1 FREQUENCY PROFILE, 2-2-82, TIME #20, FILE #4.

TIME	EMPHASIS FREQUENCY	AMP 20	AMP 14
0.0	0.099160	127	21
5.2	0.099040	127	24
10.5	0.105960	130	25
20.0	0.114260	133	27
25.2	0.125780	135	27
30.0	0.135460	138	31
35.0	0.145270	139	32
40.0	0.156010	138	32
45.1	0.166410	140	36
50.2	0.179770	142	36
55.1	0.192520	144	38
60.2	0.206490	147	40
65.2	0.221440	149	39
70.0	0.237070	153	44
75.1	0.251540	156	47
80.0	0.272230	159	50
85.0	0.289850	162	51
90.1	0.310080	164	55
95.0	0.328860	166	59
100.0	0.358770	168	62
104.9	0.378190	171	69
109.9	0.399110	173	67
115.2	0.441370	177	70
120.0	0.460870	179	70
124.9	0.480850	182	75
129.9	0.521020	186	76
135.1	0.559040	189	80
140.1	0.601800	192	81
145.1	0.640430	194	86
150.1	0.688060	196	88
155.1	0.725810	196	93
160.0	0.767620	200	96
164.9	0.833250	203	97
170.1	0.901900	205	100
175.0	0.929300	206	102
179.9	1.041000	210	103
185.0	1.098500	212	105
189.9	1.125600	216	106
194.9	1.153000	216	110
199.8	1.195200	220	112
205.1	1.279300	222	112
210.1	1.367000	223	115
215.0	1.545800	227	116
219.8	1.715700	232	122
225.1	1.829700	232	127
229.9	1.927200	235	130
235.0	2.058900	236	132
240.0	2.233100	240	134
245.0	2.398700	244	137
250.0	2.502800	247	139
255.0	2.665500	251	142
260.0	2.885900	253	144
265.0	3.098700	256	147
270.0	3.254900	261	151
275.0	3.484000	263	154
280.0	3.758900	265	157
284.9	3.997600	267	162
289.8	4.291600	271	164
294.8	4.554700	273	166
299.8	4.940800	277	168
305.0	5.246200	281	171
309.9	5.578100	284	174
314.8	5.970400	286	177
319.8	6.434200	290	180
324.8	6.807300	291	184
330.0	7.348700	295	187
334.9	7.780500	297	191
339.9	8.427000	300	194
345.1	8.980000	304	197

ORIGINAL PAGE IS
OF POOR QUALITY

354.0	9.477000	310	201
359.0	9.740000	311	202
364.0	10.350000	312	203
369.0	11.445000	313	204
374.0	12.873000	314	205
379.0	13.951000	315	206
384.0	15.009000	316	207
389.0	16.036000	317	208
394.0	17.090000	318	209
399.0	18.391000	319	210
404.0	19.281000	320	211
409.0	21.100000	321	212
414.0	22.067000	322	213
419.0	24.036000	323	214
424.0	26.207000	324	215
429.0	26.901000	325	216
434.0	28.808000	326	217
439.0	30.944000	327	218
444.0	33.043000	328	219
449.0	35.319000	329	220
454.0	37.627000	330	221
459.0	40.314000	331	222
464.0	42.980000	332	223
469.0	45.992000	333	224
474.0	49.049000	334	225
479.0	52.421000	335	226
484.0	55.899000	336	227
489.0	56.032000	337	228



ORIGINAL PAGE IS
OF POOR QUALITY

FOOTNOTES

Sumit Electric Co. Ltd. 2.5V E.S.
Serial 4758-43
approx. 100 ohms resistance
2.0 4000 2000 1000 500
5/20/72

S.V. 45

1000 V A.S.

1000
1000
1000

1000
1000
1000

1000

1000

1000
1000
1000

1000
1000
1000

ORIGINAL PAGE 13
OF POOR QUALITY

NON PRESS PROFILE TO 150 SEC THEN HOLD. 2-26-62. TAPE #202. FILE #2.

TIME	BARATRON PRESSURE	AMU 28	AMU 14
0.0	0.000146	225	109
5.0	0.000153	226	109
10.0	0.000157	226	110
20.0	0.000163	227	112
25.0	0.000173	228	113
30.0	0.000177	229	113
35.0	0.000180	229	114
40.0	0.000188	230	115
45.0	0.000194	231	116
50.0	0.000199	232	118
55.0	0.000208	232	119
59.0	0.000211	234	120
64.7	0.000218	235	122
70.0	0.000222	236	123
74.0	0.000228	237	125
79.0	0.000242	238	126
84.7	0.000250	240	128
89.0	0.000248	241	129
94.0	0.000265	242	130
99.0	0.000263	244	131
104.0	0.000274	245	132
109.0	0.000280	247	133
114.7	0.000293	248	134
119.7	0.000302	250	135
124.7	0.000307	251	136
129.0	0.000321	252	137
134.0	0.000324	253	138
139.0	0.000337	257	139
144.0	0.000345	258	140
149.0	0.000361	259	142
154.0	0.000373	260	143
159.0	0.000369	262	144
164.0	0.000369	262	145
169.0	0.000369	263	146
174.0	0.000367	263	146
179.0	0.000368	264	147
184.0	0.000369	264	146
189.0	0.000368	264	147
194.0	0.000371	264	147
199.0	0.000370	264	147
204.0	0.000368	263	147
209.0	0.000371	264	147
214.0	0.000372	265	147
219.0	0.000368	264	147
224.0	0.000368	264	147
229.0	0.000370	265	147
234.0	0.000369	265	147
239.7	0.000368	264	147

Subj. by name. Classification
Special Test #1
Note: 70 per hour! Profile to 158 seconds. Then hold.
690 #1202. Bulk file # 2
2/26/72

500m V F.S.

450


451-2

0022200

003500




ORIGINAL PAGE IS
OF POOR QUALITY

NON FFL - PROFILE TO 830 SEC THEN HOLD. 2-26-82. TIME #20. FILE #1.



TIME	BRIGHTNESS PERCENT	ADD 20	ADD 14
500.0	0.183800	169	54
505.0	0.198100	169	54
510.0	0.204000	170	57
520.0	0.296200	172	61
530.0	0.322600	175	61
540.0	0.371600	179	68
550.0	0.438400	184	71
560.0	0.513700	189	75
570.0	0.589300	194	80
580.0	0.669300	199	85
590.0	0.770000	203	93
600.0	0.852200	208	98
610.0	0.982900	214	102
620.0	1.089700	220	106
630.0	1.207100	226	110
640.0	1.323000	229	116
650.0	1.409100	232	121
660.0	1.665900	237	126
670.0	1.900600	241	130
680.0	2.176300	246	134
690.0	2.408900	254	139
700.0	2.608600	260	144
710.0	2.879500	265	149
720.0	3.171500	268	153
730.0	3.362300	272	159
740.0	3.609200	276	162
750.0	3.897000	279	164
760.0	3.988200	283	167
770.0	3.981900	286	168
780.0	3.941300	286	169
790.0	3.912700	288	168
800.0	3.890000	288	168
810.0	3.883900	288	168
820.0	3.884200	288	168
830.0	3.883500	288	168
840.0	3.884000	288	168
850.0	3.882700	288	168
860.0	3.884300	288	168
870.0	3.884100	288	168
880.0	3.883700	288	168
890.0	3.882400	288	168
900.0	3.884400	288	168
910.0	3.884300	288	168
920.0	3.883800	288	168
930.0	3.884000	288	168
940.0	3.885000	288	168
950.0	3.884100	288	168
960.0	3.883100	288	168
970.0	0.269200	284	164
980.0	0.121500	267	142
990.0	0.102100	240	119
1000.0	0.095300	224	104


FOUR



OF POOR QUALITY

5

ALL INFORMATION CONTAINED HEREIN IS UNCLASSIFIED DATE 07-18-2019 BY 60322 UCBAW



ORIGINAL PAGE IS
OF POOR QUALITY

2 26 1982 1640 HPS

SUN
FUNCTIONAL TEST

S H 6

PAGE 1 OF 6

DATA TAPE ID 0 BULL DATA FILE # 4

SUN FUNCTIONAL TEST

BACKGROUND SPECTRA, BE-H TOPP, ALL VALVES OPEN, AFTER SPECIAL TEST RUNS.

HOUSEKEEPING DATA FILAMENT NUMBER 1

SCAN NUMBER	1	2	3	4	5	6	7	8	ANAL MON
INTERLACE STEP	1	2	3	4	1	2	3	4	
IONIZATION ENERGY	75	75	75	75	75	75	75	75	
FILAMENT NUMBER	1	1	1	1	1	1	1	1	
CAR ON=1, OFF=2	1	1	1	1	1	1	1	1	
PLUS 15 VOLT	193	193	193	193	193	193	193	193	0.200
MINUS 15 VOLT	129	130	130	130	130	130	130	130	-14.970
ION PUMP VOLT	181	180	181	181	181	181	181	181	0.020
ION SOURCE TEMP	91	91	91	90	90	91	90	91	2.500
PRE-AMP TEMP	169	169	169	169	169	169	169	169	0.130
PLUS 5 VOLT	120	120	120	121	121	121	121	121	0.225
A-D REFERENCE VOLT	163	163	163	163	163	163	163	163	
EMISSION CURRENT	125	126	126	125	125	125	125	125	0.000
COLLECTOR CURRENT	112	112	112	112	112	112	112	112	0.000
ELECTRON ACC VOLT	190	189	189	190	189	190	190	189	0.000
ION ACC VOLT	39	39	39	39	39	39	39	39	7.300
ION PUMP ANALOG									2.0mV 0.0120
28 VOLT POWER SUP									0.200

ORIGINAL PAGE 13
OF POOR QUALITY

2 26 1965 1740 HPS

SCN 110 HPL 1E-1

PAGE 2 OF 6

75 ELECTRON VOLTS IONIZATION ENERGY

SCAN STEP	HIGH MASS COLLECTOR				LOW MASS COLLECTOR			
	SCAN 1	SCAN 2	SCAN 3	SCAN 4	SCAN 1	SCAN 2	SCAN 3	SCAN 4
1	20	20	20	20	4			
2	20	20	20	20		4		
3	20	20	20	20			4	
4	20	20	20	20				4
5	20	20	20	20	4			
6	20	20	20	20		12		
7	20	20	20	20			4	
8	20	20	20	20				12
9	20	20	20	20	4			
10	20	20	20	20		4		
11	20	20	20	20			4	
12	20	20	20	20				4
13	20	20	20	20	4			
14	20	20	20	20		4		
15	20	20	20	20			4	
16	20	20	20	20				12
17	20	20	20	20	4			
18	20	20	20	20		4		
19	20	20	20	20			4	
20	20	20	20	20				4
21	20	20	20	20	4			
22	20	20	20	20		4		
23	20	20	20	20			4	
24	20	20	20	20				4
25	20	20	20	20	4			
26	20	20	20	20		4		
27	20	20	20	20			4	
28	20	20	20	20				4
29	20	20	20	20	4			
30	20	20	20	20		4		
31	20	20	20	20			4	
32	20	20	20	20				4
33	20	20	20	20	4			
34	20	20	20	20		4		
35	20	20	20	20			4	
36	20	20	20	20				4
37	20	20	20	20	4			
38	20	20	20	20		4		
39	20	20	20	20			4	
40	20	20	20	20				4
41	20	20	20	20	4			
42	20	20	20	20		4		
43	20	20	20	20			4	
44	20	20	20	20				4
45	20	20	20	20	4			
46	20	20	20	20		4		
47	20	20	20	20			4	
48	20	20	20	20				4
49	20	20	20	20	4			
50	20	20	20	20				4

1144

1146 E.

01


[illegible]

ORIGINAL PAGE 13
OF POOR QUALITY

2 26 1982 1040 6

PAGE 4 OF 5

1




111	00	00	00	00	4	12	4	12
112	00	00	00	00				
113	00	00	00	00				
114	00	00	00	00				
115	00	00	00	00				
116	00	00	00	00	4	4	4	4
117	00	00	00	00				
118	00	00	00	00				
119	00	00	00	00				
120	00	00	00	00	4	12	4	4
121	00	00	00	00				
122	00	00	00	00				
123	00	00	00	00				
124	00	00	00	00				
125	00	00	00	00	4	4	4	4
126	00	00	00	00				
127	00	00	00	00				
128	00	00	00	00				
129	00	00	00	00				
130	00	00	00	00	4	4	4	4
131	00	00	00	00				
132	00	00	00	00				
133	00	00	00	00				
134	00	00	00	00				
135	00	00	00	00	4	4	4	4
136	00	00	00	00				
137	00	00	00	00				
138	00	00	00	00				
139	00	00	00	00				
140	00	00	00	00	4	4	4	4
141	00	00	00	00				
142	00	00	00	00				
143	00	00	00	00				
144	00	00	00	00	4	4	4	4
145	00	00	00	00				
146	00	00	00	00				
147	00	00	00	00	4	4	4	4
148	00	00	00	00				
149	00	00	00	00				
150	00	00	00	00	4	4	4	4
151	00	00	00	00				
152	00	00	00	00				
153	00	00	00	00				
154	00	00	00	00	4	4	4	4
155	00	00	00	00				
156	00	00	00	00				
157	00	00	00	00	4	4	4	4
158	00	00	00	00				
159	00	00	00	00				
160	00	00	00	00	4	4	4	4
161	00	00	00	00				
162	00	00	00	00				
163	00	00	00	00				
164	00	00	00	00				
165	00	00	00	00	4	4	4	4
166	00	00	00	00				
167	00	00	00	00				
168	00	00	00	00				
169	00	00	00	00				
170	00	00	00	00				

**

ORIGINAL PAGE IS
OF POOR QUALITY



1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100



171	200	200	200	200	4	4		
172	200	200	200	200				
173	401	210	210	210			4	4
174	200	200	200	200				
175	200	200	200	200				
176	200	200	200	200	4	4		
177	145	200	200	200		4	4	4
178	200	200	200	200				4
179	200	200	200	200				
180	200	200	200	200	4	4		
181	200	200	200	200				
182	200	160	160	170		4	4	
183	191	191	221	170				4
184	170	191	200	200				
185	160	191	160	160				
186	160	200	200	200	4	4		
187	200	200	200	200			4	4
188	200	200	200	200				4
189	200	200	200	200				
190	200	200	200	200	4	4		
191	200	200	200	200				
192	200	200	200	200				
193	160	200	200	200			4	4
194	200	200	200	200				
195	200	114	200	200				
196	200	200	200	200	4	4		
197	200	200	200	200				
198	200	200	200	200			4	12
199	200	200	200	200				
200	200	200	200	200	4	4		
201	200	200	200	200			4	4
202	200	200	200	200				
203	200	200	200	200				
204	200	200	200	200				
205	200	200	200	200	4	4		
206	200	200	200	200				
207	200	200	200	200				
208	200	200	200	200			149	1665
209	200	200	200	200				
210	200	200	200	200	2005	4210	4455	4580
211	200	200	200	200				
212	200	200	200	200				
213	200	200	200	200				
214	160	160	160	160				
215	175	206	175	175	4560	4700	4700	4580
216	191	221	175	175				
217	175	175	145	114				
218	200	200	200	200				
219	200	200	200	200				
220	200	200	200	200	4700	4700	4700	4700
221	200	200	200	200				
222	200	200	200	200				
223	200	200	200	200				
224	200	200	200	200	4700	4820	4820	4700
225	200	200	200	200				
226	200	200	200	200				
227	200	200	200	200				
228	200	200	200	200				
229	200	200	200	200				
230	200	200	200	200				

ORIGINAL PAGE 19
OF POOR QUALITY

1 2 26 1992 1646 6 PAGE 6 OF 6



2200					4820	2385	1870	555
2201								
2202					157	50	19	4
2203								
2204								
2205								
2206								
2207								
2208								
2209								
2210								
2211								
2212								
2213								
2214								
2215								
2216								
2217								
2218								
2219								
2220								
2221								
2222								
2223								
2224								
2225								
2226								
2227								
2228								
2229								
2230								
2231								
2232								
2233								
2234								
2235								
2236								
2237								
2238								
2239								
2240								
2241								
2242								
2243								
2244								
2245								
2246								
2247								
2248								
2249								
2250								
2251								
2252								
2253								
2254								
2255								
2256								
2257								
2258								
2259								
2260								
2261								
2262								
2263								
2264								
2265								
2266								
2267								
2268								
2269								
2270								
2271								
2272								
2273								
2274								
2275								
2276								
2277								
2278								
2279								
2280								
2281								
2282								
2283								
2284								
2285								
2286								
2287								
2288								
2289								
2290								

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32

[illegible]

2/ 26/ 1982 1646 6 PAGE 8 OF 8

ORIGINAL PAGE IS
OF POOR QUALITY

2 24 1902 1251 HPS

SUMS
FUNCTIONAL TEST

5 N 2

PAGE 1 OF 8

DATA TAPE ID 2 BULK DATA FILE # 4

SUMS FUNCTIONAL TEST

THROTTLING VALVE OPEN AND ORIFICE OPEN.

HOUSEKEEPING DATA

FILAMENT NUMBER 2

SCAN NUMBER	1	2	3	4	5	6	7	8	ANAL MUX
INTERLACE STEP	1	2	3	4	1	2	3	4	
IONIZATION ENERGY	75	75	75	75	75	75	75	75	
FILAMENT NUMBER	2	2	2	2	2	2	2	2	
CAP ON=1, OFF=2	1	1	1	1	1	1	1	1	
PLUS 15 VOLT	193	193	193	193	193	193	193	193	47.500
MINUS 15 VOLT	130	129	130	130	130	129	130	130	-14.960
ION PUMP VOLT	181	181	181	181	181	181	180	180	47.500
ION SOURCE TEMP	91	90	90	90	90	90	90	90	47.500
PRE-AMP TEMP	169	169	169	169	169	169	169	169	47.500
PLUS 5 VOLT	120	120	120	120	120	120	120	120	47.500
A/D REFERENCE VOLT	163	163	163	163	163	163	163	163	47.500
EMISSION CURRENT	125	125	125	125	125	125	125	125	47.500
COLLECTOR CURRENT	106	106	106	106	106	106	106	106	47.500
ELECTRON ACC VOLT	190	189	190	189	189	190	189	190	47.500
ION ACC VOLT	39	39	39	39	39	39	39	39	47.500

ION PUMP ANALOG
20 VOLT POWER SUP

20V 47.500
47.500

ORIGINAL PAGE 13
OF POOR QUALITY

2 26 1962

1651 HPS

SUM
FUNCTIONAL TEST

5 11 6

PAGE 2 OF 6

75 ELECTRON VOLTS IONIZATION ENERGY

SCAN STEP NO	-----HIGH MASS COLLECTOR-----				-----LOW MASS COLLECTOR-----			
	SCAN 1	SCAN 2	SCAN 3	SCAN 4	SCAN 1	SCAN 2	SCAN 3	SCAN 4
1					12			
2						4		
3							35	
4								4
5					4			
6						4		
7							4	
8								4
9					4			
10						4		
11							4	
12								4
13								
14								
15					4			
16						4		
17							4	
18								4
19					4			
20						4		
21							4	
22								4
23					4			
24						4		
25							4	
26								4
27					4			
28						4		
29							4	
30								4
31					4			
32						4		
33							4	
34								4
35					4			
36						4		
37							4	
38								4
39					4			
40						4		
41							4	
42								4
43								
44								
45					4			
46						4		
47							12	
48								4
49								
50								

[illegible]

ORIGINAL PAGE IS
OF POOR QUALITY

1961

1961



PAGE 5 OF

171	8	8	8	38	4			
172	8	130	317	603		4		
173	816	1020	1020	1020			4	
174	1050	1110	1140	1110				4
175	1110	1020	1110	1110				
176	1050	816	801	867	4			
177	121	816	816	816		4		
178	8	8	8	8			4	
179	8	8	8	8				4
180	8	8	8	8	4			
181	8	8	8	8		4		
182	8	8	8	8			4	
183	8	8	8	8				4
184	8	8	8	8				
185	8	8	8	8				
186	114	8	8	8	4			
187	8	8	8	8		4		
188	8	8	8	8			4	
189	8	8	8	8				4
190	8	8	8	8	4			
191	8	8	8	8		4		
192	8	8	8	8			4	
193	8	8	8	8				4
194	114	8	8	8				
195	114	8	8	8				
196	114	8	8	8				
197	8	8	8	8	4			
198	8	8	8	8		4		
199	8	8	8	8			4	
200	8	8	8	8				4
201	8	8	8	8	4			
202	8	8	8	8		4		
203	8	8	8	8			4	
204	8	8	8	8				4
205	8	8	8	8				
206	8	8	8	8	4			
207	8	8	8	8		4		
208	8	8	8	8			50	
209	8	8	8	8				635
210	8	8	8	8				
211	8	8	8	8	1330			
212	8	8	8	8		1635		
213	8	8	8	8			1725	
214	114	145	160	160				1755
215	130	160	145	160				
216	145	160	160	175	1785			
217	175	160	130	84		1785		
218	23	8	8	8			1785	
219	8	8	8	8				1785
220	23	8	8	8				
221	8	8	8	8	1755			
222	8	8	8	8		1785		
223	8	8	8	8			1785	
224	8	8	8	8				1785
225	8	8	8	8				
226	8	8	8	8	1785			
227	8	8	8	8		1785		
228	8	8	8	8			1785	
229	8	8	8	8				1785
230	8	8	8	8				

ORIGINAL PAGE IS
OF POOR QUALITY

2 20 1207 1051 2

PAGE 6 OF 10



2031
2032
2033
2034
2035
2036
2037
2038
2039
2040
2041
2042
2043
2044
2045
2046
2047
2048
2049
2050
2051
2052
2053
2054
2055
2056
2057
2058
2059
2060
2061
2062
2063
2064
2065
2066
2067
2068
2069
2070
2071
2072
2073
2074
2075
2076
2077
2078
2079
2080
2081
2082
2083
2084
2085
2086
2087
2088
2089
2090
2091
2092
2093
2094
2095
2096
2097
2098
2099
2100

2101
2102
2103
2104
2105
2106
2107
2108
2109
2110
2111
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123
2124
2125
2126
2127
2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148
2149
2150
2151
2152
2153
2154
2155
2156
2157
2158
2159
2160
2161
2162
2163
2164
2165
2166
2167
2168
2169
2170
2171
2172
2173
2174
2175
2176
2177
2178
2179
2180
2181
2182
2183
2184
2185
2186
2187
2188
2189
2190
2191
2192
2193
2194
2195
2196
2197
2198
2199
2200

2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217
2218
2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2300

2301
2302
2303
2304
2305
2306
2307
2308
2309
2310
2311
2312
2313
2314
2315
2316
2317
2318
2319
2320
2321
2322
2323
2324
2325
2326
2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338
2339
2340
2341
2342
2343
2344
2345
2346
2347
2348
2349
2350
2351
2352
2353
2354
2355
2356
2357
2358
2359
2360
2361
2362
2363
2364
2365
2366
2367
2368
2369
2370
2371
2372
2373
2374
2375
2376
2377
2378
2379
2380
2381
2382
2383
2384
2385
2386
2387
2388
2389
2390
2391
2392
2393
2394
2395
2396
2397
2398
2399
2400

2401
2402
2403
2404
2405
2406
2407
2408
2409
2410
2411
2412
2413
2414
2415
2416
2417
2418
2419
2420
2421
2422
2423
2424
2425
2426
2427
2428
2429
2430
2431
2432
2433
2434
2435
2436
2437
2438
2439
2440
2441
2442
2443
2444
2445
2446
2447
2448
2449
2450
2451
2452
2453
2454
2455
2456
2457
2458
2459
2460
2461
2462
2463
2464
2465
2466
2467
2468
2469
2470
2471
2472
2473
2474
2475
2476
2477
2478
2479
2480
2481
2482
2483
2484
2485
2486
2487
2488
2489
2490
2491
2492
2493
2494
2495
2496
2497
2498
2499
2500

1785

57

4

4

4

4

4

4

4

4

4

4

1360

12

4

4

4

4

4

4

4

12

4

4

4

695

4

4

4

4

4

4

4

4

4

4

4

4

210

4

4

4

4

4

4

4

4

4

4


4

4

ORIGINAL PAGE IS
OF POOR QUALITY

20 1961 1671 6

PAGE 7 OF 11



0001					4			
0002						4		
0003							4	
0004								4
0005								
0006								
0007								
0008								
0009								
0010								
0011								
0012								
0013								
0014								
0015								
0016								
0017								
0018								
0019								
0020								
0021								
0022								
0023								
0024								
0025								
0026								
0027								
0028								
0029								
0030								
0031								
0032								
0033								
0034								
0035								
0036								
0037								
0038								
0039								
0040								
0041								
0042								
0043								
0044								
0045								
0046								
0047								
0048								
0049								
0050								

ORIGINAL PAGE 19
OF FOUR QUALITY

PAGE 8 OF 8

20 20 1980 1651

351
352
353
354
355
356
357
358
359
360
361

8
8
8
8
8
8
8
8
8
8
8

8
8
8
8
8
8
8
8
8
8
8

8
8
8
8
8
8
8
8
8
8
8

8
8
8
8
8
8
8
8
8
8
8

4

4

4

4

4

4

4

4

ORIGINAL PAGE IS
OF POOR QUALITY

EXTRA DYNAMIC CALIBRATION RUNS

Runs made 3-5-82

- * Before Runs $I_{28} = 2.72 \times 10^{-12}$ A, inlet and range valves open, orifice open, throttling open, $P_{\text{chamber}} = 7 \times 10^{-9}$ Torr.
- * Ion Source Temperature = 90_{10} (HSK output) before above data was taken.
- * First run was full Dynamic, nominal profile.
(Data attached)
 - after completion of run, $I_{28} = 2.72 \times 10^{-12}$ A, 8 minutes after pump-down, range valve closed, inlet valve open, orifice open, throttling valve open, $P_{\text{chamber}} < 10^{-7}$ Torr.
- * Second run was nominal to 155 sec, then hold.
(Data attached)
 - before run, $I_{28} = 3.63 \times 10^{-12}$ A, range valve open, inlet valve open, orifice open, throttling valve open, $P_{\text{chamber}} < 10^{-7}$ Torr.
- * Third run was nominal from 500 sec to 635 sec, then hold.
(Data attached)
 - before run, $I_{28} = 4.58 \times 10^{-12}$ A, range closed, inlet open, orifice open, throttling valve open, $P_{\text{chamber}} = 3 \times 10^{-8}$ Torr.

ENTRA NOMINAL DYNAMIC PRESSURE PROFILE. 3-5-82, TAPE #203, FILE #1.

TIME	BARATRON PRESSURE	AMU 28	AMU 14
0.0	0.000146	225	107
5.2	0.000152	226	107
10.4	0.000155	227	108
20.1	0.000164	227	110
25.1	0.000169	228	110
30.0	0.000175	229	112
35.0	0.000183	230	113
40.0	0.000184	231	114
45.2	0.000195	232	115
50.0	0.000199	233	118
55.0	0.000205	235	118
60.1	0.000212	235	119
65.2	0.000217	236	121
70.2	0.000221	236	123
75.0	0.000229	239	124
80.0	0.000237	239	125
85.2	0.000247	241	126
90.2	0.000251	243	129
95.2	0.000259	243	129
100.2	0.000268	243	129
105.0	0.000272	245	131
110.2	0.000280	247	131
115.2	0.000293	248	132
120.0	0.000296	249	133
125.1	0.000301	251	133
130.1	0.000311	252	135
135.0	0.000323	254	136
140.1	0.000329	254	137
145.1	0.000340	257	138
150.0	0.000359	258	139
155.1	0.000369	260	140
160.0	0.000381	261	142
165.1	0.000387	262	143
170.0	0.000454	263	144
174.9	0.000449	265	147
179.9	0.000441	267	149
185.1	0.000457	268	151
190.1	0.000476	271	152
195.1	0.000510	271	154
200.0	0.000531	272	156
205.1	0.000560	275	158
210.0	0.000597	278	162
214.0	0.000620	278	163
219.9	0.000670	280	164
225.0	0.000691	280	166
229.9	0.000742	280	168
235.0	0.000784	290	170
239.0	0.000829	291	172
244.0	0.000946	293	174
249.0	0.000951	296	178
255.1	0.000995	299	181
259.9	0.001100	302	184
265.0	0.001150	305	188
269.9	0.001296	308	191
275.0	0.001318	312	195
280.0	0.001402	316	196
285.0	0.001594	320	199
290.0	0.001677	322	202
294.9	0.001865	325	205
300.0	0.002006	328	209
305.0	0.002195	332	214
309.9	0.002417	336	218
314.0	0.002659	340	223
320.0	0.002895	345	227
324.9	0.003059	352	230
329.0	0.003429	355	234
335.0	0.003800	358	237
339.9	0.004279	361	241
344.0	0.004706	365	246
350.0	0.005400	369	251
354.0	0.005894	375	260
360.0	0.006032	382	262
365.0	0.007003	386	245
369.9	0.008234	394	141
375.0	0.013667	397	75


ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY






0.010255	175	0.010255
0.010415	166	0.010415
0.011587	162	0.011587
0.013257	150	0.013257
0.015997	150	0.015997
0.018255	150	0.018255
0.020792	146	0.020792
0.023400	147	0.023400
0.027089	145	0.027089
0.029478	144	0.029478
0.035146	144	0.035146
0.038481	144	0.038481
0.044661	144	0.044661
0.050706	144	0.050706
0.056220	144	0.056220
0.067034	145	0.067034
0.069772	145	0.069772
0.081537	147	0.081537
0.091230	148	0.091230
0.093560	150	0.093560
0.111800	152	0.111800
0.142740	154	0.142740
0.149840	157	0.149840
0.163520	161	0.163520
0.203160	163	0.203160
0.216340	165	0.216340
0.252910	168	0.252910
0.285660	172	0.285660
0.324270	175	0.324270
0.363700	180	0.363700
0.416250	185	0.416250
0.459820	190	0.459820
0.519660	195	0.519660
0.598910	204	0.598910
0.671090	208	0.671090
0.777400	213	0.777400
0.847510	219	0.847510
0.852100	221	0.852100
1.057800	226	1.057800
1.215800	231	1.215800
1.344200	235	1.344200
1.538300	241	1.538300
1.714000	246	1.714000
1.902200	251	1.902200
2.149400	254	2.149400
2.399900	261	2.399900
2.639000	266	2.639000
2.909400	274	2.909400
3.102300	278	3.102300
3.395600	281	3.395600
3.632200	288	3.632200
3.884200	294	3.884200
4.139100	299	4.139100
4.336000	306	4.336000
4.548900	309	4.548900
4.785500	310	4.785500
4.903900	311	4.903900
5.071200	312	5.071200
5.175500	313	5.175500
5.336700	314	5.336700
5.391900	315	5.391900
5.471100	316	5.471100
5.553300	316	5.553300
5.643200	316	5.643200
5.725500	316	5.725500
5.789600	316	5.789600
5.896000	316	5.896000
5.949500	316	5.949500
6.029500	316	6.029500
6.122400	316	6.122400
6.219500	316	6.219500
6.323200	316	6.323200
6.367900	316	6.367900
6.507900	316	6.507900
6.547900	316	6.547900
6.670400	316	6.670400
6.758400	316	6.758400
6.859800	316	6.859800
6.919700	316	6.919700
7.083200	316	7.083200
7.124600	316	7.124600
7.258000	316	7.258000
7.315400	316	7.315400
7.481500	316	7.481500

799.6	7.529400	320	197
804.6	7.651900	320	197
809.6	7.756700	319	198
814.6	7.867700	320	198
819.6	7.993100	321	198
824.6	8.120500	321	199
829.6	8.257000	322	201
834.6	8.397000	324	202
839.6	8.540000	322	200
844.6	8.682000	322	200
849.6	8.821000	322	200
854.6	8.964000	322	200
859.6	9.114000	323	201
864.6	9.264000	323	201
869.6	9.417000	324	202
874.6	9.573000	324	203
879.6	9.732000	325	204
884.6	9.893000	326	205
889.6	10.055000	327	205
894.6	10.218000	327	206
899.6	10.382000	328	207
904.6	10.547000	328	207
909.6	10.713000	329	208
914.6	10.880000	329	208
919.6	11.048000	330	209
924.6	11.217000	331	210
929.6	11.387000	331	211
934.6	11.558000	332	211
939.6	11.730000	333	212
944.6	11.903000	333	213
949.6	12.077000	334	214
954.6	12.252000	334	214
959.6	12.428000	335	215
964.6	12.605000	336	216
969.6	12.783000	336	217
974.6	12.962000	337	217
979.6	13.142000	338	218
984.6	13.323000	339	219
989.6	13.505000	339	220
994.6	13.688000	340	220
999.6	13.872000	341	221
1004.6	14.057000	342	222
1009.6	14.243000	342	223
1014.6	14.430000	343	223
1019.6	14.618000	343	223
1024.6	14.807000	345	225
1029.6	15.000000	345	225
1034.6	15.193000	346	226
1039.6	15.387000	346	226
1044.6	15.582000	347	227
1049.6	15.778000	348	227
1054.6	15.975000	349	228
1059.6	16.173000	352	228
1064.6	16.372000	352	228
1069.6	16.572000	351	229
1074.6	16.773000	351	229
1079.6	16.975000	353	230
1084.6	17.178000	353	230
1089.6	17.382000	353	231
1094.6	17.587000	354	231
1099.6	17.793000	355	232
1104.6	17.999000	355	232
1109.6	18.206000	355	233
1114.6	18.414000	356	233
1119.6	18.623000	356	234
1124.6	18.833000	357	234
1129.6	19.044000	357	235
1134.6	19.256000	358	235
1139.6	19.469000	358	236
1144.6	19.683000	359	236
1149.6	19.898000	359	237
1154.6	20.114000	359	237
1159.6	20.331000	360	238
1164.6	20.549000	360	239
1169.6	20.768000	361	239
1174.6	20.988000	362	240
1179.6	21.209000	362	241
1184.6	21.431000	362	241


(



ORIGINAL PAGE
OF POOR QUALITY





ORIGINAL PAGE IS
OF POOR QUALITY



ORIGINAL PAGE IS
OF POOR QUALITY

ENTER: HOLD. PROFILE TO 155 SEC. THEN HOLD. 3-5-62. TAPE #204. FILE #2.

TIME	BARATRON PRESSURE	AMU 20	AMU 14
0.0	0.000142	107	107
5.0	0.000147	107	107
10.0	0.000147	107	107
15.0	0.000150	107	107
20.0	0.000158	107	107
25.0	0.000178	107	107
30.0	0.000179	107	107
35.0	0.000185	107	107
40.0	0.000194	107	107
45.0	0.000196	107	107
50.0	0.000205	107	107
55.0	0.000207	107	107
60.0	0.000217	107	107
65.0	0.000223	107	107
70.0	0.000223	107	107
75.0	0.000238	107	107
80.0	0.000243	107	107
85.0	0.000256	107	107
90.0	0.000259	107	107
95.0	0.000268	107	107
100.0	0.000274	107	107
105.0	0.000280	107	107
110.0	0.000285	107	107
115.0	0.000296	107	107
120.0	0.000309	107	107
125.0	0.000316	107	107
130.0	0.000325	107	107
135.0	0.000333	107	107
140.0	0.000350	107	107
145.0	0.000356	107	107
150.0	0.000371	107	107
155.0	0.000369	107	107
160.0	0.000369	107	107
165.0	0.000375	107	107
170.0	0.000368	107	107
175.0	0.000368	107	107
180.0	0.000368	107	107
185.0	0.000367	107	107
190.0	0.000367	107	107
195.0	0.000368	107	107
200.0	0.000369	107	107
205.0	0.000369	107	107
210.0	0.000368	107	107
215.0	0.000369	107	107
220.0	0.000370	107	107
225.0	0.000369	107	107
230.0	0.000368	107	107
235.0	0.000366	107	107
240.0	0.000369	107	107
245.0	0.000366	107	107
250.0	0.000369	107	107
255.0	0.000368	107	107
260.0	0.000370	107	107
265.0	0.000366	107	107
270.0	0.000365	107	107
275.0	0.000370	107	107
280.0	0.012396	107	107
285.0	0.058093	107	107





ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

ENTER: NOM. PROFILE TO 635 SEC, THEN HOLD, 3-5-82, TAPE #209, FILE #3

TIME	BARATON PRESSURE	AMU 22	AMU 14
500.0	0.192550	177	57
505.0	0.219800	179	58
510.0	0.250570	180	61
520.2	0.279150	186	66
525.1	0.213420	189	69
530.0	0.367030	192	70
535.0	0.459240	194	73
540.1	0.518830	197	75
545.0	0.556160	202	81
549.9	0.622940	206	88
555.1	0.751000	213	97
560.1	0.733700	221	101
565.1	0.761300	223	102
570.1	0.839800	225	103
575.1	0.989700	225	104
580.1	1.260500	228	107
585.0	1.586600	232	114
590.2	1.702000	241	125
595.1	1.870200	248	131
600.0	2.112300	254	134
605.1	2.424400	260	139
610.0	2.621500	264	143
615.0	2.914700	268	149
620.1	3.120000	274	153
625.1	3.387600	277	156
630.0	3.628800	281	162
634.9	3.857100	288	164
640.0	3.912200	289	166
645.0	3.888900	289	167
650.1	3.882700	290	167
655.0	3.881400	290	167
660.1	3.880700	290	167
665.1	3.882400	290	167
670.1	3.883000	290	167
675.0	3.880700	290	167
679.9	3.882800	290	167
685.1	3.880600	290	167
690.0	3.882600	290	167
694.9	3.881300	290	167



ORIGINAL PAGE IS
OF POOR QUALITY